SONY

HD OPTICAL FIBER RECEIVER

HDFR-300



HDVS

OPERATION AND MAINTENANCE MANUAL

1st Edition (Revised 3)

Serial No. 10001 and Higher

SAFETY RELATED COMPONENT WARNING

Components identified by shading and ⚠ marked on the schematic diagrams and parts list are critical to safe operation. Replace these components with SONY parts whose part numbers appear as shown in this manual or in supplements published by SONY.

Warning—This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Important—To insure that the complete system (including this peripheral) is capable of complying with the FCC requirements, it is recommended that the user make sure that the individual equipment of the complete system has a label with one of the following statements.
"This equipment has been tested with a Class A Computing Device and has been found to comply with Part 15 of FCC rules."
—or—
"This equipment complies with the requirements in Part 15 of FCC rules for a Class A Computing Device."
—or equivalent.

The shielded interface cable recommended in this manual must be used with this equipment in order to comply with the limits for a computing device pursuant to Subpart J of Part 15 of FCC rules.

WARNING:
Changing the voltage selector may require the use of a different line cord or attachment plug, or both.
To reduce the risk of fire or electric shock, refer servicing to qualified service personnel.

For the customers in Canada

This apparatus complies with the Class A limits for radio noise emissions set out in Radio Interference Regulations.

Pour les utilisateurs au Canada

Cet appareil est conforme aux normes Classe A pour bruits radioélectriques, spécifiés dans le Règlement sur le brouillage radioélectrique.

このマニュアルに記載されている事柄の著作権は当社にあり，説明内容は機器購入者の使用を目的としています。
従って，当社の許可なしに無断で複写したり，説明内容(操作，保守等）と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.
Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.
Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.
Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

Bescheinigung des Herstellers

Hiermit wird bescheinigt, daß der HD-Fiberglaskabel-Empfänger HDFR-300 in Übereinstimmung mit den Bestimmungen der Amtsblattverfügung Nr.1046/1984 funkentstört ist.
Der Deutschen Bundespost wurde das Inverkehrbringen dieses Gerätes angezeigt und die Berechtigung zur Überprüfung der Serie auf Einhaltung der Bestimmungen eingeräumt. Sony Corporation

Hinweis

Gemäß dem Amtsblatt des Bundesministers für das Post- und Fernmeldewesen Nr.163/1984 wird der Betreiber darauf aufmerksam gemacht, daß die von ihm mit diesem Gerät zusammengestellte Anlage auch den technischen Bestimmungen dieses Amtsblattes genügen muß.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

Check the metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 3.5 mA. Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 5.25 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 20 V AC range are suitable. (See Fig. A)



Fig. A. Using an AC voltmeter to check AC leakage.

目 次
TABLE OF CONTENTS

1. 取り扱い操作

1-1. 概要 ..... 1-1 (J)
1-2. 各部の名称と働き ..... 1-3 (J)
1-3. 接続 ..... 1-12 (J)
1-4. 操作 ..... 1-16 (J)
1-5. 光コネクターのクリーニング ..... 1-17 (J)
1-6. 主な仕様 ..... 1-18 (J)

1. OPERATION

1-1. Overview ..... 1-1 (E)
1-2. Location and Function of Parts ..... 1-3 (E)
1-3. Connections ..... 1-10 (E)
1-4. Operation ..... 1-14 (E)
1-5. Optical Connector Cleaning ..... 1-15 (E)
1-6. Specifications ..... 1-16 (E)

2. 設置

2-1. 開梱と再梱包 ..... 2-1 (J)
2-2. 標準付属品 ..... 2-2 (J)
2-3. 適合コネクター/ケーブル ..... 2-3 (J)
2-3-1. コネクターの入出力信号 ..... 2-3 (J)
2-3-2. 接続コネクター ..... 2-4 (J)
2-3-3. HDCCコネクターの外し方 ..... 2-5 (J)
2-3-4. ケーブルの結線 ..... 2-6 (J)
2-4. 設置 ..... 2-7 (J)
2-4-1. 設置環境 ..... 2-7 (J)
2-4-2. 外形寸法 ..... 2-7 (J)
2-4-3. 19インチラックマウント ..... 2-8 (J)
2-4-4. 付属ハーネス (ANALOG-2) の交換方法 ..... 2-9 (J)
2-5. 基板内スイッチの設定 ..... 2-10 (J)
2-6. 接続図 ..... 2-11 (J)

2. INSTALLATION

2-1. Unpacking and Repacking ..... 2-1 (E)
2-2. Supplied Accessories ..... 2-2 (E)
2-3. Connectors/Cable ..... 2-3 (E)
2-3-1. Connector Input/Output signals ..... 2-3 (E)
2-3-2. Connector ..... 2-4 (E)
2-3-3. Removal of the HDCC Connectors ..... 2-5 (E)
2-3-4. Cable wiring ..... 2-6 (E)
2-4. Installation ..... 2-7 (E)
2-4-1. Installation Conditions ..... 2-7 (E)
2-4-2. Dimensions ..... 2-7 (E)
2-4-3. 19-inch Rack Mount ..... 2-8 (E)
2-4-4. Replacement of Supplied Harness (ANALOG-2) ..... 2-9 (E)
2-5. Function of Switches on PC Board ..... 2-10 (E)
2-6. System Configuration ..... 2-11 (E)

3. サービスインフォメーション

3-1. 基板配置図 ..... 3-1 (J)
3-2. 主要部品の交換方法 ..... 3-2 (J)
3-2-1. トップパネルの取り外し ..... 3-2 (J)
3-2-2. 電源ユニットの取り外し ..... 3-2 (J)
3-2-3. コネクターパネルの取り外し ..... 3-3 (J)
3-2-4. CCUコネクターの交換方法 ..... 3-4 (J)
3-2-5. OPTICALコネクターの交換方法 ..... 3-5 (J)
3-3. 点検および保守 ..... 3-6 (J)
3-3-1. OPTICALコネクターのクリーニング ..... 3-6 (J)
3-4. サービス上の注意事項 ..... 3-7 (J)
3-4-1. 光ファイバーコードの取り扱い上の注意事項 ..... 3-7 (J)
3-4-2. 電源ユニットの注意事項 ..... 3-7 (J)
3-4-3. チップ部品交換時の注意事項 ..... 3-8 (J)
3-4-4. PROM IC ..... 3-9 (J)
3-4-5. 補修用部品の注意事項 ..... 3-9 (J)

3. SERVICE INFORMATION

3-1. Board Layout ..... 3-1 (E)
3-2. Replacement of Main Parts ..... 3-2 (E)
3-2-1. Removal of Top Panel ..... 3-2 (E)
3-2-2 Removal of Power Supply Unit ..... 3-2 (E)
3-2-3. Removal of Connector Panel ..... 3-3 (E)
3-2-4. Replacement of CCU Connector ..... 3-4 (E)
3-2-5. Replacement of OPTICAL Connector ..... 3-5 (E)
3-3. Periodic Check and Maintenance ..... 3-6 (E)
3-3-1. Optical Connector Cleaning ..... 3-6 (E)
3-4. Servicing Precautions ..... 3-7 (E)
3-4-1. Optical Fiber Cord Handling ..... 3-7 (E)
3-4-2. Power Supply Unit ..... 3-7 (E)
3-4-3. Precaution on Replacement of Chip Parts ..... 3-8 (E)
3-4-4. PROM IC ..... 3-9 (E)
3-4-5. Precaution of Replacement Parts ..... 3-9 (E)

4. 調整要項

4-1. 準備 ..... 4-1 (J)
4-1-1. 使用機器 ..... 4-1 (J)
4-1-2. 接続 ..... 4-2 (J)
4-1-3. 注意事項 ..... 4-3 (J)
4-2. 調整項目 ..... 4-3 (J)
4-2-1. 電源調整 (PS-228基板) ..... 4-4 (J)
4-2-2. +9 V調整 (VA-99基板) ..... 4-5 (J)
4-2-3. SYNC CLAMP LEVEL調整 (VA-99基板) ..... 4-6 (J)
4-2-4. +9 V調整 (OTX-11基板) ..... 4-7 (J)
4-2-5. +9 V調整 (ORX-11基板) ..... 4-8 (J)
4-2-6. OPT G/B/R周波数特性調整 (ORX-11基板) ..... 4-9 (J)
4-2-7. AUDIO周波数特性調整 (ORX-11基板) ..... 4-10 (J)
4-2-8. G/B/R信号レベル調整 (VA-99基板) ..... 4-11 (J)
4-2-9. G/B/R周波数特性調整 (VA-99基板) ..... 4-12 (J)
4-2-10. OPT LEVEL ALARM G/B/R ランプ調整 (VA-99基板) ..... 4-13 (J)
4-2-11. +20 V/+5 V (A)/+5 V (D) 調整 (AU-135基板) ..... 4-14 (J)
4-2-12. PULSE WIDTH調整 (AU-135基板) ..... 4-15 (J)
4-2-13. AUDIO LEVEL調整 (AU-135基板) ..... 4-16 (J)
4-2-14. MSB調整 (AU-135基板) ..... 4-17 (J)

4. ALIGNMENT

4-1. Preparation ..... 4-1 (E)
4-1-1. Equipment Required ..... 4-1 (E)
4-1-2. Connection ..... 4-2 (E)
4-1-3. Note on Adjustment ..... 4-3 (E)
4-2. Adjustment Items ..... 4-3 (E)
4-2-1. Power Supply Adjustment (PS-228 Board) ..... 4-4 (E)
4-2-2. +9 V Adjustment (VA-99 Board) ..... 4-5 (E)
4-2-3. SYNC Clamp Level Adjustment (VA-99 Board) ..... 4-6 (E)
4-2-4. +9 V Adjustment (OTX-11 Board) ..... 4-7 (E)
4-2-5. +9 V Adjustment (ORX-11 Board) ..... 4-8 (E)
4-2-6. OPT G/B/R Frequency Response Adjustment(ORX-11 Board) ..... 4-9 (E)
4-2-7. Audio Frequency Response Adjustment (ORX-11 Board) ..... 4-10 (E)
4-2-8. G/B/R Signal Level Adjustment (VA-99 Board) ..... 4-11 (E)
4-2-9. G/B/R Freqency Response Adjustment (VA-99 Board) ..... 4-12 (E)
4-2-10. OPT Level Alarm G/B/R Lamp Adjustment (VA-99 Board) ..... 4-13 (E)
4-2-11. +20 V/+5 V (A)/+5 V (D) Adjustment (AU-135 Board) ..... 4-14 (E)
4-2-12. Pulse Width Adjustment (AU-135 Board) ..... 4-15 (E)
4-2-13. Audio Level Adjustment (AU-135 Board) ..... 4-16 (E)
4-2-14. MSB Adjustment (AU-135 Bosrd) ..... 4-17 (E)

A. BLOCK DIAGRAMS

Overall Block Diagram A-1
ORX-11, VA-99 ..... A-4
AU-135 ..... A-7
OTX-11, CT-129, CT-130, LF-22, PS-227 ..... A-10
PS-228 ..... A-13

B. SEMICONDUCTOR

Semiconductor B-1

C. SCHEMATIC DIAGRAMS AND BOARD ILLUSTRATIONS

ORX-11 ..... C-3
VA-99 ..... C-8
AU-135 ..... C-14
OTX-11 ..... C-21
CT-129, CT-130, PS-227 ..... C-28
PS-228 ..... C-34
Frame
DP-118, DP-152, LF-22, MB-294 ..... C-39

D. SPARE PARTS

Parts Information D-1
Exploded View D-2
Screws D-12
Electrical Parts D-13
Packing Materials & Supplied Accessories D-30

E. CHANGED PARTS

第1章　取り扱い操作

1-1. 概要

HDFR-300は、HDカラーカメラHDC-300を中心とするカメラシステム用の光受信機です。本機を光ファイバーケーブルFC6-PA250/500で光送信機HDFT-300と接続することにより、ビデオ、オーディオ信号をはじめとする各種信号を多重伝送するとともに、カメラヘッド用高圧電源を供給する光伝送システムを構成できます。
光送信機HDFT-300と光受信機HDFR-300による光伝送システムの主な特長は次の通りです。

光ファイバーケーブルによる多重伝送

光送受信機を光ファイバーケーブルFC6-PA250/500で接続し、ビデオ信号、オーディオ信号、リターンビデオ信号（ビューファインダー信号）、コマンド信号（ビデオ同期信号）、インターカム信号、コントロール信号などを多重伝送します。

最長接続距離1km

ケーブル延長コネクターFC6E-PA10を使用して、光送受信機の接続距離を1kmまで延長できます。

全帯域のGBRコンポーネントビデオ信号をアナログ送信

全帯域（30MHz）のGBRコンポーネントビデオ信号をアナログ送信し、高品質の画像伝送を可能にします。

合計6チャンネルのオーディオ入力をデジタル送信

光送信機は、AES/EBUフォーマットのデジタルオーディオ入力4チャンネルとマイクなどからのアナログオーディオ入力2チャンネルの計6チャンネルを、光信号に変換して光受信機にデジタル送信します。

デジタルオーディオ6チャンネルとアナログ変換オーディオ2チャンネルを出力

光受信機は、光送信機からのデジタルオーディオ6チャンネルの出力に加えて、そのうち2チャンネルをアナログ変換して出力することができます。
オーディオ入力信号にエンファシスがかかっているときは、出力時にディエンファシスをかけます。

光送信機およびカメラヘッドの電源を光受信機から供給

光送信機およびカメラヘッドHDC-300の電源（約190V）を、光ファイバーケーブルFC6-PA250/500に内蔵の電源線（2芯）によって光受信機から供給します。

光送信機によるオーディオ同期

光送信機へのビデオ入力、デジタルオーディオ入力、または光送信機の内蔵クロックを基準クロックとして使用し、他のデジタルオーディオ機器をワード同期でロックさせることができます。

HDFT-300とHDFR-300による光伝送システム構成例



1-2. 各部の名称と働き

前面



❶ POWER（主電源）表示ランプ

POWERスイッチ❷をONにし、本機に給電が開始されると点灯します。

❷ POWER（主電源）スイッチ

ONにすると本機の主電源が入り、本機に給電が開始されます。(光送信機HDFT-300への給電の手順については、1-4「操作」をご覧ください。)

ご注意

本機は光送信機HDFT-300へ高圧電源（約190V）を供給します。POWERスイッチ❷をONにする前に、必ず所定の接続を行ってください (1-3「接続」参照)。特に、本機と光送信機HDFT-300の間の光ファイバーケーブルの接続を確認してください。

❸ OPR（高圧オペレーション）表示ランプ

本機から光送信機HDFT-300に対して高圧給電が行われている間、点灯し続けます。

❹ 通気孔

放熱用です。ふさがないようにしてください。

❺ ドアロック

下部を押し込んでアンロックし、そのまま手前に引くと前面パネルが開きます。

後面



❻ CCU（カメラコントロールユニット）マルチコネクター

本機とカメラコントロールユニットHDCS-300を、付属のマルチコアカメラケーブルHDCC-2で接続するためのコネクターです。

このコネクターに接続されたマルチコアカメラケーブルを介して、インターカム信号やコントロール信号と多重化されたGBR信号が、本機からカメラコントロールユニットへ入力されます。また、カメラコントロールユニットから本機へは、リターンビデオ信号（ビューファインダー信号）と、インターカム信号やコントロール信号と多重化されたコマンド信号（ビデオ同期信号）が入力されます。

ご注意

マルチコアカメラケーブルは、所定の特性が得られるよう必ず指定の製品をご使用ください。

❼ DIGITAL CH1/2、CH3/4、CH5/6(MIC)（デジタル出力 チャンネル1/2、3/4、5/6(マイク)）コネクター（XLR3ピン）

それぞれ次のオーディオ信号をAES/EBUのデジタルフォーマットで出力します。

CH1/2：光送信機HDFT-300のAUDIO IN DIGITAL CH1/2（デジタルオーディオ入力チャンネル1/2）コネクターに入力されたデジタルオーディオ信号

CH3/4：光送信機のAUDIO IN DIGITAL CH3/4（デジタルオーディオ入力 チャンネル3/4）コネクターに入力されたデジタルオーディオ信号

CH5/6（MIC）：光送信機のAUDIO IN ANALOG CH5、CH6（アナログオーディオ入力 チャンネル5、6）コネクターに入力されたアナログオーディオ信号

❽ ANALOG SELECT 1、SELECT 2(アナログ出力 セレクト1、セレクト2)コネクター(XLR 3ピン)

光送信機HDFT-300から送信される最大6チャンネル(3ペア)のデジタルオーディオ信号のうち、本機のAU-135基板のANALOG AUDIO OUTチャンネル選択スイッチで選択した2チャンネル（1ペア）を、アナログ信号として出力するコネクターです。出力レベルは、AU-135基板のANALOG AUDIO OUT レベル設定スイッチで、＋4dBsまたは－20dBsを選択できます。(詳しくは、AU-135基板の説明(1-9（J）ページ)を参照してください。)

ご注意

本機出荷時、❽はオスのコネクターが実装されています。メスにしたい場合は、付属のメスのコネクター(ハーネス付き)と交換してください。交換方法については、第2章以降をご覧ください。

❾ OPT（オプチカル）コネクター

本機と光送信機HDFT-300を、光ファイバーケーブルFC6-PA250/500で接続するためのコネクターです。光ファイバーケーブルは、下記の用途に割り当てられた光ファイバー6芯および電源線2芯を内蔵しています。

芯　線		伝送する信号/電源	伝送方向
光ファイバー	2芯	リターンビデオ信号（ビューファインダー信号）とコマンド信号（ビデオ同期信号）	光送信機←光受信機
	3芯	GBRコンポーネントビデオ信号	光送信機→光受信機
	1芯	デジタルオーディオ信号	光送信機→光受信機
電源線	2芯	DC電源	光送信機←光受信機

ご注意

OPTコネクターや光ファイバーケーブル端のコネクターに何も接続していないときは、必ずコネクターキャップをかぶせておいてください。

コネクターキャップをかぶせるときは、キャップおよびコネクターにほこりやごみが付着していないことを確認してください。

（OPTコネクターおよび光ファイバーケーブル端のコネクターのクリーニング方法については、1-5「光コネクターのクリーニング」を参照してください。)

⑩ ファン通風孔

内部電源冷却用ファンのための通風孔です。通風を良くするため、壁面までの距離を25cm以上あけておいてください。

⑪ AC IN（AC電源入力）コネクター

付属のAC電源コードで電源コンセントに接続します。電源コードのプラグをこのコネクターに差し込んだ後、付属のプラグホルダーでプラグを固定してください。(詳しくは1-3「接続」参照)。

⑫ VOLTAGE SELECTOR（電源電圧選択）スイッチ

使用する電源電圧に応じて、100-120Vまたは220-240Vのどちらかに設定します(1-3「接続」参照)。

ご注意

工場出荷時の設定は100-120Vです。220-240Vでご使用の際は、必ず220-240Vに切り換えてください。

前面内部

前面パネルを開くと内部基板が現れます。



前面パネルの開けかた



ドアロックの下部を押し込み、手前に引く。

ご注意

電源ユニットは高電圧を発生しています。危険ですので、ユニットを外に引き出したり、ユニット内部に触れたりしないでください。
（メンテナンスについては、第2章以降をご覧ください。）

(A) BREAKER（ブレーカー）ボタン

電源ユニットに異常電流が流れると、このボタンが突出して本機への入力電流を遮断します。操作を再開する前に、前面のPOWERスイッチをOFFにして原因を取り除き、このボタンを押し込んでください。

(B) POWER ALARM（電源アラーム）ランプ



❶ FAN（ファン）アラームランプ

電源ユニット内部の空冷ファンが停止すると点灯します。

❷ HEAT（オーバーヒート）アラームランプ

電源ユニットのスイッチング素子が過熱すると、回路が機能を停止して、このアラームランプが点灯します。

❸ LOCAL（ローカルモード）アラームランプ

電源ユニットのSELF ON/OFFスイッチS201（メンテナンス用）をONにする（コントロールパネルHDCO-300による本機のリモートコントロールが行えない状態にする）と点灯します。(詳しくは第2章以降をご覧ください。)

❹ CTRL OFF（コントロールオフ）アラームランプ

電源ユニットのON/NOR/OFFスイッチS202（メンテナンス用）を、NOR（出荷時の設定）以外に設定すると点灯します。

ご注意

通常は、ON/NOR/OFFスイッチS202をNORに設定した状態でお使いください。NOR以外の設定で使用すると危険な場合があります。

(C) AU-135基板



❶ LOCK（ロック）表示ランプ

デジタルオーディオ出力のマスタークロックとなっている信号（チャンネル）を表示します。FREEが点灯しているときは、光送信機HDFT-300の内蔵クロックがマスタークロックとなっています。

❷ DIGITAL AUDIO IN（デジタルオーディオ入力）表示ランプ

外部デジタルオーディオ信号が入力されているチャンネルを表示します。

❸ ANALOG AUDIO OUT（アナログオーディオ出力）チャンネル選択スイッチ

最大6チャンネル（CH1/2、CH3/4およびCH5/6）のデジタルオーディオ入力信号のうち、アナログ変換してANALOG SELECT 1、SELECT 2コネクターから出力させる信号（チャンネル）を選択します。

❹ ANALOG AUDIO OUT（アナログオーディオ出力）レベル設定スイッチ

ANALOG AUDIO OUTチャンネル選択スイッチ❸で選択したオーディオ信号の標準出力レベル（＋4dBsまたは－20dBs）を設定します。

❺ OPT LEVEL ALARM（受光レベルアラーム）ランプ

本基板に入力される信号の受光レベルが低下すると点灯します。

(D) VA-99基板



❶ OPT LEVEL ALARM G（G信号受光レベルアラーム）ランプ

光送信機HDFT-300から受信するコンポーネントビデオ信号のうち、G信号の受光レベルが低下すると点灯します。

❷ OPT LEVEL ALARM B（B信号受光レベルアラーム）ランプ

光送信機から受信するコンポーネントビデオ信号のうち、B信号の受光レベルが低下すると点灯します。

❸ OPT LEVEL ALARM R（R信号受光レベルアラーム）ランプ

光送信機から受信するコンポーネントビデオ信号のうち、R信号の受光レベルが低下すると点灯します。

❹ OPT LEVEL ALARM SYNC（光同期信号レベルアラーム）ランプ

光送信機に送出したコマンド信号（ビデオ同期信号）の、光送信機側での受光レベルが低下すると点灯します。

❺ OPT LEVEL ALARM VF（光ビューファインダー信号レベルアラーム）ランプ

光送信機HDFT-300に送出したリターンビデオ信号（ビューファインダー信号）の、光送信機側での受光レベルが低下すると点灯します。

ご注意

上記アラームランプが1つでも点灯した場合は、操作を一時停止して原因を取り除いてください。アラーム状態では、本機の性能は保証されません。（メンテナンスについては、第2章以降をご覧ください。）

1-3. 接続

接続および設置に関する注意事項

- 接続を行う前に、本機および光送信機HDFT-300のPOWERスイッチが両方ともOFFになっていることを必ず確認してください。
- 本機または光送信機HDFR-300に接続したケーブルを外すときも、必ず両機のPOWERスイッチをOFFにしてから外してください。
- 光送信機HDFT-300とカメラヘッドHDC-300その他の機器との接続については、HDFT-300のオペレーション アンド メンテナンスマニュアルをご覧ください。
- 光ファイバーケーブルは、コネクターブーツの色が、本機のOPTコネクターの表示（OPT）と同じ色のものをお使いください。それ以外のケーブルを接続すると、所定の機器特性を得ることができない場合があります。
- 光ファイバーケーブルを接続するときは、ケーブル端のコネクターを本機のOPTコネクターにしっかり差し込んでから、ケーブル端コネクターの締め付けリングを回して固定してください。締め付けリングは、コネクターの抜け落ちを防止するためのものです。必要以上に強く締め付けないようにしてください。
- 光ファイバー接続部にちりやごみなどの異物が入り込まないように注意してください。コネクターの端面が汚れたり傷ついたりすると、接続損失が増加して信号が劣化します。

  コネクターのクリーニング方法については、1-5「光コネクターのクリーニング」をご覧ください。
- 本機の前後面は壁などから25cm以上離してください。
- 次のような場所での設置、保管、操作は避けてください。
  - 高温または多湿の場所
  - ほこりの多い場所
  - 振動の激しい場所
  - 直射日光や強力なライトの直射を受ける場所
  - 強電界、強磁場のある場所



*1 AES/EBU規格のデジタルオーディオ入力のある機器。
*2 FC6E-PA10で光ファイバーケーブルを2本以上つなぐことにより、接続距離を1kmまで延長できます。

プラグホルダーの使用法

AC電源コード（付属）のプラグをAC INコネクターに接続した後、プラグが抜け落ちないように付属のプラグホルダーで固定してください。

プラグホルダーの取り付け



1 付属のプラグホルダーをAC電源コードにはめる。

2 AC電源コードのプラグの上からAC INコネクターにはめ込む。

プラグホルダーの取り外し



左右のレバーを押えながら引き離す。

VOLTAGE SELECTORスイッチの切り換え

本機は出荷時100-120Vに設定されています。220-240Vで使用する場合はVOLTAGE SELECTORスイッチの設定を切り換えてください。

設定の切り換えかた



1 取り付けネジと表示プレートを外す。



2 シーソースイッチの設定を切り換える。



3 表示プレートを裏返して取り付ける。

1-4. 操作

1 本機および光送信機HDFT-300側で、所定の接続と設定が正しく行われていることを確認します。

2 カメラコントロールユニットHDCS-300のMAIN POWERスイッチをONにします。

3 コントロールパネルHDCO-300のPOWERスイッチをONにします。

4 本機のPOWERスイッチをONにします。POWER表示ランプが点灯します。

5 光送信機HDFT-300のPOWERスイッチをONにします。

6 コントロールパネルHDCO-300のCHU POWERスイッチをONにします。スイッチが点滅を始めます。

光送信機HDFT-300に適正な負荷が接続されていると判定されると、本機から光送信機への給電が開始され、本機のOPR表示ランプが点灯します。(光送信機側では、POWER表示ランプが点灯します。)
(コントロールパネルHDCO-300のCHU POWERスイッチを再度押すと、光送信機への給電は停止されます。)

7 カメラヘッドHDC-300のPOWERスイッチをONにすると、カメラシステムは動作状態になります。

カメラコントロールユニットHDCS-300からカメラヘッドHDC-300へコマンド信号(ビデオ同期信号)が送られ、カメラヘッドからそれに同期したGBRコンポーネントビデオ信号が送出されると(システムの同期が取れると)、コントロールパネルHDCO-300のCHU POWERスイッチの状態が点滅から点灯に変わり、システムが正常な動作状態に入ったことを示します。

電源を切る場合は、上記の手順を逆に実行してください。

1-5. 光コネクターのクリーニング

本機や光送信機HDFT-300のOPTコネクター、光ファイバーケーブルFC6-PA250/500端部のコネクター、ケーブル延長コネクターFC6E-PA10などが汚れると、接続損失が増加して信号が劣化します。劣化が認められた場合は、これらコネクター類を次のようにしてクリーニングしてください。

1 適当な洗浄用高圧乾燥ガス（浄化された窒素ガスなど）を用意します。
2 噴射孔を少し上に向けて軽く噴射し、液体やごみなどが噴出しないことを確認します。
3 コネクターに高圧ガスを噴射して、ごみなどを吹き飛ばします。

ご注意

噴射孔の端部がコネクターに直接触れないようにしてください。

上記の方法で汚れが落ちない場合は、第2章以降を参照してクリーニングしてください。

1-6. 主な仕様

システム

発光素子	AlGaAs LED （λ＝0.85μm）	
受光素子	Si PIN-PD	
変調方式	ベースバンド	直接輝度変調
映像信号	周波数帯域	60Hz～30MHz
	S/N	47dB以上
	直線性	2%以下（100%レベルまで）
オーディオ信号	周波数帯域	20Hz～20kHz
	S/N	55dB以上（1kHz基準レベル）（MIC入力）
		65dB以上（1kHz基準レベル）（LINE入力）
	歪率	0.05%以下（1kHz基準レベル）
	ヘッドルーム	20dB以上

HDFR-300

電源　AC 90～130V/180～260V 切り換え式（50/60Hz）

消費電力　400W（max.）

入力信号

コマンド信号（ビデオ同期信号）（11ピン マルチコネクター）

0.3Vp-p、75Ω不平衡、正極性

リターンビデオ信号（ビューファインダー信号）（11ピン マルチコネクター）

1Vp-p、75Ω不平衡、正極性

出力信号

GBR信号（11ピン マルチコネクター）

1Vp-p、75Ω不平衡、正極性

オーディオ信号　アナログ（XLR 3ピン コネクター 2個、2チャンネル）

平衡　＋4dBs/－20dBs出力レベル切り換え式

（6チャンネルから2チャンネルをペアで選択）

デジタル（XLR 3ピン コネクター 3個、6チャンネル）

AES/EBUフォーマット

動作温度　0°C～40°C

外形寸法　424×88×450mm（幅/高さ/奥行き）

重量　14kg

付属品

延長基板（1）
AC電源コード（3芯プラグ付きと、先ばらコード）（各1）
プラグホルダー（1）
2p-3p変換プラグ（1）
ラックマウント金具（1式）
マルチコアカメラケーブルHDCC-2（1）
交換用オーディオ出力コネクター（メス、ハーネス付き）（1）
オペレーション アンド メンテナンス マニュアル（1）

仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

別売りアクセサリー

マルチコアカメラケーブル　HDCC-5（5m）
ケーブル延長コネクター　FC6E-PA10

Section 1. OPERATION

1-1. Overview

The HDFR-300 optical fiber receiver is designed for use with camera systems incorporating the HDC-300 HD color camera (camera head). A single FC6-PA250/500 optical fiber cable, connecting this unit to an HDFT-300 optical fiber transmitter carries the multiplexed audio and video signals along with the high voltage power for the camera head.
The following are some of the principal features of an optical transmission system using the HDFT-300 and HDFR-300 optical fiber transmitter and receiver.

Multiplexed transmission by optical fiber cable

The FC6-PA250/500 optical fiber cable connecting the optical fiber transmitter and receiver achieves multiplexed transmission of the video signals, audio signals, return video signal (viewfinder signal), command signals (video sync signal), intercom signals and control signals.

Maximum transmission distance 1 km

Using one or more FC6E-PA10 extension connectors, the distance between the optical fiber transmitter and receiver can be a maximum of 1 km (3280 ft.).

Analog transmission of full-bandwidth GBR component video signals

Analog transmission of the full-bandwidth (30 MHz) GBR component video signals enables high quality image transmission.

Digital transmission of six audio input channels

The optical fiber transmitter has a total of six (three pairs of) audio input channels: four (two pairs of) digital audio channels in AES/EBU format, and two (a pair of) analog audio input channels for connecting microphones or other analog audio equipment. These are converted to digital optical signals for transmission to the optical fiber receiver.

Receiver audio outputs

The optical fiber receiver has six (three pairs of) digital audio output channels. Additionally, it has two analog audio output channels, through which one of the three pairs of input digital audio signals can be output after conversion to analog signals. If the input signals have emphasis applied, then de-emphasis is applied on output.

Transmitter and camera head power supply from the receiver

The optical fiber receiver can supply the power (about 190 V) for the transmitter and the camera head through the pair of power lines incorporated into the FC6-PA250/500 optical fiber cable.

Audio synchronization by the transmitter

The optical fiber transmitter can use the selected video input signal, digital audio input signal or its own internal clock for word synchronization of other digital audio equipment.

Configuration example of optical fiber transmission system using HDFT-300 and HDFR-300



Principal components of the camera system	Term used in this manual
HDC-300 HD color camera	Camera head
HDCS-300 HD camera signal processor	Camera control unit
HDCO-300 HD camera operational control unit	Control panel

1-2. Location and Function of Parts

Front panel



1 POWER indicator
This indicator lights when the POWER switch 2 is turned on and power is supplied to this unit.

2 POWER switch
This controls the main power supply to this unit. (See 1-4 "Operation" for the procedure for switching on the power supply to the HDFT-300 optical fiber transmitter.)

Note

This unit provides the high voltage supply (about 190 V) to the HDFT-300 optical fiber transmitter. For safety, be sure to make the necessary connections (see 1-3 "Connections") before switching on the power. In particular, check the connections of the optical fiber cable between this unit and the HDFT-300 optical fiber transmitter.

3 OPR (high voltage operation) indicator
This indicator lights continuously when the high voltage supply is being sent to the HDFT-300 optical fiber transmitter.

4 Ventilation grille
This is for cooling purposes; do not obstruct in any way.

5 Front panel catch
Press the bottom end to unlock, then pull the top end to open the front panel.

Rear panel



6 CCU (camera control unit) connector (11-pin)

Use the HDCC-2 multicore camera cable (supplied) to connect the HDCS-300 camera control unit to this connector.

This cable inputs the GBR component video signals multiplexed with the intercom and control signals to the camera control unit from this unit, and also carries the return video signal (viewfinder signal) and the command signal (video sync signal) multiplexed with the intercom and control signals from the camera control unit to this unit.

Note

To obtain the required characteristics, always use the specified product for the multicore camera cable.

7 DIGITAL CH1/2, CH3/4, CH5/6 (MIC) connectors (XLR 3-pin)

These output the following audio signals in AES/EBU digital format.

CH1/2: The digital audio signals input to the AUDIO IN DIGITAL CH1/2 connector on the HDFT-300 optical fiber transmitter.

CH3/4: The digital audio signals input to the AUDIO IN DIGITAL CH3/4 connector on the HDFT-300 optical fiber transmitter.

CH5/6 (MIC): The analog audio signals input to the AUDIO IN ANALOG CH5 and CH6 connectors on the HDFT-300 optical fiber transmitter.

⑧ ANALOG SELECT 1, SELECT 2 connectors (XLR 3-pin)

These connectors provide analog audio outputs for one of the three audio input channel pairs sent from the HDFT-300 optical fiber transmitter. The ANALOG AUDIO OUT channel switch on the AU-135 board of this unit determines which pair of channels is converted from digital format. The output level is selectable with the ANALOG AUDIO OUT level switch on the AU-135 board to +4 dBs or −20 dBs. (For more details, see page 1-8(E).)

Note

When this unit is shipped, the connectors ⑧ are male. If you want to use female connectors, replace the male connectors with the female connectors (complete with harness) supplied with the unit. See the subsequent sections of this manual for the method of replacement.

⑨ OPT connector

This is the optical connector for the FC6-PA250/500 optical fiber cable connecting this unit to the HDFT-300 optical fiber transmitter. This cable includes six optical fiber cores and two electrical lines allocated as in the following table.

Line		Signal carried	Transmission direction
Optical fibers	2 cores	Return video signal (viewfinder signal) and command signal (video sync signal)	Transmitter ← Receiver
	3 cores	GBR component video signals	Transmitter → Receiver
	1 core	Digital audio signals	Transmitter → Receiver
Electrical lines	2 lines	DC power supply	Transmitter ← Receiver

Notes

- Always fit the connector caps on the OPT connector and the end connector of the optical fiber cable when they are not connected.
- When fitting the connector caps, ensure that there is no dirt or dust in contact with the cap or connector. (See 1-5 "Optical Connector Cleaning" for details on how to clean the OPT connector and optical fiber cable connectors.)

⑩ Fan ventilation holes

The fan cools the internal power supply unit. To ensure a sufficient flow of air through the fan, ensure that there is a gap of at least 25 cm (about 10 inches) between this rear panel and any surrounding walls.

⑪ AC IN connector

Use the power cord supplied to connect this to a power outlet. After inserting the plug in this connector, fix it with the plug holder supplied. (For details, see 1-3 "Connections")

⑫ VOLTAGE SELECTOR switch

Use this to select the AC power supply voltage (100-120 V or 220-240 V). See 1-3 "Connections".

Note

The unit is shipped with the power supply setting at 100-120 V. If using 220-240 V, be sure to change the setting first.

Internal circuit boards

To access the internal circuit boards, release the front panel catch, and open the front panel.



Opening the front panel



Press the bottom end of the front panel catch, and pull forward.

Note

The power supply unit produces a high voltage. It is dangerous, so do not remove the power supply unit or touch the interior.
(For maintenance information, see the subsequent sections of this manual.)

(A) BREAKER button

If there is a current surge in the power supply unit, the circuit breaker will operate, and this button will jump out, cutting off the power. To restart operation, first turn off the POWER switch on the front panel, and remove the cause of the fault, then push this button back in.

(B) POWER ALARM indicators



1 FAN indicator
If the cooling fan stops, this indicator will light.

2 HEAT indicator
If the switching elements in the power supply unit overheat, and the circuit can no longer function, this indicator will light.

3 LOCAL indicator
If the SELF ON/OFF switch S201 (for maintenance purposes) in the power supply unit is set to ON, this indicator will light. In this state, remote control of this unit by the HDCQ-300 control panel is not possible. (For details, see the subsequent sections of this manual.)

4 CTRL OFF indicator
This indicator lights whenever the power supply unit ON/NOR/OFF switch S202 (for maintenance purposes) is set other than to NOR. The unit is shipped with S202 set to NOR.

Note
Switch S202 should normally be in the NOR position. It may be dangerous to operate the unit with this switch set otherwise.

(C) AU-135 board



1 LOCK indicators
These indicators show which signal is being used as the master clock. When FREE is lit, the internal clock in the HDFT-300 optical fiber transmitter is being used.

2 DIGITAL AUDIO IN indicators
These show which channels the external digital audio signals are being input to.

3 ANALOG AUDIO OUT channel switch
This selects the pair of digital audio input signals (channels 1/2, 3/4 or 5/6) to be output from the ANALOG SELECT 1 and SELECT 2 connectors, after conversion to analog.

4 ANALOG AUDIO OUT level switch
Sets the standard output level (+4 dBs or −20 dBs) for the audio signals selected by the ANALOG AUDIO OUT channel switch 3

5 OPT LEVEL ALARM indicator
This indicator lights when the light level of the signal input to this board is too low.

(D) VA-99 board



1 OPT LEVEL ALARM G indicator
This indicator lights when the light level of the component video G signal from the HDFT-300 optical fiber transmitter is too low.

2 OPT LEVEL ALARM B indicator
This indicator lights when the light level of the component video B signal from the HDFT-300 optical fiber transmitter is too low.

3 OPT LEVEL ALARM R indicator
This indicator lights when the light level of the component video R signal from the HDFT-300 optical fiber transmitter is too low.

4 OPT LEVEL ALARM SYNC indicator
This indicator lights when the light level of the command signal (video sync signal) sent to the optical fiber transmitter is too low at the receiving end.

5 OPT LEVEL ALARM VF indicator
This indicator lights when the light level of the return video signal (viewfinder signal) sent to the optical fiber transmitter is too low at the receiving end.

Note

If any of the alarm indicators above comes on, stop operating the unit, and investigate and remove the cause of the problem. When any of the alarms are on, the operation of the unit cannot be guaranteed. (See the subsequent sections of this manual for details of the maintenance procedure.)

1-3. Connections

Notes on Connections and Installation

- Before making connections, check that the POWER switches on this unit and the HDFT-300 optical fiber transmitter are both off.
- Before disconnecting any cable connected to this unit or the HDFT-300 optical fiber transmitter, be sure to turn both POWER switches off.
- For details of the connections between the HDFT-300 optical fiber transmitter and the HDC-300 camera head and other units, refer to the Operation and Maintenance Manual for the HDFT-300.
- Use an optical fiber cable with a connector boot whose color matches that of the "OPT" indication on the connector of this unit. If you use any other cable, it may not have the required characteristics.
- When connecting the optical fiber cable, push the connector on the end of the cable firmly into the OPT connector on this unit, then fasten by turning the retaining ring on the cable connector. The retaining ring prevents the cable from becoming detached; do not fasten it too tightly.
- Take care that no dust, dirt or other foreign body gets into the optical fiber connections. If the connector ends get dirty or scratched, the connector loss will increase, and the signal will be degraded.
  See 1-5 "Optical Connector Cleaning" for details on how to clean the OPT connector and optical fiber cable connectors.
- Install this unit so that there is at least a 25 cm (10 inches) gap between the front and rear panels and surrounding objects.
- Do not install or store the unit in the following places:
  - In high temperatures or high humidity.
  - In very dusty places.
  - Where it is subject to severe vibration.
  - Where it is exposed to sunlight or other strong light.
  - In strong electrical or magnetic fields.



*1 Equipment having AES/EBU standard digital audio output and word sync input, such as Sony's PCM-2000 digital audio recorder.

*2 The FC6E-PA10 connector joins two optical fiber cables end to end up to a maximum length of 1 km (3280 ft.).

Use of the Plug Holder

After connecting the AC power cord to this unit, attach the plug holder (supplied with the unit) to prevent the plug from becoming detached.

Fitting the plug holder



Detaching the plug holder



Voltage Selector Setting

The unit is shipped with the power supply set to 100–120 V. Before using it with a 220–240 V supply, change the setting using the VOLTAGE SELECTOR switch.

Changing the setting



1 Remove the fixing screws and indicator plate.

2 Change the setting of the rocker switch.

3 Replace the indicator plate and fixing screws.

1-4. Operation

1 Check that the connections and settings on this unit and the HDFR-300 optical fiber transmitter are correct.

2 Turn on the MAIN POWER switch on the HDCS-300 camera control unit.

3 Turn on the POWER switch on the HDCO-300 control panel.

4 Turn on the POWER switch on this unit.
The POWER indicator will light.

5 Turn on the POWER switch on the HDFT-300 optical fiber transmitter.

6 Turn on the CHU POWER switch on the HDCO-300 control panel. The switch will begin to flash.
Once the system determines that the appropriate load is connected to the HDFT-300 optical fiber transmitter, this unit will begin supplying power to the transmitter, and the OPR indicator will come on. (On the optical fiber transmitter, the POWER indicator will light.)
(If you then press the CHU POWER switch on the HDCO-300 control panel again, the power supply to the transmitter will be cut off.)

7 Turn on the POWER switch of the HDC-300 camera head, and the camera system is ready to operate.
The command signal (video sync signal) is sent from the HDCS-300 camera control unit to the HDC-300 camera head, and the camera returns the GBR component video signals synchronized to it. When this happens, that is when the system is synchronized, the CHU POWER switch on the HDCO-300 control panel changes from flashing to continuously on, to indicate that the system is now operating normally.

When powering off the system, follow the reverse order to the procedure above.

1-5. Optical Connector Cleaning

If the OPT connector on this unit or the HDFT-300 optical fiber transmitter, or the connectors on the FC6-PA250/500 optical fiber cable get dirty, the connection loss will increase, and the signal quality will go down. If you discover a degradation in signal quality, use the following procedure to clean these connectors.

1 Use an appropriate high pressure purified and dried gas (such as pure nitrogen).

2 Point the nozzle slightly upward, and lightly expel some gas to check that no dirt or liquid is being produced.

3 Direct the jet of gas at the connector, to remove dirt and dust.

Notes

- Do not allow the nozzle to come in direct contact with the end of the connector.
- If this method does not remove the dirt, follow the cleaning procedure described in or after Section 2.

1-6. Specifications

System

Light emitting element	AlGaAs LED ($\lambda = 0.85$ µm)
Photoreceptor element	Si PIN-PD
Modulation method	Baseband direct luminance modulation
Video signals	
Frequency bandwidth	60 Hz to 30 MHz
S/N	47 dB minimum
Linearity	2% or less (to 100% level)
Audio signals	
Frequency bandwidth	20 Hz to 20 kHz
S/N	55 dB minimum (1 kHz reference level) (MIC input) 65 dB minimum (1 kHz reference level) (LINE input)
Distortion	0.05% maximum (1 kHz reference level)
Headroom	20 dB minimum

HDFR-300

Power supply	90–130 V AC or 180–260 V AC switchable (50/60 Hz)
Power consumption	400 W (max.)
Input signals	
Command signal (video sync signal) (11-pin connector)	0.3 Vp-p, 75 ohms unbalanced, positive polarity
Return video signal (viewfinder signal) (11-pin connector)	1 Vp-p, 75 ohms unbalanced, positive polarity
Output signals	
GBR component video signals (11-pin connector)	1 Vp-p, 75 ohms unbalanced, positive polarity
Audio signals	Analog (2 XLR 3-pin connectors, 2 channels) Balanced +4 dBs/−20 dBs output level switchable (Output selectable from any of the 3 input pairs) Digital (3 XLR 3-pin connectors, 6 channels) AES/EBU format
Operating temperature	0°C to 40°C (32°F to 104°F)
Dimensions (w/h/d)	424 × 88 × 450 mm (16¾ × 3½ × 17¾ inches)
Weight	14 kg (30 lb 14 oz)

Accessories supplied

Extension board (1)
AC power cords (with and without 3-pin plug fitted) (1 each)
Plug holder (1)
2-pin/3-pin adaptor (1)
Rack mounting kit (1)
HDCC-2 multicore camera cable (1)
Audio output connector conversion kit (for female connectors with harness) (1)
Operation and maintenance manual (1)

Design and specifications are subject to change without notice.

Accessory not supplied

FC6E-PA10 cable extension connector

第2章
設　置

2-1.　開梱と再梱包



2-2. 標準付属品

延長基板 "EX-252" : 1個
カード基板の点検および修理時に使用します。



電源コード : 2本
3Pプラグ付きと先バラの2種類を付属しているので使用する電源コンセントにより使い分けて下さい。



ACプラグアダプター "3P-2P" : 1個
3Pプラグ付き電源コードを2ピンの電源コンセントに変換する時に使用します。



マルチコアケーブル "HDCC-2" : 1本
HDCS-300と本体を接続するためのケーブルです。



プラグホルダー (B) : 1個
電源コードの抜け落ち防止のためのホルダーです。



ラックアングル (2U) ASSY : 1組
台形かざりワッシャーφ5用 : 4個
ネジ +RK 5×14 : 4個
ネジ +PS 4×10 : 8個
19インチラックに収納する際に使用します。
取り付け方は2-4-3. 19インチラックマウントを参照して下さい。



ハーネス (ANALOG-2) : 1本
ANALOG OUTコネクタの交換用のハーネスです。
交換方法は、2-4-4. 付属ハーネス (ANALOG-2) の交換方法を参照して下さい。



OPERATION & MAINTENANCE MANUAL : 1冊

2-3. 適合コネクター/ケーブル

2-3-1. コネクターの入出力信号

主なコネクターの入出力信号は次の通りです。

CCU (11P, MALE)



PIN No.	SIGNAL	REMARK for SIGNAL
1	COMMAND IN	SERIAL DATA for CAMERA Control
2	RETURN VIDEO IN	Zi=75Ω 1.0 Vp-p
3	R (VA) VIDEO OUT	V 0.7 Vp-p, 75Ω
4	G (VA) VIDEO OUT	V 0.7 Vp-p, 75Ω
5	B (VA) VIDEO OUT	V 0.7 Vp-p, 75Ω
6	⊕POWER SENSE OUT	DC+10.6 V～+25 V
7	⊖POWER SENSE OUT	
8	REG (+17 V) IN	DC+10.6 V～+25 V 3A
9	GND (+17 V)	
10	NC	Non connection
11	NC	

OPTICAL (8P, FEMALE)



PIN No.	SIGNAL	REMARK for SIGNAL
1	High Volt. IN (+)	DC+100 V～+200 V
2	OPT. R-CHV IN	OPT. Sig
3	OPT. B-CH IN	
4	OPT. G-CH IN	
5	High Volt. IN (–)	DC+100 V～+200 V
6	OPT. SYNC-CH OUT	OPT. Sig
7	OPT. VF-CH OUT	
8	OPT. D-AUD-CH IN	

DIGITAL OUT (3P, MALE)



PIN No.	SIGNAL	REMARK for SIGNAL
1	D-AUD OUT (G)	AES/EBU Digital Audio interface
2	D-AUD OUT (+)	
3	D-AUD OUT (–)	

ANALOG OUT (3P, FEMALE)
(3P, MALE)





(supplied parts)

PIN No.	SIGNAL	REMARK for SIGNAL
1	A-AUD OUT (G)	Zo = Low
2	A-AUD OUT (X)	
3	A-AUD OUT (Y)	

2-3-2. 接続コネクター

設置時、サービス時等において、コネクターパネル部の各種コネクターにケーブルを接続する際には、その先端に次に記すコネクター又は同等品を使用して下さい。

コネクターの機能名称	接続するケーブル側のコネクターの部品番号および名称
CCU (11P, FEMALE)	1-564-916-11 HDCC PLUG, 11P FEMALE 7-613-099-30 TV CCX CABLE or HDCC cable assembly HDCC-2 (2 m/6.4 feet)
OPTICAL (8P, FEMALE)	OPTICAL FIBER cable assembly ※ FC6-PA250 (250 m) FC6-PA500 (500 m)
ANALOG SELECT OUT (3P, FEMALE) (or 3P, MALE)	1-508-084-11 (1-508-083-11 XLR-3P, MALE XCR-3P, FEMALE) or CANNON XLR-3-12C (CANNON XLR-3-11C)
DIGITAL OUT (3P, MALE)	1-508-083-11 XLR-3P, FEMALE or CANNON XLR-3-11C

※ OPTICAL FIBER cableはプラグの交換はできません。

2-3-3. HDCCコネクターの外し方

Step 1.
ビスを外す。



Step 2.
コネクターをカメラ又はプロセッサーに接続し, 固定する。



Step 3.
反時計方向に回し, コネクターをゆるめる。



Step 4.
あとは手で外れます。



Step 5.
左図のように分解されます。



2-3-4. ケーブルの結線

HDCCケーブル



11P CONNECTOR (FEMALE)
(WIRING SIDE)

11P CONNECTOR (MALE)
(WIRING SIDE)

2-4. 設置

2-4-1. 設置環境

動作温度　0°～ +40℃
保存温度
湿度

- できるだけ乾燥した、風通しの良い場所に置いて下さい。
- 次のような場所は避けて下さい。
  1. 高温の部屋、熱源の近く
  2. ホコリや振動の激しい場所
  3. 直射日光や強力なライト等が直接当たる所
  4. 強電界、強磁場の所

- できるだけ上部を上に向けて設置してください。
- 前方と後方は壁等から25cm以上離して通風を良くしてください。
- 光ファイバーケーブルの延線と巻き取り時は80kg以上の張力をかけないようにしてください。

2-4-2. 外形寸法

単位記号: mm



2-4-3. 19インチラックマウント

HDFR-300は、付属のラックアングルASSYを使ってEIA標準の19インチラックに収納できます。

(1) ラックアングルを取り付けます。



(2) 別表スライドレールのインナーメンバーを、取り付けます。



推奨レール：モデル305 18, 22インチ

(3) 脚4本を、外します。



(4) ラックにブラケットとスライドレールのアウターメンバーを取り付けます。

(5) 付属のネジとかざりワッシャーを使ってラックと固定します。



2-4-4. 付属ハーネス (ANALOG-2) の交換方法

(1) トップパネルを外します。

(2) ネジ (+BVTT 3x8) とコネクターCN71を、外しハーネス (ANALOG-1) を取り外します。



(3) 付属のハーネス (ANALOG-2) を、(1)～ (2) の逆の手順で取り付けます。



2-5. 基板内スイッチの設定

•AU-135基板

S1 (ANALOG AUDIO OUT CHANNEL)

3系統のディジタルオーディオのうち、どのCHをアナログ出力するかを選択するスイッチです。

S2 (ANALOG AUDIO OUT LEVEL)

アナログ出力の基準レベルを+4d Bsにするか-20 dBsにするかを選択するスイッチです。

2-6. SYSTEM CONFIGRATION



FIXED FOCAL LENSES

Focal length (mm)	Manufacturer
9.5	FUJINON
13	FUJINON
18	FUJINON
30	FUJINON
50	FUJINON
9	NIKON
15	NIKON
21	NIKON
30	NIKON
50	NIKON

ZOOM LENSES

Focal length (mm)	Manufacturer
12.5 – 70	NIKON
12.5 – 75	FUJINON
12 – 84	NIKON
12 – 120	NIKON
11 – 121	FUJINON
15 – 180	FUJINON
23.5 – 282	NIKON
12.5 – 175	FUJINON
18 – 400	FUJINON

第3章
サービスインフォメーション

3-1. 基板配置図



3-2. 主要部品の交換方法

3-2-1. トップパネルの取り外し

ネジ (+BVTT 3×5) を6本外し、本体よりトップパネルを、外します。



3-2-2. 電源ユニットの取り外し

ネジ (+BVTT 3×6) を4本外し、電源ユニットを引き出します。



3-2-3. コネクターパネルの取り外し

(1) トップパネルを、取り外します。
(2) ネジ (+BVTT 3x5) 6本と、各々のコネクターを外し、
コネクターパネルを取り外します。

- CCUコネクターからのハーネスの外し方は3-2-4.を、
OPTICAL コネクターからのハーネスの外し方は、
3-2-5.を参照して下さい。



3-2-4. CCUコネクターの交換方法

(1) トップパネルを取り外します。

(2) ネジ (+BVTT 3×5 2本、+BVTT 3×6 2本) を外し、ハーネス補正板Assy、ORX-11基板、OTX-11基板を外します。
注意) OTX-11基板とORX-11基板を外すとき、光ファイバーコード及び光コネクタ部に無理な力が加わらないように、十分に注意して取り扱い下さい。光ファイバーコードは引っ張ったりはさみこんだり、最小径が30 mmφ以下に曲げないようにして下さい。



(3) コネクターCN11とMB-294基板のコネクターCN101～CN501を外します。

(4) ネジ(+BVTT 3×5) を4本外しCCUコネクターを、ハーネスごと取り外します。



(5) 新しいCCUコネクター (ソニー部品番号：1-946-217-11) を (1)～(4) の逆の手順で取り付けます。
注1;ハーネス補正板Assyを取り付ける際には、図のようにカラーチューブの後端が、ハーネス補正板Assyのくし歯部分より、内側になるように取り付けて下さい。



3-2-5. OPTICALコネクターの交換方法

(1) トップパネルを取り外します。
(2) ORX-11基板のD101～D401とOTX-11基板のD101, D201より光プラグを抜きます。
(3) コネクターCN21を外します。
(4) ダストキャップを開け、ネジ(+B 3x6)を4本外しOPTICALコネクターをハーネスごと取り外します。
注1;光プラグを抜く時は、光ファイバーコードは絶対に持たないで図のように光プラグを直接持って抜いて下さい。
注2;光ファイバーコードを取り扱う時は、引っぱったりはさみこまないようにして下さい。又、最少径が30 mmより小さく曲げないようにして下さい。



(5) 新しいOPTICALコネクター(ソニー部品番号：A-7602-076-A)の防塵キャップを外し、(1) ~ (4) の逆の手順で取り付けます。
注3;防塵キャップを外す時は、光ファイバーコードは絶対に持たないで、図のように光プラグを持ち防塵キャップを引き抜いて下さい。
注4;光プラグを差し込む時は、図のように光プラグを直接持って差し込んで下さい。
注5;図のように光プラグを取り付けた時に、カラーチューブの後端がハーネス補正板Assyのくし歯部分より内側になるようにハーネス補正板Assyを取り付けて下さい。



3-3. 点検および保守

3-3-1. OPTICALコネクターのクリーニング

OPTICALコネクターおよび光ファイバーケーブル端のプラグ、中間アダプターなどが汚れると伝送信号が劣化します。従って、下記要領とサービス上の注意事項を参照して定期的にクリーニングを行ってください。

(1) 高圧ガスによるクリーニング方法
定期的に行う軽い汚れに対応する方法です。
- 清浄高圧ガス (フィルターに通された窒素ガスなど) を、少し上に向けて軽く噴射し、液体や油脂等が噴出しないことを確認します。
- 下図の場所に高圧ガスを噴射してゴミ等を吹き飛ばします。(図②はリセプタクルインサートをつけたままで行います。)

注1：ガス噴出孔の端部が、コネクター端子部に触れないようにして下さい。
注2：ガス噴射中に液を噴出させないで下さい。

(2) エチルアルコールによるクリニーング法
高圧ガスでクリーニングしても汚れが取り除けなかった場合に行います。この場合、光ファイバーの先端部やアダプターを傷つけたり、綿ぼこりを残したりするので十分注意して行って下さい。
- エチルアルコールを十分にしみこませたきれいな綿棒で、下図の場所を軽く拭きます。(図②はリセプタクルインサートをつけたままで行います。)
- クリーニング後高圧ガスを軽く噴出させて、アルコール分を吹き飛ばします。

(3) 以下の方法でもOPTICALコネクター部の汚れがとれない場合は図②のようにリセプタクルインサートを外して高圧ガスやエチルアルコールでクリーニングします。クリーニング後は、リセプタクルインサートの穴と光ファイバー先端部との位置が合っているのを確認してからリセプタクルインサートを押し込み、元の位置に戻します。そして中心のねじを締めて固定して下さい。このとき、光ファイバー先端部とリセプタクルインサートがぶつかって光ファイバー先端部を傷つける可能性が高いので、必要なとき以外は行わないでください。又、作業は十分注意して



3-4. サービス上の注意事項

3-4-1. 光ファイバーコードの取り扱い上の注意事項

コネクターパネルのOPTICALコネクターから出ている6本の水色の線材は光ファイバーコードです。従ってコードを折ったり最少径が30 mm以下に曲げたりしないで下さい。
又、このファイバーコードとコネクターおよびプラグの接続には特殊治具を必要とするため、部品単体での交換は出来ません。ハーネス付6芯OPTICALコネクター (ソニー部品番号 : A-7602-076-A) を単位として交換して下さい。



ハーネス付 6 芯OPTICALコネクター

3-4-2. 電源ユニットの注意事項

電源ユニット故障の場合はユニット毎交換して下さい。
万一、電源ユニット (スイッチングレギュレター) を修理する際は、下記のような注意が必要になります。

(1) 本機は高圧、大容量の電源を供給しているので感電に十分注意を要します。
(2) 電源スイッチを切っても、しばらくはコンデンサに電荷が残っているため感電の危険があります。電源を切った後も数分間は感電に注意して下さい。
(3) 電源単体を無負荷で動作させると電源が故障する恐れがあります。電源ユニット単位でのチェックは絶対に行わないで下さい。
(4) 動作中に異常が起きた電源が発振を停止した場合、再度電源スイッチを入れ直さない限り復帰しません。再度入れ直す時は、1分間以上間をおいて下さい。

3-4-3. チップ部品交換時の注意事項

コンデンサー



端を電極が覆っている

抵抗



側面に電極がない

ダイオード、トランジスタ



用意する工具: 20W程度の半田ゴテ（可能ならば、コテの温度が270±10℃にコントロールできる温度コントローラーを使用する。）
編組線(ソルダートール)
半田(0.6mm径のものが望ましい)
ピンセット

半田付け条件： コテ温度270±10℃
端子1か所を2秒以内に半田付けすること。

手順

1. 抵抗又はコンデンサーを外す場合は、半田ゴテの先をチップ部品の上にのせて部品を加熱し、半田が溶けた状態で横にずらして外します。
   ダイオード又はトランジスターの場合は、チップ部品の片側に足が2本出ている方を同時に加熱し、半田が溶けたら部品を上に起こして足2本を外します。次にもう片方の足を外すようにします。
2. 外した後、ランド表面を平らにするために、編組線を使って半田を吸い取って下さい。
3. 取り外した部分のパターンはがれ、隣接半田付け部のダメージ、ブリッジなどがないことを目視にて確認します。
4. パターンにうすく予備半田します。
5. 新しいチップ部分をパターンにのせ両端を半田付けします。

   取り外したチップ部品は再度使用しないこと。

   詳しくは、チップ・マニュアル ソニー部品番号9-963-089-01を参照して下さい。

3-4-4. PROM IC

PROM ICにはオリジナル品名の末尾にそのプログラムの名称が記載されています。
又、バージョン変更された場合、この末尾の名称が変わります。
オリジナル品名のみは(プログラム化されていない) 絶対に使用しないで下さい。
尚、各基板に使われているICは全てソケット化しています。

3-4-5. 補修用部品の注意事項

(1) 安全重要部品
回路図、分解図、電気部品表中、⚠ 印及び▒▒で囲まれた部品は安全性を維持するために重要な部品です。従って、これらの部品を交換するには必ず指定の部品と交換して下さい。

(2) 部品の共通化
ソニーから供給される部品はセットに実装されているものと異なることがあります。これは部品の共通化、改良等によるものです。分解図や電気部品表中には現時点での共通化された部品が記載されています。

(3) 部品在庫
分解図、電気部品表中、SP欄がSで示されている部品は常時在庫しています。
SP欄が"O"で示されている部品は交換頻度が低い部品であるので在庫しないことがあり、納期が長くなることがあります。

(4) コンデンサ、インダクタ、抵抗の単位
回路図、分解図、電気部品表中、特に明記したものを除き、下記の単位は省略されています。
コンデンサ : μF
インダクタ : μH
抵抗 : Ω

SECTION 3
SERVICE INFORMATION

3-1. BOARD LAYOUT



3-2. REPLACEMENT OF MAIN PARTS

3-2-1. Removal of Top Panel

Remove the six screws (+BVTT 3×5) and remove the top panel.



3-2-2. Removal of Power Supply Unit

Remove the four screws (+BVTT 3×6) and remove the power supply unit



3-2-3. Removal of Connector Panel

(1) Remove the top panel.
(2) Remove the six screws (+BVTT 3×5) and disconnect the connectors as the illustration. The connector panel will be removed.

In removing the CCU connector and the OPTICAL connector, refer to Section 3-2-4 and 3-2-5.



3-2-4. Replacement of CCU Connecter

(1) Remove the top panel.

(2) Remove the screws (+BVTT 3×5 (2 pcs.), +BVTT 3×6 (2 pcs.)) and then remove the harness correction plate Ass'y, the ORX-11 board, and the OTX-11 board.

Note: In removing the OTX and ORX boards, do not overstress the optical fiber cords and optical connector. Do not pull or pinch the optical fiber cords between things.
Also, do not bent them under 30 mmϕ.



(3) Disconnect the connector CN11 and disconnect the five connectors CN101 to CN501 on the MB-294 board.

(4) Remove the four screws (+BVTT 3×5) and remove the CCU connector with harness connected.



(5) Insert a new CCU connector (Sony parts No. 1-946-217-11) in a reverse order of the above procedures.

Note1: If the harness correction plate Ass'y is installed, it must be installed as shown in the figure so that the back end of the color tube is placed inside the comb-tooth section of the harness correction plate Ass'y.



3-2-5. Replacement of OPTICAL Connector

(1) Remove the top panel.
(2) Disconnect the optical plugs D101 to D401 on the ORX-11 board and D101 and D201 on the OTX-11 board.
(3) Disconnect the connector CN21.
(4) Open the dust cap. Remove the four screws (+B 3×6), and remove the OPTICAL connector with harness connected.

Note1: In removing the optical plugs, do not hold the optical fiber cords, but hold the optical plugs as the illustration.

Note2: In handling the optical fiber cords, do not pull them or pinch them between things. Also do not bent them under 30 mm ø.

(5) Remove the dust protection caps from the optical plugs. Insert a new OPTICAL connector (Sony part No. A-7602-076-A) through the hole in the connector panel from outside, then fix them in a reverse order of the above procedures.

Note3: In removing the dust protection caps, do not hold the optical fiber cords, but hold the optical plugs as the illustration.

Note4: In inserting the optical plugs, hold them on the heads as the illustration.

Note5: The harness correction plate Ass'y must be installed so that the back end of the color tube is placed inside the comb-tooth section of the harness ccorrection plate Ass'y when the optical plug is mounted.





3-3. PERIODIC CHECK AND MAINTENANCE

3-3-1. Optical Connector Cleaning

The signal loss may be caused by dirt or dust on the optical connector, the optical fiber cable, or the cable extension connector. To prevent this, clean them periodically as follows referring to the servicing precautions.

(1) Cleaning by high tension gas spray

Use the clean high tension gas spray (filtered nitrogen gas etc.) for periodical cleaning to remove slight stains.

- Slant the gas spray slightly upward, and press the bottom to check that no fluid or oil sprays out.
- Spray onto the parts which are indicated in the illustrations below, and remove the dust.
  (Clean the optical connector without removing the receptacle insert. -Illust. ②)

Note1: Be sure not to touch the connector terminal with the gas spray nozzle.

Note2: Be sure not to spray the fluid during the cleaning.

(2) Cleaning by ethyl alcohol.

Use ethyl alcohol for stains which cannot be removed by the gas spray.

- Saturate a clean cotton-tipped applicator with ethyl alcohol, and wipe lightly the parts indicated in the illustrations below. (Clean the optical connector without removing the receptacle insert. -Illust. ②)
- After wiping, spray the gas lightly and blow away the alcohol.

Note: Pay special attention not to damage the tips of the optical fibers or the cable extension connector, or not to leave a piece of cotton attached on them.

(3) If the stains on the optical connector cannot be removed by the two methods mentioned above, remove the receptacle insert as the illustration ②, and clean by the high tension gas spray or ethyl alcohol.
After cleaning, insert the receptacle insert making sure that its holes exactly fit the tips of the optical fiber, and fix it tightening the center screw. In doing this, a miss-touch between the optical fiber and the receptacle insert may damage the tips of the optical fiber connector. Do not do this unless it is absolutely necessary.



3-4. SERVICING PRECAUTIONS

3-4-1. Optical Fiber Cord Handling

The six sky-blue cords from the optical connectors of the connector panel are the optical fiber cords. Do not fold or bend them under 30 mm ø.
A special jig is required to connect the optical fiber cords with a connector and a plug, so it is impossible to replace only a part. If one or more of the six cords is disconnected, the 6-fiber optical connector with harness (Sony part No. A-7602-076-A) must be replaced as a unit.



6-fiber OPTICAL connector with harness

3-4-2. Power Supply Unit

When the power supply unit (switching requlator) goes out of order, replace the whole unit. If repair is required, take the following precautions.

(1) The power supply unit supplies considerable power of high voltage, so take precautions to prevent electric shock.

(2) Since the capacitor remains charged for a while after the power is switched off, take precautions to prevent electric shock for a few minutes, even after disconnecting the power supply unit.

(3) Running the power supply unit under no load may cause power source trouble, so never check the power supply unit independently.

(4) In case of a trouble during the operation, the power supply unit stops oscillating and does not refunction until the power switch is turned off, then to on again. Wait 1 minute or longer before setting the power switch to on again.

3-4-3. Precaution on Replacement of Chip Parts



Tools required:

Soldering iron of approx. 20W
(Use a temperature controller, if possible, which can control the iron temperature to 270±10℃)
Braided wire (SOLDER TAUL)
Solder (A solder of 0.6mm in diameter is recommended.)
Tweezers

Soldering conditions:

Iron temperature of 270±10℃
A connector should be soldered within 2 seconds.

Do not reuse parts which have been removed.

For details, refer to CHIP COMPONENTS MANUAL, Sony's parts No. 9-972-289-91 prepared by Sony Corporation.

Procedures

(1) To remove a resistor or capacitor, place the tip of a soldering iron on chip parts to heat the parts, and then move it horizontally for removal while being desoldered.
For removal of a diode or transistor, heat the one side, with two pins, of chip parts at the same time, set the parts up when desoldered, and remove the two pins. And then, remove the pin on another side.

(2) Absorb solder by using a braided wire to smooth the land surface of board after removal.

(3) Confirm by visual check that no trace is come off, no adjacent parts is damaged or no bridging occur.

(4) Perform a thin pretinning on the trace.

(5) Place new chip parts on the trace to solder its both sides.

3-4-4. PROM IC

Each PROM IC on the PC board has a suffix to its original designation. This suffix may change according to improvement of IC. Never use an IC having no suffix to its original designation, because its memory has not been programmed. Each PROM IC is mounted to the PC board via socket.

3-4-5. Precaution of Replacement Parts

(1) Safety Related ComponentsWarning
Components identified by shading marked with ⚠ on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony parts whose parts numbers appear as shown in this manual or in service bulletins and service manual supplements published by Sony.

(2) Standardization of Parts
Replace parts that are supplied from Sony Parts Center can sometimes have different shape and external appearance than what are actually used in equipment. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts." This manual's exploded view and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present."

(3) Stocked Parts
The parts marked with "S" in the SP column of the exploded views and electrical spare parts list are normally required for routine service work. Orders for parts marked with "O" will be proceed, but allow for additional delivery time.

(4) Units of Capacitors, Inductors, and Resistors
The following units are omitted in the schematic diagrams, exploded views, and electrical part lists unless otherwise specified;
Capacitor : μF
Inductor : μH
Resistor : Ω

第 4 章
調整要項

4-1. 準備

4-1-1. 使用機器

J-6029-140-A	パターンボックス PTB-500

PTB-100も使用できます。



J-6026-110-A	マルチバーストチャート



A-7515-188-A	延長基板 EX-252

付属品



- HDVSカメラシステム
  - HDC-300
  - HDCS-300
  - HDCO-300
  - HDFT-300
- HDVSモニタ
  - HDM-1220 (または相当品)
  - HDM-90 (または相当品)

測定器

- デジタル電圧計
- オシロスコープ (テクトロニクス社2465または相当品)
- 周波数カウンタ
- HDVS波形モニタ (テクトロニクス社1730HDまたは相当品)
- オーディオアナライザ(シバソク社AH87Bまたは相当品)

4-1-2. 接続


HDC-300 color camera
PTB-500
Pattern box
more than 3m
3200° K
650W
HD
CHART
more than 3m
HDCC-5
multicore camera cable
HDFT-300
3200° K
650W
FCA-PA250/500
optical fiber cable
HDM-1220/1220E
color monitor
FC6E-PA10
cable extension connector
HDFR-300
75 Ω × 3
HDCC-2
multicore camera cable
HDCS-300 camera
signal processor
1730HD
waveform monitor
HDM-90
monochrome monitor
1A 2A 3A
75 Ω × 3
VIDEO
IN
PIX MON OUT
75 Ω
HDCO-300 camera operational
control unit

4-1-3. 注意事項

- 本機は電源部分に非常な高圧を生じるため、調整を行なう時には特に注意して下さい。
- 調整に使用するHDVSカメラシステムは、完全に調整されていることが必要です。
- 接続を行なう場合や基板を延長する場合等は、必ず電源をOFFしてから行なって下さい。
- HDVSカメラシステム各機器の操作及び初期設定は、それぞれの操作マニュアルに従って行なって下さい。
- 調整を行なう前に、本機を含むHDVSカメラシステムの電源をONにして、約30分間ウォーミングアップを行なって下さい。
- 特に指示が無い限り、HDFR-300とHDFT-300との接続には、ケーブル延長コネクター (FC6E-PA10) を用いて250 mのOPTファイバーケーブル (FC6-PA250) を2本使用します。尚、250 mのOPTファイバーケーブルが無い場合には、500 mのOPTファイバーケーブル (FC6-PA500) が使用できます。
- OTX-11基板のボリュームのセッティング
  工場出荷時には、下記のようになっていますので調整しないで下さい。

RV101	反時計方向一杯
RV201	
RV102	時計方向一杯
RV202	

4-2. 調整項目

4-2-1. 電源調整 (PS-228基板)
4-2-2. +9 V調整 (VA-99基板)
4-2-3. SYNC CLAMP LEVEL調整 (VA-99調整)
4-2-4. +9 V調整 (OTX-11基板)
4-2-5. +9 V調整 (ORX-11基板)
4-2-6. OPT G/B/R周波数特性調整 (ORX-11基板)
4-2-7. AUDIO周波数特性調整 (ORX-11基板)
4-2-8. G/B/R信号レベル調整 (VA-99基板)
4-2-9. G/B/R周波数特性調整 (VA-99基板)
4-2-10. OPT LEVEL ALARM G/B/Rランプ調整 (VA-99基板)
4-2-11. +20 V/+5 V (A)/+5 V (D) 調整 (AU-135基板)
4-2-12. PULSE WIDTH調整 (AU-135基板)
4-2-13. AUDIO LEVEL調整 (AU-135基板)
4-2-14. MSB調整 (AU-135基板)

4-2-1. 電源調整 (PS-228基板)

注意事項: 危険が伴いますので、ふだんはこの調整を行なわないで下さい。どうしても調整が必要な場合は、高電圧に細心の注意を払い絶対に感電しないように行なって下さい。

測定器: デジタル電圧計

準備: 電源をOFFにした状態で天板を取りはずし、電源ユニットを引き出します。そして電源ユニットの天板を取りはずし、再び電源ユニットをセットし、電源をONします。また、調整終了後は、電源をOFFにして注意しながら電源ユニットの天板をもとに戻して下さい。尚、電源ユニットの天板着脱時は必ず電源コードをはずして下さい。

調整手順:

測定点 /PS-228基板	調整箇所 /PS-228基板	規格
TP1 (GND: E1)	⊘RV202	20.75±0.02 V
TP2 (GND: E1)	⊘RV203	9.75±0.02 V
TP3 (GND: E1)	⊘RV201	5.75±0.02 V



PS-228 BOARD (COMPONENT SIDE)

測定器: デジタル電圧計

基板延長: VA-99基板

調整手順:

測定点/ VA-99基板	調整箇所/ VA-99基板	規格
TP1 (GND: E1)	◐RV1	9.00±0.03 V
TP3 (GND: E2)	◐RV2	9.00±0.03 V



測定器: オシロスコープ

基板延長: VA-99基板

準備:

- HDCO-300のTEST CHUスイッチを押して、テスト波形を出力させます。

調整手順:

1. TP303/VA-99基板のSYNC CLAMP LEVEL "A" が規格になるように ◐RV301/VA-99基板を調整します。
2. 同様に、B-ch, R-chについても同じ方法で行ないます。

	測定点/ VA-99基板	調整箇所/ VA-99基板	規格
G-ch	TP303 (GND: E302)	◐RV301	A=75±5 mV
B-ch	TP203 (GND: E202)	◐RV201	
R-ch	TP103 (GND: E102)	◐RV101	





(PANEL SIDE) VA-99 BOARD (COMPONENT SIDE)

4-2-4. +9 V調整 (OTX-11基板)

測定器: デジタル電圧計

基板延長: OTX-11基板

測定点: TP1 (GND: E1)/OTX-11基板

調整箇所: ◐ RV1/OTX-11基板

規格: 9.00±0.03 V



OTX-11 BOARD (COMPONENT SIDE)

4-2-5. +9 V調整 (ORX-11基板)

測定器: デジタル電圧計

基板延長: ORX-11基板

測定点: TP1 (GND: E1)/ORX-11基板

調整箇所: ◐RV1/ORX-11基板

規格: 9.00±0.03 V



ORX-11 BOARD (COMPONENT SIDE)

測定器: オシロスコープ

基板延長: OTX-10基板/HDFT-300

被写体: バーストチャート



モニタ画面



基準波形

測定波形

調整手順:
基準点の波形に対して、測定点の全体の波形が同等になるように下記の調整箇所を調整します。

	基準点/ HDFT-300 OTX-10基板	測定点/ ORX-11基板	調整箇所/ ORX-11基板
G-ch	TP301 (GND: TP302)	TP301 (GND: E301)	L: RV302 M: RV302 H: RV301
B-ch	TP201 (GND: TP202)	TP201 (GND: E201)	L: RV203 M: RV202 H: RV201
R-ch	TP101 (GND: TP102)	TP101 (GND: E101)	L: RV103 M: RV102 H: RV101



ORX-11 BOARD (COMPONENT SIDE)

注意事項: 下記の写真は、250 mのOPTファイバーケーブル (FC6-PA250) を使用して測定したものです。500 mのものを使用した時には、信号レベルが減少します。けれどもこの調整には影響ありません。

測定点: TP-401(GND: E401)/ORX-11基板

調整手順:

1. ◐RV403, ◐RV402/ORX-11基板のボリュームをメカニカルセンターにします。
2. "A"部の波形がフラットになるように ◐RV401/ORX-11基板を調整します。









ORX-11 BOARD (COMPONENT SIDE)

測定器: オシロスコープ

基板延長: VA-99基板
OTX-10基板/HDFT-300

準備:

- HDCO-300のTEST CHUスイッチを押して、テスト波形を出力させます。

調整手順:

1. TP-301/OTX-10基板のレベル "A" に対して、TP304/VA-99基板の信号レベル "B" が2倍になるように ◐ RV302/VA-99基板を調整します。
2. 同様に、B-ch, R-chについても同じ方法で行ないます。



	基準点/ HDFT-300 OTX-10基板	測定点/ VA-99基板	調整箇所/ VA-99基板
G-ch	TP301 (GND: TP302)	TP304 (GND: E302)	◐ RV302
B-ch	TP201 (GND: TP202)	TP204 (GND: E202)	◐ RV202
R-ch	TP101 (GND: TP102)	TP104 (GND: E102)	◐ RV102



測定器: オシロスコープ

基板延長: VA-99基板
OTX-10基板/HDFT-300

被写体: バーストチャート



モニタ画面

調整手順:

基準点の波形に対して、測定点の波形が同等になるように下記の調整箇所を調整します。
但し、測定点のレベルは基準点のレベルに対して2倍のレベルがありますので、オシロスコープのVOLTS/DIVを調整して、同じレベルにしてから調整します。



基準波形

測定波形

	基準点/ HDFT-300 OTX-10基板	測定点/ VA-99基板	調整箇所/ VA-99基板
G-ch	TP301 (GND: TP302)	TP304 (GND: E303)	RV303
B-ch	TP201 (GND: TP202)	TP204 (GND: E203)	RV203
R-ch	TP101 (GND: TP102)	TP104 (GND: E103)	RV103



(PANEL SIDE) VA-99 BOARD (COMPONENT SIDE)

測定器: オシロスコープ

基板延長: VA-99基板
ORX-11基板

準備:

• HDCO-300のTEST CHUスイッチを押して、テスト波形を出力させます。

調整手順:

1. オシロスコープを見ながら、TP301/VA-99基板のレベル "A" が200±10 mVp-pになるまで、ORX-11基板のD301のコネクターを少しずつ抜きます。そして、Gランプ/VA-99基板が点灯するように ◐RV304/VA-99基板を調整します。
2. D301のコネクターを差し、レベル "A" が220±10 mVp-pになった時、Gランプが消灯することを確認します。
3. 同様にB-ch, R-chについても同じ方法で行ないます。



	コネクター/ ORX-11基板	測定点/ VA-99基板	調整箇所/ VA-99基板
G-ch	D301	TP301 (GND: E301)	◐RV304
B-ch	D201	TP201 (GND: E201)	◐RV204
R-ch	D101	TP101 (GND: E101)	◐RV104



(PANEL SIDE) VA-99 BOARD (COMPONENT SIDE)

測定器: デジタル電圧計

基板延長: AU-135基板

調整手順:

測定箇所/ AU-135基板	調整箇所/ AU-135基板	規格
TP1 (GND: TPE1)	RV1	20.00±0.03 V
TP3 (GND: TPE1)	RV2	5.00±0.03 V
TP5 (GND: TPE1)	RV3	5.00±0.03 V



(PANEL SIDE) AU-135 BOARD (COMPONENT SIDE)

測定器:　オシロスコープ

基板延長:　AU-135基板

調整手順:

1. オシロスコープCH-1のプローブをTP18/AU-135基板 (GND:TPE2), CH-2のプローブをTP7/AU-135基板 (GND: TPE2) に接続します。
2. 次のような波形が見えるようにオシロスコープを設定します。



パルスとパルスの間隔が
最も狭い部分を拡大します。



3. 上の波形パルス幅:Aを調整します。
A=70±3 ns



(PANEL SIDE)　AU-135 BOARD (COMPONENT SIDE)

測定器: オーディオアナライザ, オシロスコープ

基板延長: AU-135基板

準備:

- オーディオアナライザの入力、出力端子を短絡 (Zo=600 Ω, Zi=10 kΩ) させ内蔵発振器からの信号 (f=1 kHz, level=24 dBs) を確認します。
- オーディオアナライザ ; 入力インピーダンス→600 Ω
- HDFT-300 ; LEVEL SW/CONNECTOR PANEL→+4 dBs
- HDFR-300 ; ANALOG AUDIO OUT
  選択スイッチ/AU-135基板→CH 5/6
  ANALOG AUDIO OUT
  LEVELスイッチ/AU-135基板→+4 dBs側

調整手順:

1. 次図の様な接続をします。



2. 次の波形になるように次表に示す所を調整して下さい。



測定チャンネル	測定点/ AU-135基板	調整箇所/ AU-135基板	規格
5-ch	TP101 (GND: TPE1)	RV102	9.6±0.1 V
6-ch	TP201 (GND: TPE1)	RV202	

注意事項: この設定のまま、次の調整へ進みます。



(PANEL SIDE) AU-135 BOARD (COMPONENT SIDE)

4-2-14. MSB調整 (AU-135基板)

注意事項: この調整において、使用するオーディオアナライザーにMONITOR OUTPUT端子がついていない場合には、オシロスコープによる波形の観測をしなくてもかまいません。

測定器: オーディオアナライザ, オシロスコープ

基板延長: AU-135基板

準備:

- オーディオアナライザを歪率測定モードにします。
- オシロスコープの入力端子とオーディオアナライザのMONITOR OUTPUT端子を接続します。
- オーディオアナライザ; 30 kHz L.P.F→ON
  OUTPUT LEVEL→+4 dBs
  (Zo=600 Ω, Zi=10 kΩで測定)

調整手順:

測定チャンネル	調整箇所/AU-135基板	規格
5-ch	◐RV101	歪率最小 (0.05%以下) 且つ、MONITOR OUTPUT の波形を次のようにする。
6-ch	◐RV201	

MONITOR OUTPUTの波形



NG



OK



(PANEL SIDE) AU-135 BOARD (COMPONENT SIDE)

SECTION 4
ALIGNMENT

4-1. PREPARATION

4-1-1. Equipment Required

J-6029-140-A	Pattern Box PTB-500

PTB-100 is also available.



J-6026-110-A	Burst Chart



A-7515-188-A	Extension board EX-252

Supplied accessory



•HDVS Camera System
  HD Color Camera HDC-300
  HD Camera Signal Processor HDCS-300
  HD Camera Operational Control Unit HDCO-300
  HD Optical Fiber Transmitter HDFT-300
•HDVS Monitor
  HDM-1220 or equivalent
  HDM-90 or equivalent

Measuring Equipment
- •Digital Voltmeter
- •Oscilloscope (Tektronix 2465 or equivalent)
- •Frequency Counter
- •HDVS Waveform Monitor (Tektronix 1730HD or equivalent)
- •Audio Analyzer (Shibasoku AH87B or equivalent)

4-1-2. Connection



4-1-3. Note on Adjustment

- The power supply unit supplies considerable power of high voltage, so take precautions to prevent electric shock during the adjustment.
- Completely-aligned HDVS camera system is required for adjustment.
- Be sure to turn off the power of the HDFR before connecting the system or extracting PC board.
- For details on the operation and initial setting of individual HDVS system equipment, follow the operation manual supplied with each equipment.
- Before beginning adjustments, warm up all of the HDVS system for about 30 minutes.
- Use the two optical fiber cables (FC6-PA250) connected via the cable extension connector (FC6E-PA10) for connection between the HDFR-300 and the HDFT-300, otherwise specified. Without the optical fiber cable of 250 m (FC6-PA250), one cable of 500m (FC6-PA500) is usable.
- Do not adjust the following controls on the OTX-11 board, maintaining them at the factory-set position.

RV101	Fully counterclockwise
RV201	
RV102	Fully clockwise
RV202	

4-2. ADJUSTMENT ITEMS

4-2-1. Power Supply Adjustment (PS-228 Board)
4-2-2. +9 V Adjustment (VA-99 Board)
4-2-3. SYNC Clamp Level Adjustment (VA-99 Board)
4-2-4. +9 V Adjustment (OTX-11 Board)
4-2-5. +9 V Adjustment (ORX-11 Board)
4-2-6. OPT G/B/R Frequency Response Adjustment (ORX-11 Board)
4-2-7. Audio Frequency Response Adjustment (ORX-11 Board)
4-2-8. G/B/R Signal Level Adjustment (VA-99 Board)
4-2-9. G/B/R Freqency Response Adjustment (VA-99 Board)
4-2-10. OPT Level Alarm G/B/R Lamp Adjustment (VA-99 Board)
4-2-11. +20 V/+5 V (A)/+5 V (D) Adjustment (AU-135 Board)
4-2-12. Pulse Width Adjustment (AU-135 Board)
4-2-13. Audio Level Adjustment (AU-135 Board)
4-2-14. MSB Adjustment (AU-135 Board)

4-2-1. POWER SUPPLY ADJUSTMENT (PS-228 BOARD)

Note:
Do not perform this adjustment for a routine maintenance because the power supply unit supplies the considerable power of the high voltage. If necessary, take the greatest possible care to prevent electric shock during the adjustment.

Equipment: Digital voltmeter

Preparation:
Turn off the power. Remove the top panel of the unit and pull out the power supply unit. Remove the top cover of the power supply unit and reinstall the power supply unit. Then turn on the power and perform the following adjustment. After the adjustment, turn off the power and install the top cover of the power supply unit, taking care of electric shock. In removing and installing the top cover of the power supply unit, be sure to disconnect the power cord.

Adjustment procedure:

Test Point /PS-228 board	Adj. Point /PS-228 board	Specification
TP1 (GND: E1)	⊘RV202	20.75±0.02 V
TP2 (GND: E1)	⊘RV203	9.75±0.02 V
TP3 (GND: E1)	⊘RV201	5.75±0.02 V



PS-228 BOARD (COMPONENT SIDE)

4-2-2. +9 V ADJUSTMENT (VA-99 BOARD)

Equipment: Digital voltmeter

To be extended: VA-99 board

Adjustment procedure:

Test point/ VA-99 board	Adj. point/ VA-99 board	Specifications
TP1 (GND: E1)	⊘ RV1	9.00±0.03 V
TP3 (GND: E2)	⊘ RV2	9.00±0.03 V



(PANEL SIDE) VA-99 BOARD (COMPONENT SIDE)

4-2-3. SYNC CLAMP LEVEL ADJUSTMENT (VA-99 BOARD)

Equipment: Oscilloscope

To be extended: VA-99 board

Preparation:

- To output the test signal, press the TEST CHU switch on the HDCO-300.

Adjustment procedure:

1. Adjust ◐RV301/VA-99 board so that the sync clamp level "A" meets the specification.
2. Perform the same manner for B-ch and R-ch.

	Test Point/ VA-99 board	Adj. Point/ VA-99 board	Specification
G-ch	TP303 (GND: E302)	◐RV301	A=75±5 mV
B-ch	TP203 (GND: E202)	◐RV201	
R-ch	TP103 (GND: E102)	◐RV101	





4-2-4. +9 V ADJUSTMENT (OTX-11 BOARD)

Equipment: Digital voltmeter

To be extended: OTX-11 board

Test point: TP1 (GND: E1)/OTX-11 board

Adjusting point: ⊘ RV1/OTX-11 board

Specification: 9.00±0.03 V



OTX-11 BOARD (COMPONENT SIDE)

4-2-5 +9 V ADJUSTMENT (ORX-11 BOARD)

Equipment: Digital voltmeter

To be extended: ORX-11 board

Test point: TP1 (GND: E1)/ORX-11 board

Adjusting point: ⊘ RV1/ORX-11 board

Specification: 9.00±0.03 V



ORX-11 BOARD (COMPONENT SIDE)

4-2-6. OPT G/B/R FREQUENCY RESPONSE ADJUSTMENT (ORX-11 BOARD)

Equipment: Oscilloscope

To be extended: OTX-10 board/HDFT-300

Object: Burst chart



Monitor screen

Adjustment procedure:

Adjust the following potentiometers so that overall waveform is the same as reference waveform.

	Ref. waveform/ HDFT-300/ OTX-10 board	Test Point/ ORX-11 board	Adj. Point/ ORX-11 board
G-ch	TP301 (GND: TP302)	TP301 (GND: E301)	L: RV302 M: RV302 H: RV301
B-ch	TP201 (GND: TP202)	TP201 (GND: E201)	L: RV203 M: RV202 H: RV201
R-ch	TP101 (GND: TP102)	TP101 (GND: E101)	L: RV103 M: RV102 H: RV101





ORX-11 BOARD (COMPONENT SIDE)

4-2-7. AUDIO FREQUENCY RESPONSE ADJUSTMENT (ORX-11 BOARD)

Note:
The pictures below are measured in use of 250 m OPT fiber cable (FC6-PA250). When 500 m OPT fiber cable (FC6-PA500) is used, the level will be decreased. However, either 250 m cable or 500 m cable can be used for this adjustment.

Equipment: Oscilloscope

Test Point TP401 (GND: E401)/ORX-11 board

Adjustment procedure:
1. Set ⊘ RV403, and ⊘ RV402/ORX-11 board to the mechanical center position.
2. Adjust ⊘ RV401/ORX-11 board so that the waveform of portion "A" is flat.









ORX-11 BOARD (COMPONENT SIDE)

4-2-8. G/B/R SIGNAL LEVEL ADJUSTMENT (VA-99 BOARD)

Equipment: Oscilloscope

To be extended: VA-99 board
OTX-10 board/HDFT-300

Preparation:

- To output the test signal, press the TEST CHU switch on the HDCO-300.

Adjustment procedure:

1. Adjust ⊘ RV302/VA-99 board so that the level "B" at TP304 /VA-99 board is doubled as compared with the level "A" at TP301/OTX-10 board.
2. Perform the same manner for B-ch and R-ch.



	Reference level/ HDFT-300 OTX-10 board	Test Point/ VA-99 board	Adj. Point/ VA-99 board
G-ch	TP301 (GND: TP302)	TP304 (GND: E302)	⊘ RV302
B-ch	TP201 (GND: TP202)	TP204 (GND: E202)	⊘ RV202
R-ch	TP101 (GND: TP102)	TP104 (GND: E102)	⊘ RV102



(PANEL SIDE) VA-99 BOARD (COMPONENT SIDE)

4-2-9. G/B/R FREQUENCY RESPONSE ADJUSTMENT (VA-99 BOARD)

Equipment: Oscilloscope

To be extended: VA-99 board
OTX-10 board/HDFT-300

Object: burst chart



Monitor screen



Reference Waveform

Test Point

Adjustment procedure:
Adjust the following potentiometers so that the waveform at the test point is the same as reference waveform.

Note:
The level at the test point is doubled. To compare the waveform, adjust the VOLTS/DIV control knob of the oscilloscope.

	Ref. waveform/ HDFT-300 OTX-10 board	Test Point/ VA-99 board	Adj. Point/ VA-99 board
G-ch	TP301 (GND: TP302)	TP304 (GND: E303)	RV303
B-ch	TP201 (GND: TP202)	TP204 (GND: E203)	RV203
R-ch	TP101 (GND: TP102)	TP104 (GND: E103)	RV103



(PANEL SIDE) VA-99 BOARD (COMPONENT SIDE)

4-2-10. OPT LEVEL ALARM G/B/R LAMP ADJUSTMENT (VA-99 BOARD)

Equipment: Oscilloscope

To be extended: VA-99 board
ORX-11 board

Preparation:

- To output the test signal, press the TEST CHU switch on the HDCO-300.

Adjustment procedure:

1. Pull carefully the D301 connector on the ORX-11 board until the level "A" at TP301/VA-99 board becomes 200±10 mVp-p observing the oscilloscope. Then, adjust ⊘ RV304/VA-99 board so that the G lamp lights up.
2. Insert the D301 connector a little until the level "A" becomes 220±10 mVp-p and make sure that the G lamp should go off.
3. Perform the same manner for B-ch and R-ch.



	Connector/ ORX-11 board	Test Point/ VA-99 board	Adj. Point/ VA-99 board
G-ch	D301	TP301 (GND: E301)	⊘ RV304
B-ch	D201	TP201 (GND: E201)	⊘ RV204
R-ch	D101	TP101 (GND: E101)	⊘ RV104



4-2-11. +20 V/+5 V(A)/+5 V(D) ADJUSTMENT (AU-135 BOARD)

Equipment: Digital voltmeter

To be extended: AU-135 board

Adjustment procedure:

Test Point/ AU-135 board	Adj. Point/ AU-135 board	Specification
TP1 (GND: TPE1)	RV1	20.00±0.03 V
TP3 (GND: TPE1)	RV2	5.00±0.03 V
TP5 (GND: TPE1)	RV3	5.00±0.03 V



(PANEL SIDE) AU-135 BOARD (COMPONENT SIDE)

4-2-12. PULSE WIDTH ADJUSTMENT (AU-135 BOARD)

Equipment: Oscilloscope

To be extended: AU-135 board

Preparation:

1. Connect the probe of the CH1 to TP18/AU-135 board (GND: TPE2) and that of the CH2 to TP7/AU135 board (GND: TPE2).
2. Set the oscilloscope so that the following waveform is displayed.



Enlarge the portion where the pulse interval is narrowest.



3. Adjust the pulse width A for 70 ±3nS.



(PANEL SIDE) AU-135 BOARD (COMPONENT SIDE)

4-2-13. AUDIO LEVEL ADJUSTMENT (AU-135 BOARD)

Equipment: Audio Analyzer

To be extended: AU-135 board

Preparation:

- Short between the input and output terminals of the audio analyzer (Zo=600 Ω, Zi=10k Ω). Check the signal from the built-in oscillator of 1kHz, -24dBs is output.
- Set the input impedance of the audio analyzer to 600 ohms.
- LEVEL switch/HDFT-300 connector panel → +4dBs
- ANALOG AUDIO OUT select switch
  /AU-135 board (HDFR-300) → 5/6CH
- ANALOG AUDIO OUT LEVEL switch
  /AU-135 board (HDFR-300) → +4dBs

Adjustment procedure:

1. Connect the audio analyzer as the illustration.



2. Adjust the potentiometer shown in the table for the following waveform.



Channel	Test Point/ AU-135 board	Adj. Point/ AU-135 board	Specification
5-ch	TP101 (GND: TPE1)	RV102	9.6±0.1 V
6-ch	TP201 (GND: TPE1)	RV202	

Note: Proceed the next step, maintaining the above settings.



4-2-14. MSB ADJUSTMENT (AU-135 BOARD)

Note:
If the MONITOR OUTPUT terminal is not equipped with the audio analyzer, omit the observation of the waveform.

Equipment: Audio Analyzer

To be extended: AU-135 board

Preparation:
- Put the audio analyzer into the DIST (distortion) mode.
- Connect the input terminal of the oscilloscope with the MONITOR OUTPUT terminal of the audio analyzer.
- 30kHz L.P.F switch/Audio analyzer → ON
- OUTPUT LEVEL switch/Audio analyzer → +4dBs
  (Measured at Zo=600 Ω, Zi=10 kΩ)

Adjustment procedure:

Channel	Adj.point/ AU-135 board	Specification
5-ch	⊘RV101	Adjust so that the distortion ratio is minimum (less than 0.05%) and the waveform at the MONITOR OUTPUT terminal is as follows.
6-ch	⊘RV201	

Waveform at MONITOR OUTPUT terminal



NG



OK



(PANEL SIDE) AU-135 BOARD (COMPONENT SIDE)

SECTION A
BLOCK DIAGRAMS

OVERALL BLOCK



OVERALL BLOCK
HDFR-300

ORX-11 VA-99 ORX-11 VA-99

ORX-11 BLOCK
VA-99 BLOCK





ORX-11 BLOCK
HDFR-300

VA-99 BLOCK
HDFR-300

AU-135 BLOCK



AU-135 BLOCK
HDFR-300

OTX-11 PS-227 CT-129/130 LF-22

OTX-11 BLOCK
PS-227 BLOCK
CT-129/130 BLOCK
LF-22 BLOCK



OTX-11 BLOCK
HDFR-300

PS-227 BLOCK
CT-129 BLOCK
CT-130 BLOCK
LF-22 BLOCK
HDFR-300

PS-228 BLOCK



PS-228 BLOCK
HDFR-300

SECTION B
SEMICONDUCTOR

The circuit diagram of IC is obtained from the IC data book published by the manufacturer.

TYPE	PAGE
11EQS10	B-2
1S1555	B-2
1SS119	B-2
1SS123	B-2
1SS226	B-2
1SZ46A	B-2
1T34	B-2
2SA1162	B-2
2SA1226	B-2
2SA1283	B-2
2SA1441	B-2
2SA1462	B-2
2SA1469	B-2
2SA812	B-2
2SB733	B-2
2SB734	B-2
2SC1252	B-2
2SC1622A	B-2
2SC1623	B-2
2SC2688	B-2
2SC2712	B-2
2SC2714	B-2
2SC2733	B-2
2SC2758	B-2
2SC2785	B-2
2SC3243	B-2
2SC3460	B-2
2SD773	B-2
2SD774	B-2
3SK163	B-2
5P6M	B-2
AM26LS31CNS	B-3
AM26LS32ACNS	B-3
AQV203A	B-3
CX23065A	B-3
DTA114ES	B-2
DTC114ES	B-2
ERA22-06	B-2
ERA84-009	B-2
ERB44- ? ?	B-2
ESAD92M-02	B-2
FMB-29L	B-2
HSM88AS	B-2
LM358PS	B-3
M5237L	B-3
MBM27C64-30	B-3
MC14011BCP	B-3
MC14013BF	B-4
MC14052BF	B-4
MC14528BF	B-4
MC14584BCP	B-4
MC74HC4049F	B-4
MC74HC4050F	B-4
MC79L ? ? ACP	B-4
NJM5534M	B-5
PCM78P-J-1	B-5
RD ? ? ESB ?	B-2
RD ? ? ESL ?	B-2
RD ? ? M-B ?	B-2
RU3AM	B-2
SN74HC00NS	B-5
SN74HC04NS	B-5
SN74HC08NS	B-5
SN74HC161NS	B-5
SN74HC163NS	B-6
SN74HC164NS	B-6
SN74HC174NS	B-6
SN74HC175NS	B-6
SN74HC32NS	B-6
SN74HC374NS	B-6
SN74HC74NS	B-7
SN74LS624NS	B-7
SSM2016P	B-7
TC74AC153F	B-7
TC74AC163F	B-6
TC74HC4049F	B-4
TC74HC4050AF	B-4
TC74HC4538AF	B-7
TDA1535	B-8
TL062CPS	B-8
TL1451ACN	B-8
TL431CLP	B-8
TL7705ACPS	B-8
TLC27M2CPS	B-8
TLG124A	B-2
TLGC135AP	B-2
TLP621	B-2
uPC311G2	B-8
uPC319G2	B-8
uPC339C	B-8
uPD4011BC	B-3



11EQS10
1S1555
1SS119
ERA22-06
ERA84-009
ERB44- ? ?
RU3AM

(SCALE 4/1)
TOP VIEW



1SS123
1SS226
HSM88AS



1SZ46A

BOTTOM VIEW



1T34



5P6M



ESAD92M-02



FMB-29L



RD ? ?ESB ?
RD ? ?ESL ?

(SCALE 4/1)
TOP VIEW



RD ? ?M-B ?



TLG124A ; GREEN
TLGC135AP ; GREEN

TOP VIEW



TLP621

(SCALE 4/1)
TOP VIEW



2SA1162
2SA1226
2SA1462
2SA812



2SA1283



2SA1441



2SA1469



2SB733
2SB734

BOTTOM VIEW



2SC1252

(SCALE 4/1)
TOP VIEW



2SC1622A
2SC1623
2SC2712
2SC2714
2SC2733
2SC2758



2SC2688

TYPE NO.
PRINTED



2SC2785



2SC3243



2SC3460



2SD773
2SD774

(SCALE 3/1)



3SK163



DTA114ES (R1 = 10K, R2 = 10K)



DTC114ES (R1 = 10K, R2 = 10K)

AM26LS31CNS (TI) FLAT PACKAGE

HIGH SPEED DIFFERENTIAL LINE DRIVER

– TOP VIEW –



FUNCTION TABLE		
EN2	EN1	OUTPUT
0	0	ENABLE
0	1	ENABLE
1	0	HI-Z
1	1	ENABLE

0 ; LOW LEVEL
1 ; HIGH LEVEL
HI-Z ; HIGH IMPEDANCE

AM26LS32ACNS (TI) FLAT PACKAGE

HIGH SPEED DIFFERENTIAL LINE RECEIVER

– TOP VIEW –



FUNCTION TABLE		
EN2	EN1	OUTPUT
0	0	ENABLE
0	1	ENABLE
1	0	HI-Z
1	1	ENABLE

0 ; LOW LEVEL
1 ; HIGH LEVEL
HI-Z ; HIGH IMPEDANCE

	SENSE	INPUT VOLT
LS32	±200mV	±7V
LS33	±500mV	±15V

AQV203A (MATSUSHITA) FLAT PACKAGE

PHOTO MOS RELAY

– TOP VIEW –



CX23065A (SONY)

N-MOS PHASE COMPARATOR WITH INVERSION AMPLIFIER

– PRINTED SIDE VIEW –



EN	OUT
1	ACTIVE
0	HIGH IMPEDANCE

1 ; HIGH LEVEL
0 ; LOW LEVEL

TIMING CHART



HI-Z ; HI-IMPEDANCE

LM358PS (TI) FLAT PACKAGE

DUAL OPERATIONAL AMPLIFIERS

– TOP VIEW –



M5237L (MITSUBISHI)

ADJUSTABLE VOLTAGE REGULATOR



MBM27C64-30 (FUJITSU) (ACCESS TIME = 300nS)

C-MOS 64K (8K-8) ERASABLE PROM WITH 3-STATE OUTPUTS

– TOP VIEW –





A0–A12 ; ADDRESS
CE ; CHIP ENABLE
D0–D7 ; DATA OUTPUT
OE ; OUTPUT ENABLE
PGM ; PROGRAM ENABLE
VPP ; PROGRAM VOLTAGE



An	CE	OE	PGM	VPP	Dn	FUNCTION
An	0	0	1	+5V	D OUT	READ
An	0	1	1	+5V	HI-Z	OUTPUT DISABLE
An	0	0	0	+5V	HI-Z	OUTPUT DISABLE
X	1	X	X	+5V	HI-Z	STANDBY
An	0	X	⊓	+21V	DIN	PGM
An	0	0	1	+21V	D OUT	PGM VERIFY
X	1	X	X	+21V	HI-Z	PGM INH

0 ; LOW LEVEL
1 ; HIGH LEVEL
X ; DON'T CARE
HI-Z ; HIGH IMPEDANCE

MC14011BCP (MOTOROLA)
uPD4011BC (NEC)

C-MOS 2-INPUT NAND GATE

– TOP VIEW –





A	B	Y
0	0	1
0	1	1
1	0	1
1	1	0

0 : LOW LEVEL
1 : HIGH LEVEL

MC14013BF (MOTOROLA) FLAT PACKAGE

C-MOS D-TYPE FLIP-FLOP WITH DIRECT SET/RESET
– TOP VIEW –



DIRECT R-S FLIP FLOP			
Sd	Rd	Q	$\overline{Q}$
0	0	Qn	$\overline{Qn}$
0	1	0	1
1	0	1	0
1	1	1	1

0; LOW LEVEL
1; HIGH LEVEL

D-TYPE FLIP FLOP	
CKn	CKn+1
D	Q
0	0
1	1

CLOCK CK; ⌐¯
CKn; BEFORE CLOCK
CKn+1; AFTER CLOCK



MC14052BF (MOTOROLA) FLAT PACKAGE

C-MOS DUAL 4-CHANNEL ANALOG MULTIPLEXER/DEMULTIPLEXER
– TOP VIEW –



VEE*; VDD – VEE = +3 to +18V

CONTROL INPUTS			"ON" CHANNEL
EN	B	A	
0	0	0	0
0	0	1	1
0	1	0	2
0	1	1	3
1	X	X	OPEN

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE.

MC14528BF (MOTOROLA) FLAT PACKAGE

C-MOS RETRIGGERABLE/RESETTABLE MMV
– TOP VIEW –



INPUTS			OUTPUTS	
CK1	CK2	Rd	Q	$\overline{Q}$
⌐¯	1	1	⌐¯	¯⌐
⌐¯	0	1	0	1
1	¯⌐	1	Q	$\overline{Q}$
0	¯⌐	1	⌐¯	¯⌐
X	X	0	0	1

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

OUTPUT PULSE WIDTH Q OR $\overline{Q}$
• (FOR Cx ≧ 0.01μF USE FORMULA)
PW = 0.2 • Rx • Cx • ℓn (VDD – GND)
• (FOR Cx < 0.01μF USE DATA BOOK.)



MC14584BCP (MOTOROLA)

C-MOS SCHMITT TRIGGER INVERTER
– TOP VIEW –



MC74HC4049F (MOTOROLA) FLAT PACKAGE
TC74HC4049F (TOSHIBA) FLAT PACKAGE

C-MOS HEX BUFFER/CONVERTER (INVERTING)
– TOP VIEW –



A	Y
0	1
1	0

0; LOW LEVEL
1; HIGH LEVEL

MC74HC4050F (MOTOROLA) FLAT PACKAGE
TC74HC4050AF (TOSHIBA) FLAT PACKAGE

C-MOS NON-INVERTING TYPE BUFFER/CONVERTER
– TOP VIEW –



A	Y
0	0
1	1

0; LOW LEVEL
1; HIGH LEVEL

MC79L ? ?ACP (MOTOROLA)

NEGATIVE VOLTAGE REGULATOR (100mA)



OUTPUT VOLTAGE	NJM79L??A	RC79L??A	AN79L??	MC79L??ACP
-3V	NJM79L03A	RC79L03A	-------	----------
-4V	----------	--------	AN79L04	----------
-5V	NJM79L05A	RC79L05A	AN79L05	MC79L05ACP
-6V	NJM79L06A	RC79L06A	AN79L06	----------
-7V	----------	--------	AN79L07	----------
-8V	NJM79L08A	RC79L08A	AN79L08	----------
-9V	NJM79L09A	RC79L09A	AN79L09	----------
-10V	----------	--------	AN79L10	----------
-12V	NJM79L12A	RC79L12A	AN79L12	MC79L12ACP
-15V	NJM79L15A	RC79L15A	AN79L15	MC79L15ACP
-18V	NJM79L18A	RC79L18A	AN79L18	MC79L18ACP
-20V	----------	--------	AN79L20	----------
-24V	NJM79L24A	RC79L24A	AN79L24	MC79L24ACP

NJM5534M (JRC) FLAT PACKAGE

OPERATINAL AMPLIFIER

– TOP VIEW –



PCM78P-J-1 (BURR-BROWN)

A/D CONVERTER

– TOP VIEW –



C.CMD ; CONVERTER COMMAND SIGNAL
S.CYC ; SHORT CYCLE TIMING
STUS ; STATUS SIGNAL
WD CK ; WORD CLOCK



SN74HC00NS (TI) FLAT PACKAGE

C-MOS QUAD 2-INPUT NAND GATE

– TOP VIEW –





A	B	Y
0	0	1
0	1	1
1	0	1
1	1	0

0; LOW LEVEL
1; HIGH LEVEL

TYPE	VDD
TC74AC00P	+2 to +5.5V
MC74HCT00N 74ACT00PC	+5V
OTHER TYPES	+2 to +6V

SN74HC04NS (TI) FLAT PACKAGE

C-MOS HEX INVERTER

– TOP VIEW –





A	Y
0	1
1	0

0: LOW LEVEL
1: HIGH LEVEL

NOTE :

TYPE	VDD
74ACT04 TYPES 74HCT04 TYPES	+5V
OTHER TYPES	+2V to +6V

SN74HC08NS (TI) FLAT PACKAGE

C-MOS QUAD 2-INPUT AND GATE

– TOP VIEW –





A	B	Y
0	0	0
0	1	0
1	0	0
1	1	1

0; LOW LEVEL
1; HIGH LEVEL

SN74HC161NS (TI) (V_{DD} = + 2 to + 6V) FLAT PACKAGE

C-MOS SYNCHRONOUS PRESETTABLE 4-BIT BINARY COUNTER

– TOP VIEW –





MODE SELECTION

CONTROL INPUTS				MODE
RD	LD	EN1	EN2	
0	X	X	X	RESET (ASYNCHRONOUS)
1	0	X	X	PRESET (SYNCHRONOUS)
1	1	0	X	NO COUNT
1	1	X	0	NO COUNT
1	1	1	1	COUNT

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

CARRY OUTPUT "CO"



CO IS HIGH WHEN EN2 INPUT IS HIGH AND COUNT IS "15".

COUNT SEQUENCE

COUNT	OUTPUTS			
	QD	QC	QB	QA
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
10	1	0	1	0
11	1	0	1	1
12	1	1	0	0
13	1	1	0	1
14	1	1	1	0
15	1	1	1	1

SN74HC163NS (TI) (V_{DD} = + 2 to + 6V) FLAT PACKAGE
TC74AC163F (TOSHIBA) (V_{DD} = + 2 to + 5.5V) FLAT PACKAGE

C-MOS PRESETTABLE SYNCHRONOUS 4-BIT BINARY COUNTER
– TOP VIEW –





MODE SELECTION

CONTROL INPUTS				MODE
RD	LD	EN1	EN2	
0	X	X	X	RESET (SYNCHRONOUS)
1	0	X	X	PRESET (SYNCHRONOUS)
1	1	0	X	NO COUNT
1	1	X	0	NO COUNT
1	1	1	1	COUNT

COUNT SEQUENCE

COUNT	OUTPUTS			
	QD	QC	QB	QA
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
10	1	0	1	0
11	1	0	1	1
12	1	1	0	0
13	1	1	0	1
14	1	1	1	0
15	1	1	1	1

CARRY OUTPUT "CO"



CO IS HIGH WHEN EN2 INPUT IS HIGH AND COUNT IS "15".

SN74HC164NS (TI) FLAT PACKAGE

C-MOS 8-BIT SERIAL-IN/PARALLEL-OUT SHIFT REGISTER
– TOP VIEW –





INPUTS				OUTPUTS			
RD	CK	A	B	Q1	Q2	----	Q8
0	X	X	X	0	0	0	0
1	0	X	X	Q1o	Q2o	----	Q8o
1	↑	1	1	1	Q1n	----	Q7n
1	↑	0	X	0	Q1n	----	Q7n
1	↑	X	0	0	Q1n	----	Q7n

0;LOW LEVEL
1;HIGH LEVEL
X;DON'T CARE



SN74HC174NS (TI) FLAT PACKAGE

C-MOS D-TYPE FLIP-FLOP WITH RESET
– TOP VIEW –





EACH FLIP - FLOP

INPUT				OUT
RD	CK	D		Q
0	X	X		0
1	↑	0		0
1	↑	1		1
1	0	X		Qo

0;LOW LEVEL
1;HIGH LEVEL
X;DON'T CARE



*

TYPE	VDD
74AC	+3.3 to +5V
74ACT	+5V
74HC	+2 to +6V

SN74HC175NS (TI) (V_{DD} = + 2 to + 6V) FLAT PACKAGE

C-MOS D-TYPE FLIP-FLOP WITH RESET
– TOP VIEW –





RD	CK	D	Q	$\overline{Q}$
0	X	X	0	1
1	↑	1	1	0
1	↑	0	0	1
1	0	X	Qo	$\overline{Q}$o

0 ; LOW LEVEL
1 ; HIGH LEVEL
X ; DON'T CARE
Qo ; NO CHANGE
$\overline{Q}$o ; NO CHANGE

SN74HC32NS (TI) FLAT PACKAGE

C-MOS 2-INPUT OR GATE
– TOP VIEW –





A	B	Y
0	0	0
0	1	1
1	0	1
1	1	1

0;LOW LEVEL
1;HIGH LEVEL

SN74HC374NS (TI) FLAT PACKAGE

C-MOS 3-STATE OCTAL D-TYPE FLIP-FLOP
– TOP VIEW –





INPUTS			OUT
EN	D	CK	Q
0	1	↑	1
0	0	↑	0
0	X	0	Qo
1	X	X	HI-Z

0 ; LOW LEVEL
1 ; HIGH LEVEL
X ; DON'T CARE
HI-Z ; HIGH IMPEDANCE



NOTE :

TYPE	VDD
74AC/74HC	+2 to +6V
74ACT/74HCT	+5V

SN74HC74NS (TI) FLAT PACKAGE

C-MOS D-TYPE FLIP FLOP WITH DIRECT SET/RESET
– TOP VIEW –



INPUTS				OUTPUTS	
$\overline{S_D}$	$\overline{R_D}$	CK	D	Qn+1	$\overline{Q_{n+1}}$
0	1	X	X	1	0
1	0	X	X	0	1
0	0	X	X	1	1
1	1	↑	1	1	0
1	1	↑	0	0	1
1	1	0	X	Qn	$\overline{Q_n}$

0 ; LOW LEVEL
1 ; HIGH LEVEL
X ; DON'T CARE



NOTE :

TYPE	VDD
74AC/74HC	+2 to +6V
74ACT	+5V

SN74LS624NS (TI) FLAT PACKAGE

TTL VOLTAGE CONTROLLED OSCILLATOR
– TOP VIEW –





EN	OSC	$\overline{OSC}$
0	ENABLE	ENABLE
1	0	1

0 ; LOW LEVEL
1 ; HIGH LEVEL

SSM2016P (PMI)

DIFFERENTIAL AUDIO PREAMPLIFIER
– TOP VIEW –





NULL1 – 2 ; OFFSET ADJUST INPUT
COMP1 – 4 ; COMPENSATION INPUT
RG +, RG –, SUM1 – 2 ; GAIN SETTING PIN



TC74AC153F (TOSHIBA) FLAT PACKAGE

C-MOS DUAL 4-LINE-TO-1-LINE DATA SELECTOR/MULTIPLEXER
– TOP VIEW –





TYPE	VDD
EXCEPT FOL. TYPE	+2 to +6V
74ACT153PC 74ACT153SJ	+5V
TC74AC153P	+2 to +5.5V

CONTROL IN			ON CHANNEL
INH	B	A	
0	0	0	0
0	0	1	1
0	1	0	2
0	1	1	3
1	X	X	GND

0 ; LOW LEVEL
1 ; HIGH LEVEL
X ; DON'T CARE

TC74HC4538AF (TOSHIBA) FLAT PACKAGE

C-MOS DUAL RETRIGGERABLE/NON-RETRIGGERABLE MONOSTABLE MULTIVIBRATOR
– TOP VIEW –





OUTPUT PULSE WIDTH = k·C·R



RETRIGGERABLE M.M.V



NON-RETRIGGERABLE M.M.V



TDA1535 (SIGNETICS)

HIGH-SPEED SAMPLE AND HOLD AMPLIFIER

– TOP VIEW –







TL062CPS (TI) FLAT PACKAGE

OPERATIONAL AMPLIFIER

(JFET INPUT)

– TOP VIEW –



TL1451ACN (TI)

DUAL PWM POWER CONTROLLER

– TOP VIEW –





TL431CLP (TI)

ADJUSTABLE PRECISION SHUNT REGULATOR





TLC27M2CPS (TI) FLAT PACKAGE

OPERATIONAL AMPLIFIER

– TOP VIEW –



uPC311G2 (NEC) FLAT PACKAGE

VOLTAGE COMPARATOR

– TOP VIEW –



uPC319G2 (NEC) FLAT PACKAGE

DUAL VOLTAGE COMPARATOR

– TOP VIEW –



uPC339C (NEC)

COMPARATOR

– TOP VIEW –



TL7705ACPS (TI) FLAT PACKAGE

POWER VOLTAGE SUPERVISOR

– TOP VIEW –







SECTION C
SCHEMATIC DIAGRAMS AND BOARD ILLUSTRATIONS

BOARD LAYOUT



ORX-11 BOARD

Ser No.10001-10100

ORX-11 (1-635-698-11)

CN1	F-2
D1	F-4
D2	F-4
D3	E-4
D101	B-3
D201	F-4
D301	B-5
D401	B-2
E1	F-5
E101	F-1
E201	F-2
E301	F-2
E401	F-1
IC1	E-4
Q1	F-5
Q2	E-5
Q101	C-2
Q102	C-3
Q103	C-2
Q104	C-2
Q105	D-2
Q201	C-4
Q202	C-4
Q203	C-4
Q204	C-4
Q205	D-3
Q301	C-5
Q302	C-5
Q303	C-5
Q304	C-5
Q305	D-5
Q401	C-1
Q402	C-2
Q403	C-1
Q404	C-1
Q405	D-1
RV1	F-4
RV101	C-2
RV102	D-2
RV103	C-3
RV201	C-3
RV202	D-4
RV203	C-4
RV301	C-4
RV302	D-5
RV303	C-5
RV401	C-1
RV402	D-1
RV403	C-2
TP1	E-5
TP2	E-5
TP3	E-3
TP101	E-1
TP201	E-2
TP301	E-2
TP401	E-1



1-635-698-11 COMPONENT SIDE



1-635-698-11 SOLDERING SIDE

C-3 (a)

C-4 (a)

HDFR-300

ORX-11 BOARD

Ser No.10101-

ORX-11 (1-635-698-12)

CN1	F-2
D1	F-4
D2	F-4
D3	E-4
D101	B-3
D201	B-4
D301	B-5
D401	B-1
E1	F-5
E101	F-1
E201	F-2
E301	F-2
E401	F-1
IC1	E-4
Q1	F-5
Q2	E-5
Q101	C-2
Q102	C-3
Q103	C-2
Q104	C-2
Q105	D-2
Q201	C-4
Q202	C-4
Q203	C-4
Q204	C-4
Q205	D-3
Q301	C-5
Q302	C-5
Q303	C-5
Q304	C-5
Q305	D-5
Q401	C-1
Q402	C-2
Q403	C-1
Q404	C-1
Q405	D-1
RV1	F-4
RV101	C-2
RV102	D-2
RV103	C-3
RV201	C-3
RV202	D-4
RV203	C-4
RV301	C-4
RV302	D-5
RV303	C-5
RV401	C-1
RV402	D-1
RV403	C-2
TP1	E-5
TP2	E-5
TP3	E-3
TP101	E-1
TP201	E-2
TP301	E-2
TP401	E-1



1-635-698-12 COMPONENT SIDE

1-635-698-12 SOLDERING SIDE



1-635-698-12 COMPONENT SIDE

1-635-698-12 SOLDERING SIDE

C-3 (b)

C-4 (b)

ORX-11 BOARD
OPTICAL RECEIVER



ORX-11 BOARD
HDFR-300

VA-99 BOARD Ser No.10001-10199

VA-99 (1-635-703-11)

CN1	A-5	IC306	H-1	Q309	C-2
		IC307	G-2	Q310	C-2
D1	I-7	IC401	B-6	Q311	C-2
D2	I-7	IC402	C-6	Q312	C-2
D3	J-6	IC403	E-6	Q313	D-1
D4	G-7	IC501	B-7	Q314	E-1
D5	G-7	IC502	C-7	Q315	H-1
D6	D-6	IC503	E-7	Q316	F-2
D101	B-4			Q317	F-2
D102	B-5	PH101	B-4	Q318	F-2
D103	D-4	PH102	B-4	Q319	K-6
D104	F-5	PH201	B-2	Q401	B-6
D105	G-5	PH202	B-2	Q402	B-6
D106	K-5	PH301	B-1	Q403	C-6
D201	B-3	PH302	B-1	Q404	K-4
D202	B-3			Q501	B-7
D203	D-3	Q1	J-7	Q502	B-7
D204	F-3	Q2	I-7	Q503	C-7
D205	G-4	Q3	H-7	Q504	K-3
D206	K-6	Q4	G-7		
D301	B-1	Q101	B-5	RV1	J-6
D302	B-2	Q102	B-4	RV2	H-6
D303	D-1	Q103	B-4	RV101	D-5
D304	F-2	Q104	B-5	RV102	F-4
D305	G-2	Q105	C-4	RV103	C-4
D306	K-6	Q106	D-4	RV104	E-4
D401	C-6	Q107	C-4	RV201	D-4
D402	K-4	Q108	D-4	RV202	F-2
D501	C-7	Q109	C-5	RV203	C-3
D502	K-3	Q110	C-5	RV204	E-3
		Q111	C-5	RV301	D-2
E1	H-6	Q112	C-5	RV302	F-1
E2	F-5	Q113	D-4	RV303	C-1
E101	A-5	Q114	E-4	RV304	E-1
E102	F-5	Q115	H-4		
E103	F-5	Q116	F-5	TP1	H-6
E201	A-3	Q117	F-5	TP2	H-6
E202	F-3	Q118	F-5	TP3	G-6
E203	F-3	Q119	K-5	TP4	F-6
E301	A-2	Q201	B-3	TP101	B-4
E302	F-2	Q202	B-3	TP102	C-4
E303	F-2	Q203	B-3	TP103	D-4
E401	D-6	Q204	B-3	TP104	G-4
E501	D-7	Q205	C-3	TP105	F-5
		Q206	D-2	TP106	G-5
IC1	I-6	Q207	C-3	TP201	B-2
IC2	G-6	Q208	D-3	TP202	C-2
IC101	D-4	Q209	C-3	TP203	D-2
IC102	D-4	Q210	C-3	TP204	G-3
IC103	E-4	Q211	C-3	TP205	F-3
IC104	I-4	Q212	C-3	TP206	G-3
IC105	F-4	Q213	D-3	TP301	B-1
IC106	H-4	Q214	E-3	TP302	C-1
IC107	G-5	Q215	H-3	TP303	D-1
IC201	D-3	Q216	F-3	TP304	G-1
IC202	D-3	Q217	F-3	TP305	F-2
IC203	E-3	Q218	F-3	TP306	G-2
IC204	I-3	Q219	K-5	TP401	B-5
IC205	F-3	Q301	B-2	TP402	D-5
IC206	H-2	Q302	B-1	TP501	B-7
IC207	G-4	Q303	B-1	TP502	D-7
IC301	D-1	Q304	B-2		
IC302	D-1	Q305	C-1		
IC303	E-2	Q306	D-1		
IC304	I-1	Q307	C-1		
IC305	F-1	Q308	D-1		



1-635-703-11 COMPONENT SIDE



1-635-703-11 SOLDERING SIDE

VA-99 VA-99

VA-99 BOARD

Ser No.10201-

VA-99 (1-635-703-12)

CN1	A-5	IC306	H-1	Q309	C-2
		IC307	G-2	Q310	C-2
D1	I-7	IC401	B-6	Q311	C-2
D2	I-7	IC402	C-6	Q312	C-2
D3	J-6	IC403	E-6	Q313	D-1
D4	G-7	IC501	B-7	Q314	E-1
D5	G-7	IC502	C-7	Q315	H-1
D6	G-6	IC503	E-7	Q316	F-2
D101	B-4			Q317	F-2
D102	B-5	PH101	B-4	Q318	F-2
D103	D-4	PH102	B-4	Q319	K-6
D104	F-5	PH201	B-2	Q401	B-6
D105	G-5	PH202	B-2	Q402	B-6
D106	K-5	PH301	B-1	Q403	C-6
D201	B-3	PH302	B-1	Q404	K-4
D202	B-3			Q501	B-7
D203	D-3	Q1	J-7	Q502	B-7
D204	F-3	Q2	I-7	Q503	C-7
D205	G-4	Q3	H-7	Q504	K-3
D206	K-6	Q4	G-7		
D301	B-1	Q101	B-5	RV1	J-6
D302	B-2	Q102	B-4	RV2	H-6
D303	D-1	Q103	B-4	RV101	D-5
D304	F-2	Q104	B-5	RV102	F-4
D305	G-2	Q105	C-4	RV103	C-4
D306	K-6	Q106	D-4	RV104	E-4
D401	C-6	Q107	C-4	RV201	D-4
D402	K-4	Q108	D-4	RV202	F-2
D501	C-7	Q109	C-5	RV203	C-3
D502	K-3	Q110	C-5	RV204	E-3
		Q111	C-5	RV301	D-2
E1	H-6	Q112	C-5	RV302	F-1
E2	F-5	Q113	D-4	RV303	C-1
E101	A-5	Q114	E-4	RV304	E-1
E102	F-5	Q115	H-4		
E103	F-5	Q116	F-5	TP1	H-6
E201	A-3	Q117	F-5	TP2	H-6
E202	F-3	Q118	F-5	TP3	G-6
E203	F-3	Q119	K-5	TP4	F-6
E301	A-2	Q201	B-3	TP101	B-4
E302	F-2	Q202	B-3	TP102	C-4
E303	F-2	Q203	B-3	TP103	D-4
E401	D-6	Q204	B-3	TP104	G-4
E501	D-7	Q205	C-3	TP105	F-5
		Q206	D-2	TP106	G-5
IC1	I-6	Q207	C-3	TP201	B-2
IC2	G-6	Q208	D-3	TP202	C-2
IC101	D-4	Q209	C-3	TP203	D-2
IC102	D-4	Q210	C-3	TP204	G-3
IC103	E-4	Q211	C-3	TP205	F-3
IC104	I-4	Q212	C-3	TP206	G-3
IC105	F-4	Q213	D-3	TP301	B-1
IC106	H-4	Q214	E-3	TP302	C-1
IC107	G-5	Q215	H-3	TP303	D-1
IC201	D-3	Q216	F-3	TP304	G-1
IC202	D-3	Q217	F-3	TP305	F-2
IC203	E-3	Q218	F-3	TP306	G-2
IC204	I-3	Q219	K-5	TP401	B-5
IC205	F-3	Q301	B-2	TP402	D-5
IC206	H-2	Q302	B-1	TP501	B-7
IC207	G-4	Q303	B-1	TP502	D-7
IC301	D-1	Q304	B-2		
IC302	D-1	Q305	C-1		
IC303	E-2	Q306	D-1		
IC304	I-1	Q307	C-1		
IC305	F-1	Q308	D-1		



1-635-703-12 COMPONENT SIDE

1-635-703-12 SOLDERING SIDE



1-635-703-12 COMPONENT SIDE

1-635-703-12 SOLDERING SIDE

C-8 (b)

C-9 (b)

C-10 (b)

HDFR-300

VA-99 BOARD
VIDEO LEVEL CONTROL
SYNC, VF AMPLIFIER



VA-99 BOARD
HDFR-300

*NOTE

MARK	ADDRESS	CHANGE INFORMATION	SERIAL NO
*1	G-1	C150 33P ADD	10101-
		R177 1.5K ADD	
	G-2	C250 33P ADD	
		R277 1.5K ADD	
	G-3	C350 33P ADD	
		R377 1.5K ADD	
*2	H-5	C520 10/16V ADD	10201-
	C-1	C103 DELETE	
	C-2	C203 DELETE	
	C-3	C303 DELETE	

AU-135 AU-135

AU-135 BOARD

Ser No.10001-10199

AU-135 (1-635-699-11)

CN1	A-5	IC9	C-2	RV3	A-2
		IC10	E-2	RV4	A-5
CP1	C-3	IC11	C-5	RV101	H-8
CP2	D-3	IC12	E-5	RV102	F-6
CP101	F-7	IC13	D-3	RV201	G-9
CP201	F-8	IC14	D-3	RV202	F-9
		IC15	D-2		
DL1	B-1	IC16	H-4	S1	H-5
		IC17	D-5	S2	H-4
D1	A-7	IC18	D-4		
D2	A-8	IC19	E-4	TP1	B-7
D3	B-7	IC20	E-5	TP2	B-8
D4	A-8	IC21	G-6	TP3	B-8
D5	A-9	IC22	E-3		
D6	A-2	IC23	G-5		
D7	A-1	IC24	H-5		
D8	E-5	IC25	H-4		
D9	B-3	IC26	G-4		
D10	B-3	IC27	H-5		
D11	B-4	IC28	G-6		
D12	C-4	IC29	F-1		
D13	B-4	IC30	C-4		
D14	B-4	IC31	F-8		
D15	B-4	IC32	F-3		
D16	B-4	IC40	C-5		
D17	H-6	IC101	H-7		
D18	H-6	IC102	F-7		
D19	H-8	IC103	E-7		
D20	H-7	IC104	E-7		
D21	H-7	IC105	D-7		
D22	H-7	IC201	H-8		
D23	H-3	IC202	F-9		
D24	A-3	IC203	E-9		
D25	G-3	IC204	E-9		
D26	B-5	IC205	D-9		
D27	B-5				
D28	B-5	PH101	B-6		
D29	B-5	PH102	B-7		
D101	E-6	PH103	B-6		
D102	D-6	PH104	B-7		
D103	E-7	PH201	B-8		
D104	D-7	PH202	B-9		
D105	B-6	PH203	B-8		
D106	A-6	PH204	B-9		
D107	B-6				
D108	B-6	Q1	A-7		
D201	E-8	Q2	A-8		
D202	D-8	Q3	A-8		
D203	E-9	Q4	A-9		
D204	D-9	Q5	A-3		
D205	B-7	Q6	A-1		
D206	B-7	Q7	B-5		
D207	B-7	Q8	B-6		
D208	A-7	Q9	F-7		
		Q11	B-5		
E1	A-9	Q101	E-6		
E2	F-1	Q102	D-6		
		Q103	E-7		
IC1	A-8	Q104	D-4		
IC2	A-9	Q201	E-8		
IC3	A-2	Q202	D-8		
IC4	A-4	Q203	E-9		
IC5	A-4	Q204	D-9		
IC6	B-2				
IC7	C-1	RV1	A-7		
IC8	C-3	RV2	B-9		



1-635-699-11 COMPONENT SIDE



1-635-699-11 SOLDERING SIDE

AU-135

AU-135 BOARD

Ser No.10201-

AU-135 (1-635-699-12)

CN1	A-5	IC9	C-2	RV1	A-7
		IC10	E-2	RV2	B-9
CP1	C-3	IC11	C-5	RV3	A-2
CP2	D-3	IC12	E-5	RV4	A-5
CP101	F-7	IC13	D-3	RV101	H-8
CP201	F-8	IC14	D-3	RV102	F-6
		IC15	D-2	RV201	G-9
DL1	B-1	IC16	H-4	RV202	F-9
		IC17	D-5		
D1	A-7	IC18	D-4	S1	H-5
D2	A-8	IC19	E-4	S2	H-4
D3	B-7	IC20	E-5		
D4	A-8	IC21	G-6	TP1	B-7
D5	A-9	IC22	E-3	TP2	B-8
D6	A-2	IC23	G-5	TP3	B-8
D7	A-1	IC24	H-5	TP4	B-9
D8	E-5	IC25	H-4	TP5	A-3
D9	B-3	IC26	G-4	TP6	B-1
D10	B-3	IC27	H-5	TP7	B-2
D11	B-4	IC28	G-6	TP8	B-2
D12	C-4	IC29	F-1	TP9	B-2
D13	B-4	IC30	C-4	TP11	C-3
D14	B-4	IC31	F-8	TP12	E-5
D15	B-4	IC32	F-3	TP15	E-3
D16	B-4	IC33	E-1	TP16	E-4
D17	H-6	IC40	C-5	TP17	D-3
D18	H-6	IC101	H-7	TP18	H-3
D19	H-8	IC102	F-7	TP19	F-5
D20	H-7	IC103	E-7	TP20	C-4
D21	H-7	IC104	E-7	TP21	C-5
D22	H-7	IC105	D-7	TP22	C-5
D23	H-3	IC201	H-8	TP23	C-3
D24	A-3	IC202	F-9	TP24	F-3
D25	G-3	IC203	E-9	TP25	H-6
D26	B-5	IC204	E-9	TP26	H-5
D27	B-5	IC205	D-9	TP101	F-7
D28	B-5			TP103	A-6
D29	B-5	PH101	B-6	TP104	A-6
D101	E-6	PH102	B-7	TP201	F-9
D102	D-6	PH103	B-6	TP203	A-6
D103	E-7	PH104	B-7	TP204	A-6
D104	D-7	PH201	B-8		
D105	B-6	PH202	B-9		
D106	A-6	PH203	B-8		
D107	B-6	PH204	B-9		
D108	B-6				
D201	E-8	Q1	A-7		
D202	D-8	Q2	A-8		
D203	E-9	Q3	A-9		
D204	D-9	Q4	A-9		
D205	B-7	Q5	A-3		
D206	B-7	Q6	A-1		
D207	B-7	Q7	B-5		
D208	A-7	Q8	B-6		
		Q9	F-7		
E1	A-9	Q10	A-5		
E2	F-1	Q11	B-5		
		Q101	E-6		
IC1	A-8	Q102	D-6		
IC2	A-9	Q103	E-7		
IC3	A-2	Q104	D-7		
IC4	A-4	Q201	E-8		
IC5	A-4	Q202	D-8		
IC6	B-2	Q203	E-9		
IC7	C-1	Q204	D-9		
IC8	C-3				



1-635-699-12 COMPONENT SIDE

1-635-699-12 SOLDERING SIDE



1-635-699-12 COMPONENT SIDE

1-635-699-12 SOLDERING SIDE

AU-135 AU-135

AU-135 BOARD

AUDIO D/A CONVERTER
DIGITAL AUDIO DECODER



★NOTE			
MARK	ADDRESS	CHANGE INFORMATION	SERIAL NO
★1	D-1	IC7 EPM5032DC-AU2 → EPM5032DC-AU22	10101-
★2	D-4	C77, C79 0.22 DELETE	10201-
	F-2	C99 0.1 ADD IC33 TL7705ACPS ADD R32 1M → 10K	

AU-135 BOARD
HDFR-300

OTX-11 BOARD Ser No.10001-10100

OTX-11 (1-635-697-11)

CN1	I-3
D1	I-3
D2	H-3
D3	I-2
D101	C-4
D102	D-3
D103	D-3
D104	D-3
D105	D-4
D106	E-4
D201	C-2
D202	D-2
D203	D-2
D204	D-2
D205	D-2
D206	E-2
E1	I-4
E101	D-4
E201	H-1
IC1	H-2
IC101	F-4
IC201	F-2
Q1	H-3
Q2	H-3
Q101	F-3
Q102	F-3
Q201	F-1
Q202	F-1
RV1	H-2
RV101	E-4
RV102	E-4
RV201	E-2
RV202	E-2
TH101	E-3
TH201	E-1
TP1	H-4
TP2	H-4
TP101	G-4
TP102	C-4
TP201	G-1
TP202	F-1



1-635-697-11 COMPONENT SIDE



1-635-697-11 SOLDERING SIDE

OTX-11 BOARD Ser No.10101-

OTX-11 (1-635-697-12)

CN1	I-3
D1	I-3
D2	H-3
D3	I-2
D101	C-4
D102	D-4
D103	D-3
D104	D-3
D105	D-4
D106	E-4
D201	C-2
D202	D-2
D203	D-2
D204	D-2
D205	D-2
D206	E-2
E1	I-4
E101	D-4
E201	H-1
IC1	H-2
IC101	F-4
IC201	F-2
Q1	H-3
Q2	H-3
Q101	F-3
Q102	F-3
Q201	F-1
Q202	F-1
RV1	H-2
RV101	E-4
RV102	E-4
RV201	E-2
RV202	E-2
TH101	E-3
TH201	E-1
TP1	H-4
TP2	H-4
TP101	G-4
TP102	C-4
TP201	G-1
TP202	F-1



1-635-697-12 COMPONENT SIDE



1-635-697-12 SOLDERING SIDE

OTX-11

OTX-11 BOARD
OPTICAL TRANSMITTER



OTX-11 BOARD
HDFR-300

CT-129 CT-130 PS-227 PS-227 CT-129 CT-130

PS-227 BOARD

Ser No.10001-10199

PS-227 (1-635-707-11)

CN101	A-1	Q205	E-2
CN102	A-1	Q206	D-2
CN103	A-1	Q207	D-3
CN201	F-1	Q208	E-3
CN202	F-2	Q209	E-3
CN203	F-2	Q210	E-1
CN204	F-2	Q212	F-2
CN205	F-2	Q213	F-2
CN207	D-1	Q214	F-2
		Q215	F-2
CT129	D-2	Q216	F-2
CT130	D-3	Q217	F-3
		Q218	F-3
D101	A-1	Q219	E-3
D102	C-2	Q220	E-2
D103	C-3	Q221	F-2
D201	C-1	Q222	E-3
D202	C-1	Q223	F-3
D203	C-1	Q224	E-3
D204	C-1	Q225	E-3
D205	D-1	Q226	F-3
D206	E-1		
D207	F-1	S201	E-2
D208	F-1	S202	E-3
D209	F-2		
D210	F-1	TP21	D-3
D214	F-3	TP22	E-3
D215	E-2	TP23	E-2
D216	F-2	TP24	D-2
D217	D-2	TP25	D-1
D218	D-3		
D219	D-3	T101	C-1
D220	D-3	T102	C-2
D221	F-2	T103	C-2
D222	F-2	T104	C-3
D223	D-1	T201	D-1
D224	D-1		
D225	D-2	VZ101	A-1
D226	D-2		
D227	F-3		
D228	F-3		
D229	F-2		
D230	F-3		
D232	F-3		
D233	F-3		
D234	F-3		
E1	F-3		
E2	E-1		
E3	E-3		
F101	A-1		
IC201	E-2		
IC202	E-1		
PS201	D-1		
Q101	C-2		
Q102	C-3		
Q103	C-2		
Q104	C-3		
Q201	F-2		
Q202	E-1		
Q203	E-1		
Q204	E-2		



1-635-707-11 COMPONENT SIDE

1-635-707-11 SOLDERING SIDE

CT-129 BOARD

Ser No.10001-10199

CT-129 (1-635-709-11)

CN51	A-2
D51	B-2
D52	B-2
D53	B-2
D54	B-2
D55	B-1
D56	B-1
D57	A-1
D58	A-2
D59	A-2
E51	A-1
IC51	B-1
Q53	A-2
TP51	B-1
TP52	A-2
TP53	B-2



1-635-709-11 COMPONENT SIDE

1-635-709-11 SOLDERING SIDE

CT-130 BOARD

Ser No.10001-10199

CT-130 (1-635-710-11)

CN301	A-2
D301	B-1
D302	A-2
D303	A-2
D304	A-2
D305	B-2
D306	A-1
D307	A-1
D308	B-1
D309	B-2
E301	B-2
IC301	A-1
IC302	A-2
IC303	A-2
IC304	A-1
IC305	B-1
Q301	B-1
Q302	B-2
Q303	B-2
TP301	B-2
TP302	B-1
TP303	A-1
TP304	A-1



1-635-710-11 COMPONENT SIDE

1-635-710-11 SOLDERING SIDE

PS-227 BOARD

Ser No.10201-

PS-227 (1-635-707-12)

CN101	A-1	Q203	E-1
CN102	A-1	Q204	E-2
CN103	A-1	Q205	E-2
CN201	F-1	Q206	D-2
CN202	F-2	Q207	D-3
CN203	F-2	Q208	E-3
CN204	F-2	Q209	E-3
CN205	F-2	Q210	E-1
CN207	D-1	Q212	F-2
		Q213	F-2
CT129	D-3	Q214	F-2
CT130	D-2	Q215	F-2
		Q216	F-2
D101	A-1	Q217	F-3
D102	C-2	Q218	F-3
D103	C-3	Q219	E-3
D201	C-1	Q220	E-2
D202	C-1	Q221	F-2
D203	C-1	Q222	E-3
D204	C-1	Q223	F-3
D205	D-1	Q224	E-3
D206	E-1	Q225	E-3
D207	F-1	Q226	F-3
D208	F-1		
D209	F-2	S201	E-2
D210	F-1	S202	E-3
D214	F-2		
D215	E-2	TP21	D-3
D216	F-2	TP22	E-3
D217	D-2	TP23	E-2
D218	D-3	TP24	D-2
D219	D-3	TP25	D-1
D220	D-3		
D221	F-2	T101	C-1
D222	F-2	T102	C-2
D223	D-1	T103	C-2
D224	D-1	T104	C-3
D225	D-2	T201	D-1
D226	D-2		
D227	F-3	VZ101	A-1
D228	F-3		
D229	F-2		
D230	F-3		
D232	F-3		
D233	F-3		
D234	F-3		
D235	F-3		
E1	F-3		
E2	E-1		
E3	E-3		
F101	A-1		
F102	A-1		
IC201	E-2		
IC202	E-1		
PS201	D-1		
Q101	C-2		
Q102	C-3		
Q103	C-2		
Q104	C-3		
Q201	F-2		
Q202	E-1		



1-635-707-12 COMPONENT SIDE

1-635-707-12 SOLDERING SIDE

CT-129 BOARD

Ser No.10201-

CT-129 (1-635-709-12)

CN51	A-2
D51	B-2
D52	B-2
D53	B-2
D54	B-2
D55	B-1
D56	B-1
D57	A-1
D58	A-2
D59	A-2
E51	A-1
IC51	B-1
Q53	A-2
TP51	B-1
TP52	A-2
TP53	B-2



1-635-709-12 COMPONENT SIDE

1-635-709-12 SOLDERING SIDE

CT-130 BOARD

Ser No.10201-

CT-130 (1-635-710-12)

CN301	A-2
D301	A-1
D302	A-2
D303	A-2
D304	A-2
D305	B-2
D306	A-1
D307	A-1
D308	B-1
D309	B-2
E301	B-2
IC301	A-1
IC302	A-2
IC303	A-2
IC304	A-1
IC305	B-1
Q301	B-1
Q302	B-2
Q303	B-2
TP301	B-2
TP302	B-1
TP303	A-1
TP304	A-1



1-635-710-12 COMPONENT SIDE

1-635-710-12 SOLDERING SIDE

PS-227 BOARD

SWITCHING REGULATOR 1 (HIGH VOLTAGE)



*NOTE :PS-227BOARD

MARK	ADDRESS	CHANGE INFORMATION	SERIAL.NO
*1	J-1	Q208 RB35ESB1 → RG01E-B	10101-
	J-2	C226 3.3/50V → 3.3/35V R215 47K → 27K R216 10K → 120K	
*2	B-3	F102 A00	10201-
	Q-1	R205 4.7K → 22K R206 750 → 3.3K	
*3	J-3	Q216 GL-SPG5 → GL5KG8T	10401-
	J-4	Q227 GL-SPR5 → GL5PR8T	

PS-228 PS-228

PS-228 BOARD

Ser No.10001-10199

PS-228 (1-635-708-11)

CN101 A-3
CN201 E-2
CN202 E-3

D101 A-2
D102 B-2
D103 B-3
D104 B-1
D105 A-2
D106 B-1
D107 B-1
D201 B-1
D202 C-1
D203 C-1
D204 C-1
D205 C-2
D206 C-2
D207 C-2
D208 C-1
D209 D-1
D210 D-1
D211 E-1
D212 C-3
D213 E-3
D214 E-3
D215 C-3
D216 C-1
D217 D-3

E1 E-2

F101 A-3

IC101 B-2
IC201 E-1
IC202 E-2
IC203 C-3
IC204 D-3

PS201 C-1

Q101 B-3
Q102 B-3
Q201 E-1
Q202 E-2
Q203 E-2
Q204 E-3
Q205 E-3
Q206 E-3
Q207 D-3

RV201 D-2
RV202 E-1
RV203 E-2

TP1 E-1
TP2 E-2
TP3 E-3

T101 B-1
T102 C-3
T103 B-2
T104 B-1



1-635-708-11 COMPONENT SIDE

1-635-708-11 SOLDERING SIDE

PS-228 BOARD

Ser No.10201-

PS-228 (1-635-708-12)

CN101	A-3
CN201	E-2
CN202	E-3
D101	A-2
D102	B-2
D103	B-3
D104	B-1
D105	A-2
D106	B-1
D107	B-1
D201	B-1
D202	C-1
D203	C-1
D204	C-1
D205	C-2
D206	C-2
D207	C-2
D208	C-1
D209	D-1
D210	D-1
D211	E-1
D212	C-2
D213	E-3
D214	E-3
D215	C-3
D216	C-1
D217	D-3
E1	E-2
F101	A-3
IC101	B-2
IC201	E-1
IC202	E-2
IC203	C-3
IC204	D-3
PS201	C-1
Q101	B-3
Q102	B-3
Q201	E-1
Q202	E-2
Q203	E-2
Q204	E-3
Q205	E-3
Q206	E-3
Q207	D-3
RV201	D-2
RV202	E-1
RV203	E-2
TP1	E-1
TP2	E-2
TP3	E-3
T101	B-1
T102	C-3
T103	B-2
T104	B-1



1-635-708-12 COMPONENT SIDE

1-635-708-12 SOLDERING SIDE

PS-228 BOARD
SWITCHING REGULATOR 2



PS-228 BOARD
HDFR-300

MB-294 LF-22
DP-118 DP-152 **FRAME** **FRAME** MB-294 LF-22
DP-118 DP-152

MB-294 BOARD

Ser No.10001-10199

MB-294 (1-635-700-11)

CN1	D-2
CN2	D-1
CN3	C-2
CN4	E-2
CN5	F-3
CN6	B-1
CN7	F-1
CN101	C-3
CN201	B-3
CN301	B-3
CN401	D-3
CN501	D-3



1-635-700-11 COMPONENT SIDE
1-635-700-11 SOLDERING SIDE

DP-118 BOARD



1-635-701-11 COMPONENT SIDE
1-635-701-11 SOLDERING SIDE



LF-22 BOARD

LF-22 (1-635-704-12)

CN601	A-2
CN602	A-2
CN603	B-1
CN604	B-2
CN605	B-2
F601	B-2
D601	B-2
RY601	B-2



1-635-704-12 SOLDERING SIDE

DP-152 BOARD



1-636-217-11 COMPONENT SIDE
1-636-217-11 SOLDERING SIDE



C-39 (a)
C-40 (a)
HDFR-300

C-38 (P)



LE-55 BOARD

C-40 (P)

DB-125 BOARD

MB-584 BOARD

DB-118 BOARD

FRAME

FRAME

MB-294 LF-22
DP-118 DP-152 **FRAME** **FRAME** MB-294 LF-22
DP-118 DP-152

MB-294 BOARD

Ser No.10201-

MB-294 (1-635-700-12)

CN1	D-2
CN2	D-1
CN3	C-2
CN4	E-2
CN5	F-3
CN6	B-1
CN7	F-1
CN101	C-3
CN201	B-3
CN301	B-3
CN401	D-3
CN501	D-3



1-635-700-12 COMPONENT SIDE

1-635-700-12 SOLDERING SIDE

DP-118 BOARD



1-635-701-11 COMPONENT SIDE

1-635-701-11 SOLDERING SIDE



LF-22 BOARD

LF-22 (1-635-704-12)

CN601	A-2
CN602	A-2
CN603	B-1
CN604	B-2
CN605	B-2
F601	B-2
D601	B-2
RY601	B-2



1-635-704-12 SOLDERING SIDE

DP-152 BOARD



1-636-217-11 COMPONENT SIDE

1-636-217-11 SOLDERING SIDE



HDFR-300

C-39 (b)

C-40 (b)

FRAME WIRING
HDFR-300

FRAME MB-294 LF-22
DP-118 DP-152

MB-294 LF-22
DP-118 DP-152 **FRAME**

FRAME
MB-294 BOARD
LF-22 BOARD
DP-118 BOARD
DP-152 BOARD



SECTION D
SPARE PARTS

PARTS INFORMATION

1. **Safety Related Component Warning**

   Components indentified by shading marked with ⚠ on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony parts whose parts numbers appear as shown in this manual or in service manual supplements published by Sony.

2. Replace Parts that are supplied from Sony Parts Center can sometimes have different shape and external appearance than what are actually used in equipment. This is due to **"accommodating the improved parts and/or engineering changes" or "standardization of genuine parts."**

   · This manual 's exploded view and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present."

   · Regarding engineering parts and diagrams changes in our engineering department, refer to Sony service bulletins and service manual supplements.

3. The parts marked with "S" in the SP column of the exploded views and electrical spare parts list are normally required for routine service work. Orders for parts marked with "O" will be processed, but allow for additional delivery time.

4. Item with no parts number and/or no description are not stocked because they are seldom required for routine service.

5. Regarding engineering parts changes in our engineering department, refer to SECTION E "CHANGED PARTS".

6. Abbreviation

REF.NO.	DESCRIPTION	REF.NO.	DESCRIPTION	REF.NO.	DESCRIPTION
BT	BATTERY	F	FUSE	RB, RP	RESISTOR BLOCK
BZ	BUZZER	FB	FERRITE BEAD	RY	RELAY
C	CAPACITOR	FL	FILTER	RV	VARIABLE RESISTOR
CF	CERAMIC FILTER	IC	IC	S	SWITCH
CN	CONNECTOR	L	INDUCTOR	T	TRANSFORMER
CP	COMBINATION PARTS	LV	VARIABLE INDUCTOR	TH	THERMISTOR
CV	VARIABLE CAPACITOR	PL	PILOT LAMP	TM	TIMER
D	DIODE	Q	TRANSISTOR	VDR	VARISTOR
DL	DELAY LINE	R	RESISTOR	X	OSCILLATOR

All capacitors are in micro farads unless otherwise specified.
All inductors are in micro henries unless otherwise specified.
All resistors are in ohms.

EXPLODED VIEW

PC BOARD

No.	Part No.	SP	Description
1	A-7515-183-A	o	MOUNTED CIRCUIT BOARD, AU-135
2	A-7515-184-A	o	MOUNTED CIRCUIT BOARD, VA-99
3	A-7515-185-A	o	MOUNTED CIRCUIT BOARD, MB-294
4	A-7515-186-A	o	MOUNTED CIRCUIT BOARD, OTX-11
5	A-7515-187-A	o	MOUNTED CIRCUIT BOARD, ORX-11
6	A-7570-046-A	s	TABLE ASSY, LOCK
7	A-7615-184-A	s	PD ASSY
8	A-7615-263-A	s	LED ASSY
9	3-500-131-00	s	SPRING, COMPRESSION
10	3-673-676-21	o	RAIL, PC BOARD GUIDE

PC BOARD	PC BOARD

PC BOARD



POWER UNIT


+PWH 3x5
+K 3x6
+PWH 3x5
105
104
106
+PWH 3x5
+PWH
+PWH 3x5
+K 3x6
+B 3x6
127
+BVTT 3x5
124
+B 3x35
+BVTT 3x8
135
+BVTT 3x5
+B 3x35
128
+BVTT 3x8
109
+B 3x5
+BVTT 3x8
119
+BVTT 3x5
+BVTT 3x5
118
110
115
116
125
114
+BVTT 3x8
111
129
117
112
121
+B 3x6
+B 3x6
+BVTT 3x5
102
103
123
122
134
132
110
+B 3x5
113
+B 3x16
+BVTT 3x5
+BVTT 3x5
+BVTT 3x5
+RK 3x6
101
+PWH 3x5
+PWH 3x5
+BVTT 3x5
+PTP 3x5
+BVTT 3x5
122
+PWH 3x5
120
126
131
+PWH 3x5
+BVTT 3x5
+PWH 3x5
107
130
133
108
+K 2.6x4

POWER UNIT

No.	Part No.	SP	Description
101	A-7515-182-A	o	MOUNTED CIRCUIT BOARD, LF-22
102	A-7570-047-A	o	FRONT ASSY
103	A-7570-048-A	s	HANDLE ASSY, SWITCHING
104	A-7570-049-A	o	POWER UNIT
105	A-7584-071-A	o	POWER ASSY, A
106	A-7584-072-A	o	POWER ASSY, B
107	3-174-488-01	s	STAY
108	X-3166-510-1	s	BRACKET ASSY, STAY
109	1-541-611-21	s	FAN, DC
110	1-552-060-21	s	SWITCH, SEESAW "AC POWER"
111	1-580-375-11	s	INLET 3P
112	1-576-037-11	s	BREAKER, CIRCUIT
113	1-635-701-11	s	PRINTED CIRCUIT BOARD, DP-118
114	1-636-217-11	o	PRINTED CIRCUIT BOARD, DP-152
115	1-946-222-11	o	HARNESS (FAN)
116	2-112-820-01	o	BRACKET, HEAT SINK
117	2-146-518-01	s	WIRE (2U), HINGE
118	2-146-530-21	s	HINGE (2U), FRONT
119	2-990-241-01	o	HOLDER (A), PLUG
120	3-166-836-01	o	PLATE, ORNAMENTAL, PSW
121	3-166-837-01	o	PLATE, BREAKER
122	3-166-838-01	o	RETAINER
123	3-166-839-01	o	HANDLE, DRAWER
124	3-166-841-01	o	PANEL, VOLTAGE SELECTOR
125	3-625-620-01	s	BRACKET, AC CONNECTOR
126	3-651-850-03	s	GUARD, P SWITCH
127	3-673-676-41	o	RAIL, GUIDE, PC BOARD
128	3-675-898-03	o	PLATE, VENTILATION
129	4-601-466-11	s	COVER, 3P INLET
130	4-937-120-01	o	STOPPER, FILTER
131	4-937-143-01	s	FILTER (2U)
132	4-937-144-01	o	NET (2U), FRONT
133	4-937-156-11	o	GRILLE (2U), FRONT
134	4-937-157-01	o	RETAINER (2U), GRILLE
135	3-654-058-11	o	SPACER (3X2)

REAR PANEL

No.	Part No.	SP	Description
201	A-7602-076-A	s	CONNECTOR, 8P FEMALE "OPT"
202	X-3316-715-1	s	FOOT ASSY
203	1-509-176-41	s	CONNECTOR, 3P MALE "DIGITAL AUDIO OUT"
204	1-509-176-51	s	CONNECTOR, 3P MALE "ANALOG AUDIO OUT"
205	1-563-223-11	s	CAP, DUST
206	1-946-217-11	o	HARNESS "CCU"
207	2-146-588-01	o	PANEL, REAR
208	4-879-919-00	o	ANGLE, GUARD

REAR PANEL REAR PANEL

REAR PANEL



SCREWS

PRECISION +P Cr-N

7-627-□□□-□□

Size	Parts No.
1.7 × 1.6	–
× 1.8	–
× 2	552-27
× 2.2	552-87
× 2.5	552-07
× 2.8	–
× 3	552-37
× 3.5	–
× 4	552-47
× 4.5	552-67
× 5	552-57
× 5.5	557-07
× 6	552-77
× 8	552-97
2 × 1.8	554-37
× 2	553-17
× 2.2	554-07
× 2.5	553-27
× 2.8	–
× 3	553-37
× 3.5	554-17
× 4	553-47
× 4.5	553-57
× 5	553-67
× 5.5	–
× 6	554-27
× 7	553-87
× 8	553-97
× 10	553-77
2.6 × 2.8	556-07
× 3	–
× 3.5	–
× 4	556-37
× 4.5	–
× 5	556-57
× 5.5	–
× 6	556-77
× 7	–
× 8	556-97
× 9	–
× 10	557-47

+B Cr-N

7-682-□□□-□□

Size	Parts No.
3 × 3	544-04
× 4	545-04
× 5	546-04
× 6	547-04
× 8	548-04
× 10	549-04
× 12	550-04
× 14	551-04
× 16	552-04
× 20	553-04
4 × 4	558-04
× 5	559-04
× 6	560-04
× 8	561-04
× 10	562-04
× 12	563-04
× 14	564-04
× 16	565-04
× 20	566-04
× 25	567-04
× 30	568-04
× 35	569-04
× 40	570-04
× 45	571-04
× 50	572-04
5 × 8	574-04
× 10	575-04
× 12	576-04
× 14	577-04
× 16	578-04
× 20	579-04
× 25	580-04
× 30	581-04

+B Bzn-N

7-682-□□□-□□

SIZE	Parts No.
3 x 3	544-09
x 4	545-09
x 5	546-09
x 6	547-09
x 8	548-09
x 10	549-09
x 12	550-09
x 14	551-09
x 16	552-09
x 20	553-09
x 30	555-09
4 x 4	558-09
x 5	559-09
x 6	560-09
x 8	561-09
x 10	562-09
x 12	563-09
x 14	564-09
x 16	565-09
x 20	566-09
5 x 8	574-09
x 10	575-09
x 12	576-09
x 14	577-09
x 16	578-09
x 20	579-09

+BVTT BZn-N

7-685-□□□-□□

SIZE	Parts No.
2 x 3	850-09
x 4	851-09
x 5	852-09
x 6	853-09
x 8	854-09
x 10	855-09
x 12	856-09
2.6 x 4	860-09
x 5	861-09
x 6	862-09
x 8	863-09
x 10	864-09
x 12	865-09
x 14	866-09
x 16	867-09
x 20	868-09
3 x 5	870-09
x 6	871-09
x 8	872-09
x 10	873-09
x 12	874-09
x 14	875-09
x 16	876-09
x 20	877-09
x 25	878-09
x 30	879-09

+BVTT Cr-N

7-685-□□□-□□

SIZE	Parts No.
2 x 3	850-04
x 4	851-04
x 5	852-04
x 6	853-04
x 8	854-04
x 10	855-04
x 12	856-04
2.6 x 4	860-04
x 5	861-04
x 6	862-04
x 8	863-04
x 10	864-04
x 12	865-04
x 14	866-04
x 16	867-04
x 20	868-04
3 x 5	870-04
x 6	871-04
x 8	872-04
x 10	873-04
x 12	874-04
x 14	875-04
x 16	876-04
x 20	877-04
x 25	878-04
x 30	879-04

+P Ni-N



7-621-□□□-□□

SIZE	Parts No.
2 x 3	255-12
x 4	255-22
x 5	255-32
x 6	255-42
x 8	255-52
x 10	255-62
x 12	255-72
x 14	–
x 16	–
x 20	–
2.3 x 5	–
x 6	–
x 8	–
x 10	–
x 12	–
x 14	–
x 16	–
x 20	–
2.6 x 3	259-12
x 4	259-22
x 5	259-32
x 6	259-42
x 8	259-52
x 10	259-62
x 12	259-72
x 14	259-82
x 16	260-02
x 20	260-22

+PWH



7-682-□□□-□□

Size	Parts No.
2.6 × 4	902-01
× 5	902-11
× 6	902-21
× 8	902-31
× 10	
× 12	902-51
× 14	
3 × 5	903-01
× 6	903-11
× 8	903-21
× 10	903-31
× 12	903-41
× 14	
4 × 6	904-01
× 8	904-11
× 10	904-21
× 12	904-31
× 14	904-41
× 16	
× 20	

+PSW Czn-N

7-682-□□□-□□

SIZE	Parts No.
3 x 6	947-01
x 8	948-01
x 10	949-01
x 12	950-01
x 14	951-01
x 16	952-01
x 20	953-01
x 25	954-01
x 30	955-01
x 35	956-01
x 40	957-01
4 x 8	961-01
x 10	962-01
x 12	963-01
x 14	964-01
x 16	965-01
x 20	966-01
x 25	967-01
x 30	968-01
x 35	969-01
x 40	970-01

+PS Czn-N

7-628-□□□-□□

Size	Parts No.
2 × 4	255-20
× 5	283-00
× 6	255-40
× 8	255-50
× 10	283-10
× 12	283-70
2.6 × 4	284-00
× 5	284-10
× 6	284-20
× 8	284-30
× 10	284-40
× 12	259-70
× 14	259-80
× 16	260-00
× 20	260-20

+K Bzn-N

7-682-□□□-□□

SIZE	Parts No.
3 x 4	245-09
x 5	246-09
x 6	247-09
x 8	248-09
x 10	249-09
x 12	250-09
x 14	251-09
x 16	252-09
x 20	253-09
4 x 6	260-09
x 8	261-09
x 10	262-09
x 12	263-09
x 14	264-09
x 16	265-09
x 20	266-09
5 x 8	274-09
x 10	275-09
x 12	276-09
x 14	277-09
x 16	278-09
x 20	279-09
x 25	280-09
x 30	281-09
x 35	282-09
x 40	283-09
x 45	284-09
x 50	285-09

+RK Cr-N

7-682-□□□-□□

Size	Parts No.
3 × 4	245-04
× 5	246-04
× 6	247-04
× 8	248-04
× 10	249-04
× 12	350-04
× 14	351-04
× 16	352-04
× 20	353-04
4 × 6	360-04
× 8	361-04
× 10	362-04
× 12	363-04
× 14	364-04
× 16	365-04
× 20	366-04
× 25	367-04
× 30	368-04
× 35	369-04
× 40	370-04
5 × 8	374-04
× 10	375-04
× 12	376-04
× 14	377-04
× 16	378-04
× 20	379-04

+K Cr-N

7-682-□□□-□□

SIZE	Parts No.
3 x 4	245-04
x 5	246-04
x 6	247-04
x 8	248-04
x 10	249-04
x 12	250-04
x 14	251-04
x 16	252-04
x 20	253-04
4 x 6	260-04
x 8	261-04
x 10	262-04
x 12	263-04
x 14	264-04
x 16	265-04
x 20	266-04

+BTP Bzn-N NON-SLIT



7-685-□□□-□□

SIZE	Parts No.
2.6 x 4	531-19
2.6 x 5	532-19
2.6 x 6	533-19
2.6 x 8	534-19
2.6 x 10	535-19
2.6 x 12	536-19
2.6 x 14	537-19
2.6 x 16	538-19
3 x 5	544-19
3 x 6	545-19
3 x 8	546-19
3 x 10	547-19
3 x 12	548-19
3 x 14	549-19
3 x 16	550-19
3 x 20	551-19
3 x 25	552-19
3 x 30	553-19
3 x 35	554-19
3 x 40	555-19
3 x 45	–
3 x 50	596-19
3 x 60	–

CAPACITOR, CHIP CERAMIC

Part No.	SP	Description			
1-163-083-00	s	CAP, CHIP CERAMIC	1pF	+-0.25pF	50V
1-163-085-00	s	CAP, CHIP CERAMIC	2pF	+-0.25pF	50V
1-163-087-00	s	CAP, CHIP CERAMIC	4pF	+-0.25pF	50V
1-163-089-00	s	CAP, CHIP CERAMIC	6pF	+-0.5pF	50V
1-163-091-00	s	CAP, CHIP CERAMIC	8pF	+-0.5pF	50V
1-163-093-00	s	CAP, CHIP CERAMIC	10pF	5%	50V
1-163-097-00	s	CAP, CHIP CERAMIC	15pF	5%	50V
1-163-101-00	s	CAP, CHIP CERAMIC	22pF	5%	50V
1-163-105-00	s	CAP, CHIP CERAMIC	33pF	5%	50V
1-163-109-00	s	CAP, CHIP CERAMIC	47pF	5%	50V
1-163-113-00	s	CAP, CHIP CERAMIC	68pF	5%	50V
1-163-117-00	s	CAP, CHIP CERAMIC	100pF	5%	50V
1-163-121-00	s	CAP, CHIP CERAMIC	150pF	5%	50V
1-163-125-00	s	CAP, CHIP CERAMIC	220pF	5%	50V
1-163-129-00	s	CAP, CHIP CERAMIC	330pF	5%	50V
1-163-133-00	s	CAP, CHIP CERAMIC	470pF	5%	50V
1-163-137-00	s	CAP, CHIP CERAMIC	680pF	5%	50V
1-163-141-00	s	CAP, CHIP CERAMIC	1000pF	5%	50V
1-163-145-00	s	CAP, CHIP CERAMIC	1500pF	10%	50V
1-164-161-11	s	CAP, CHIP CERAMIC	2200pF	10%	100V
1-164-182-11	s	CAP, CHIP CERAMIC	3300pF	10%	100V
1-163-017-00	s	CAP, CHIP CERAMIC	4700pF	10%	50V
1-163-019-00	s	CAP, CHIP CERAMIC	6800pF	10%	50V
1-164-232-11	s	CAP, CHIP CERAMIC	0.01	20%	100V
1-163-023-00	s	CAP, CHIP CERAMIC	0.015	10%	50V
1-163-034-00	s	CAP, CHIP CERAMIC	0.033		50V
1-163-035-00	s	CAP, CHIP CERAMIC	0.047		50V
1-163-036-00	s	CAP, CHIP CERAMIC	0.068		50V
1-163-038-00	s	CAP, CHIP CERAMIC	0.1		50V

CAPACITOR, ELECTROLYTIC

Part No.	SP	Description			
1-124-902-00	s	CAP, ELECT	0.47	20%	50V
1-124-791-11	s	CAP, ELECT	1.0	20%	100V
1-124-925-11	s	CAP, ELECT	2.2	20%	100V
1-123-382-00	s	CAP, ELECT	3.3	20%	100V
1-124-927-00	s	CAP, ELECT	4.7	20%	100V
1-123-875-91	s	CAP, ELECT	10	20%	50V
1-124-915-11	s	CAP, ELECT	10	20%	63V
1-124-667-11	s	CAP, ELECT	10	20%	100V
1-124-908-11	s	CAP, ELECT	22	20%	50V
1-124-916-11	s	CAP, ELECT	22	20%	63V
1-124-929-11	s	CAP, ELECT	22	20%	100V
1-124-963-11	s	CAP, ELECT	33	20%	16V
1-124-482-11	s	CAP, ELECT	33	20%	35V
1-124-917-11	s	CAP, ELECT	33	20%	63V
1-124-930-11	s	CAP, ELECT	33	20%	100V
1-124-446-11	s	CAP, ELECT	47	20%	10V
1-124-477-11	s	CAP, ELECT	47	20%	25V
1-124-910-11	s	CAP, ELECT	47	20%	50V
1-124-918-11	s	CAP, ELECT	47	20%	63V
1-124-931-11	s	CAP, ELECT	47	20%	100V
1-124-443-00	s	CAP, ELECT	100	20%	10V
1-126-101-11	s	CAP, ELECT	100	20%	16V
1-124-478-11	s	CAP, ELECT	100	20%	25V
1-124-122-11	s	CAP, ELECT	100	20%	50V
1-124-572-11	s	CAP, ELECT	100	20%	63V
1-123-605-00	s	CAP, ELECT	100	20%	100V
1-124-444-00	s	CAP, ELECT	220	20%	10V
1-124-120-11	s	CAP, ELECT	220	20%	25V
1-124-484-11	s	CAP, ELECT	220	20%	35V
1-124-911-11	s	CAP, ELECT	220	20%	50V
1-124-919-51	s	CAP, ELECT	220	20%	63V
1-124-628-11	s	CAP, ELECT	220	20%	100V
1-124-442-00	s	CAP, ELECT	330	20%	6.3V
1-124-604-00	s	CAP, ELECT	330	20%	10V
1-124-119-00	s	CAP, ELECT	330	20%	16V
1-124-479-11	s	CAP, ELECT	330	20%	25V
1-124-485-11	s	CAP, ELECT	330	20%	35V
1-124-912-11	s	CAP, ELECT	330	20%	50V
1-124-472-11	s	CAP, ELECT	470	20%	10V
1-124-475-11	s	CAP, ELECT	470	20%	16V
1-124-480-11	s	CAP, ELECT	470	20%	25V
1-126-104-11	s	CAP, ELECT	470	20%	35V
1-124-913-11	s	CAP, ELECT	470	20%	50V
1-124-921-11	s	CAP, ELECT	470	20%	63V
1-124-471-00	s	CAP, ELECT	1000	20%	6.3V
1-124-473-11	s	CAP, ELECT	1000	20%	10V
1-124-555-00	s	CAP, ELECT	1000	20%	16V
1-124-557-11	s	CAP, ELECT	1000	20%	25V
1-126-105-11	s	CAP, ELECT	1000	20%	35V
1-124-637-11	s	CAP, ELECT	1000	20%	50V
1-124-922-11	s	CAP, ELECT	1000	20%	63V
1-124-893-11	s	CAP, ELECT	2200	20%	10V
1-124-556-11	s	CAP, ELECT	2200	20%	16V
1-124-563-11	s	CAP, ELECT	2200	20%	25V
1-124-618-11	s	CAP, ELECT	2200	20%	35V

CAPACITOR, ELECTROLYTIC

Part No.	SP	Description			
1-124-607-11	s	CAP, ELECT	2200	20%	50V
1-124-621-11	s	CAP, ELECT	3300	20%	6.3V
1-124-887-00	s	CAP, ELECT	3300	20%	16V
1-124-636-00	s	CAP, ELECT	3300	20%	25V
1-124-762-00	s	CAP, ELECT	4700	20%	10V
1-124-898-11	s	CAP, ELECT	4700	20%	16V
1-124-564-11	s	CAP, ELECT	4700	20%	25V
1-124-891-11	s	CAP, ELECT	10000	20%	6.3V
1-124-763-00	s	CAP, ELECT	10000	20%	10V

CAPACITOR, ELECTROLYTIC

Part No.	SP	Description			
1-124-902-00	s	CAP, ELECT	0.47	20%	50V
1-124-791-11	s	CAP, ELECT	1.0	20%	100V
1-124-925-11	s	CAP, ELECT	2.2	20%	100V
1-123-382-00	s	CAP, ELECT	3.3	20%	100V
1-124-927-00	s	CAP, ELECT	4.7	20%	100V
1-123-875-91	s	CAP, ELECT	10	20%	50V
1-124-908-11	s	CAP, ELECT	22	20%	50V
1-124-963-11	s	CAP, ELECT	33	20%	16V
1-124-482-11	s	CAP, ELECT	33	20%	35V
1-124-917-11	s	CAP, ELECT	33	20%	63V
1-124-446-11	s	CAP, ELECT	47	20%	10V
1-124-477-11	s	CAP, ELECT	47	20%	25V
1-124-910-11	s	CAP, ELECT	47	20%	50V
1-124-443-00	s	CAP, ELECT	100	20%	10V
1-126-101-11	s	CAP, ELECT	100	20%	16V
1-124-478-11	s	CAP, ELECT	100	20%	25V
1-124-122-11	s	CAP, ELECT	100	20%	50V
1-124-444-00	s	CAP, ELECT	220	20%	10V
1-124-120-11	s	CAP, ELECT	220	20%	25V
1-124-484-11	s	CAP, ELECT	220	20%	35V
1-124-911-11	s	CAP, ELECT	220	20%	50V
1-124-442-00	s	CAP, ELECT	330	20%	6.3V
1-124-604-00	s	CAP, ELECT	330	20%	10V
1-124-119-00	s	CAP, ELECT	330	20%	16V
1-124-479-11	s	CAP, ELECT	330	20%	25V
1-124-485-11	s	CAP, ELECT	330	20%	35V
1-124-912-11	s	CAP, ELECT	330	20%	50V
1-124-472-11	s	CAP, ELECT	470	20%	10V
1-124-475-11	s	CAP, ELECT	470	20%	16V
1-124-480-11	s	CAP, ELECT	470	20%	25V
1-126-104-11	s	CAP, ELECT	470	20%	35V
1-124-913-11	s	CAP, ELECT	470	20%	50V

RESISTOR, CHIP METAL

Part No.	SP	Description			
1-216-603-11	s	RES, CHIP METAL	10	1%	1/10W
1-216-605-11	s	RES, CHIP METAL	12	1%	1/10W
1-216-609-11	s	RES, CHIP METAL	18	1%	1/10W
1-216-611-11	s	RES, CHIP METAL	22	1%	1/10W
1-216-614-11	s	RES, CHIP METAL	30	1%	1/10W
1-216-617-11	s	RES, CHIP METAL	39	1%	1/10W
1-216-619-11	s	RES, CHIP METAL	47	1%	1/10W
1-216-620-11	s	RES, CHIP METAL	51	1%	1/10W
1-216-623-11	s	RES, CHIP METAL	68	1%	1/10W
1-216-624-11	s	RES, CHIP METAL	75	1%	1/10W
1-216-625-11	s	RES, CHIP METAL	82	1%	1/10W
1-216-626-11	s	RES, CHIP METAL	91	1%	1/10W
1-216-627-11	s	RES, CHIP METAL	100	1%	1/10W
1-216-629-11	s	RES, CHIP METAL	120	1%	1/10W
1-216-631-11	s	RES, CHIP METAL	150	1%	1/10W
1-216-633-11	s	RES, CHIP METAL	180	1%	1/10W
1-216-634-11	s	RES, CHIP METAL	200	1%	1/10W
1-216-635-11	s	RES, CHIP METAL	220	1%	1/10W
1-216-636-11	s	RES, CHIP METAL	240	1%	1/10W
1-216-637-11	s	RES, CHIP METAL	270	1%	1/10W
1-216-638-11	s	RES, CHIP METAL	300	1%	1/10W
1-216-639-11	s	RES, CHIP METAL	330	1%	1/10W
1-216-640-11	s	RES, CHIP METAL	360	1%	1/10W
1-216-641-11	s	RES, CHIP METAL	390	1%	1/10W
1-216-642-11	s	RES, CHIP METAL	430	1%	1/10W
1-216-643-11	s	RES, CHIP METAL	470	1%	1/10W
1-216-644-11	s	RES, CHIP METAL	510	1%	1/10W
1-216-645-11	s	RES, CHIP METAL	560	1%	1/10W
1-216-647-11	s	RES, CHIP METAL	680	1%	1/10W
1-216-648-11	s	RES, CHIP METAL	750	1%	1/10W
1-216-649-11	s	RES, CHIP METAL	820	1%	1/10W
1-216-650-11	s	RES, CHIP METAL	910	1%	1/10W
1-216-651-11	s	RES, CHIP METAL	1.0k	1%	1/10W
1-216-652-11	s	RES, CHIP METAL	1.1k	1%	1/10W
1-216-653-11	s	RES, CHIP METAL	1.2k	1%	1/10W
1-216-655-11	s	RES, CHIP METAL	1.5k	1%	1/10W
1-216-656-11	s	RES, CHIP METAL	1.6k	1%	1/10W
1-216-657-11	s	RES, CHIP METAL	1.8k	1%	1/10W
1-216-658-11	s	RES, CHIP METAL	2k	1%	1/10W
1-216-659-11	s	RES, CHIP METAL	2.2k	1%	1/10W
1-216-660-11	s	RES, CHIP METAL	2.4k	1%	1/10W
1-216-661-11	s	RES, CHIP METAL	2.7k	1%	1/10W
1-216-662-11	s	RES, CHIP METAL	3k	1%	1/10W
1-216-663-11	s	RES, CHIP METAL	3.3k	1%	1/10W
1-216-664-11	s	RES, CHIP METAL	3.5k	1%	1/10W
1-216-665-11	s	RES, CHIP METAL	3.9k	1%	1/10W
1-216-666-11	s	RES, CHIP METAL	4.3k	1%	1/10W
1-216-667-11	s	RES, CHIP METAL	4.7k	1%	1/10W
1-216-668-11	s	RES, CHIP METAL	5.1k	1%	1/10W
1-216-669-11	s	RES, CHIP METAL	5.6k	1%	1/10W

RESISTOR, CHIP METAL

Part No.	SP	Description
1-216-670-11	s	RES, CHIP METAL 6.2k 1% 1/10W
1-216-671-11	s	RES, CHIP METAL 6.8k 1% 1/10W
1-216-672-11	s	RES, CHIP METAL 7.5k 1% 1/10W
1-216-673-11	s	RES, CHIP METAL 8.2k 1% 1/10W
1-216-674-11	s	RES, CHIP METAL 9.1k 1% 1/10W
1-216-675-11	s	RES, CHIP METAL 10k 1% 1/10W
1-216-676-11	s	RES, CHIP METAL 11k 1% 1/10W
1-216-677-11	s	RES, CHIP METAL 12k 1% 1/10W
1-216-678-11	s	RES, CHIP METAL 13k 1% 1/10W
1-216-679-11	s	RES, CHIP METAL 15k 1% 1/10W
1-216-680-11	s	RES, CHIP METAL 16k 1% 1/10W
1-216-681-11	s	RES, CHIP METAL 18k 1% 1/10W
1-216-682-11	s	RES, CHIP METAL 20k 1% 1/10W
1-216-683-11	s	RES, CHIP METAL 22k 1% 1/10W
1-216-684-11	s	RES, CHIP METAL 24k 1% 1/10W
1-216-685-11	s	RES, CHIP METAL 27k 1% 1/10W
1-216-686-11	s	RES, CHIP METAL 30k 1% 1/10W
1-216-687-11	s	RES, CHIP METAL 33k 1% 1/10W
1-216-688-11	s	RES, CHIP METAL 36k 1% 1/10W
1-216-689-11	s	RES, CHIP METAL 39k 1% 1/10W
1-216-690-11	s	RES, CHIP METAL 43k 1% 1/10W
1-216-691-11	s	RES, CHIP METAL 49k 1% 1/10W
1-216-692-11	s	RES, CHIP METAL 51k 1% 1/10W
1-216-693-11	s	RES, CHIP METAL 56k 1% 1/10W
1-216-694-11	s	RES, CHIP METAL 62k 1% 1/10W
1-216-695-11	s	RES, CHIP METAL 68k 1% 1/10W
1-216-696-11	s	RES, CHIP METAL 75k 1% 1/10W
1-216-697-11	s	RES, CHIP METAL 82k 1% 1/10W
1-216-698-11	s	RES, CHIP METAL 91k 1% 1/10W
1-216-699-11	s	RES, CHIP METAL 100k 1% 1/10W

INDUCTOR, MICRO

Part No.	SP	Description
1-408-876-00	s	INDUCTOR, MICRO 0.18 5%
1-408-877-00	s	INDUCTOR, MICRO 0.22 5%
1-408-878-00	s	INDUCTOR, MICRO 0.33 5%
1-408-879-21	s	INDUCTOR, MICRO 0.47 5%
1-408-931-00	s	INDUCTOR, MICRO 0.56 5%
1-408-880-00	s	INDUCTOR, MICRO 0.68 5%
1-408-763-00	s	INDUCTOR, MICRO 0.82 5%
1-408-397-00	s	INDUCTOR, MICRO 1.0 5%
1-408-398-00	s	INDUCTOR, MICRO 1.2 5%
1-408-399-00	s	INDUCTOR, MICRO 1.5 5%
1-408-400-00	s	INDUCTOR, MICRO 1.8 5%
1-408-401-00	s	INDUCTOR, MICRO 2.2 5%
1-408-402-00	s	INDUCTOR, MICRO 2.7 5%
1-408-403-00	s	INDUCTOR, MICRO 3.3 5%
1-408-404-00	s	INDUCTOR, MICRO 3.9 5%
1-408-405-00	s	INDUCTOR, MICRO 4.7 5%
1-408-406-00	s	INDUCTOR, MICRO 5.6 5%
1-408-407-00	s	INDUCTOR, MICRO 6.8 5%
1-408-408-00	s	INDUCTOR, MICRO 8.2 5%
1-408-409-00	s	INDUCTOR, MICRO 10 5%
1-408-410-00	s	INDUCTOR, MICRO 12 5%
1-408-411-00	s	INDUCTOR, MICRO 15 5%
1-408-412-00	s	INDUCTOR, MICRO 18 5%
1-408-413-00	s	INDUCTOR, MICRO 22 5%
1-408-414-00	s	INDUCTOR, MICRO 27 5%
1-408-415-00	s	INDUCTOR, MICRO 33 5%
1-408-416-00	s	INDUCTOR, MICRO 39 5%
1-408-417-21	s	INDUCTOR, MICRO 47 5%
1-408-418-00	s	INDUCTOR, MICRO 56 5%
1-408-419-00	s	INDUCTOR, MICRO 68 5%
1-408-420-00	s	INDUCTOR, MICRO 82 5%
1-408-421-00	s	INDUCTOR, MICRO 100 5%
1-408-422-00	s	INDUCTOR, MICRO 120 5%
1-408-423-00	s	INDUCTOR, MICRO 150 5%
1-408-424-00	s	INDUCTOR, MICRO 180 5%
1-408-425-00	s	INDUCTOR, MICRO 220 5%
1-408-426-00	s	INDUCTOR, MICRO 270 5%
1-408-427-00	s	INDUCTOR, MICRO 330 5%
1-408-428-00	s	INDUCTOR, MICRO 390 5%
1-408-429-00	s	INDUCTOR, MICRO 470 5%

AU-135 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-183-A	o	MOUNTED CIRCUIT BOARD, AU-135
6pcs	3-621-124-00	o	SPACER
4pcs	7-626-320-11	s	PIN, SPRING 3X8
2pcs	7-685-870-04	s	SCREW +BVTT 3X5 (S)
C4	1-131-347-00	s	TANTALUM 1uF 10% 35V
C13	1-131-347-00	s	TANTALUM 1uF 10% 35V
C23	1-131-347-00	s	TANTALUM 1uF 10% 35V
C35	1-107-165-00	s	MICA 56PF 5% 50V
C39	1-107-077-00	s	MICA 47PF 5% 50V
C43	1-131-379-00	s	TANTALUM 22uF 10% 10V
C44	1-131-347-00	s	TANTALUM 1uF 10% 35V
C46	1-131-379-00	s	TANTALUM 22uF 10% 10V
C49	1-131-347-00	s	TANTALUM 1uF 10% 35V
C55	1-131-379-00	s	TANTALUM 22uF 10% 10V
C56	1-131-347-00	s	TANTALUM 1uF 10% 35V
C58	1-131-379-00	s	TANTALUM 22uF 10% 10V
C77	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C79	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C81	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C83	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C85	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C87	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C89	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C91	1-130-499-00	s	MYLAR 0.22uF 5% 50V
C98	1-131-347-00	s	TANTALUM 1uF 10% 35V
C99	1-163-038-00	s	CERAMIC CHIP 0.1uF 25V
C101	1-124-589-11	s	ELECT 47uF 20% 10V
C104	1-124-589-11	s	ELECT 47uF 20% 10V
C105	1-124-589-11	s	ELECT 47uF 20% 10V
C108	1-124-273-00	s	ELECT, NONPOLAR 3.3uF 20% 50V
C110	1-124-248-00	s	ELECT 22uF 20% 35V
C112	1-124-248-00	s	ELECT 22uF 20% 35V
C113	1-124-584-00	s	ELECT 100uF 20% 10V
C114	1-124-584-00	s	ELECT 100uF 20% 10V
C115	1-124-584-00	s	ELECT 100uF 20% 10V
C116	1-124-584-00	s	ELECT 100uF 20% 10V
C201	1-124-589-11	s	ELECT 47uF 20% 10V
C204	1-124-589-11	s	ELECT 47uF 20% 10V
C205	1-124-589-11	s	ELECT 47uF 20% 10V
C208	1-124-273-00	s	ELECT, NONPOLAR 3.3uF 20% 50V
C210	1-124-248-00	s	ELECT 22uF 20% 35V
C212	1-124-248-00	s	ELECT 22uF 20% 35V
C213	1-124-584-00	s	ELECT 100uF 20% 10V
C214	1-124-584-00	s	ELECT 100uF 20% 10V
C215	1-124-584-00	s	ELECT 100uF 20% 10V
C216	1-124-584-00	s	ELECT 100uF 20% 10V
C233	1-131-368-00	s	TANTALUM 3.3uF 10% 16V
CN1	1-580-098-11	o	CONNECTOR, 50P
CN17	1-526-653-21	s	SOCKET, IC (DP) 14P
CN171	1-526-653-21	s	SOCKET, IC (DP) 14P
CP1	1-579-077-11	s	OSCILLATOR, CRYSTAL
CP2	1-577-596-11	s	OSCILLATOR, CRYSTAL
CP101	1-464-947-11	s	FILTER UNIT, LOW PASS
CP201	1-464-947-11	s	FILTER UNIT, LOW PASS
D1	8-719-107-23	s	DIODE RD20M-T1B1
D2	8-719-107-23	s	DIODE RD20M-T1B1
D3	8-719-118-38	s	DIODE 1SZ46A

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(AU-135 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
D4	8-719-105-72	s	DIODE RD4.7M-B1
D5	8-719-105-72	s	DIODE RD4.7M-B1
D6	8-719-105-72	s	DIODE RD4.7M-B1
D7	8-719-105-72	s	DIODE RD4.7M-B1
D9	8-719-800-76	s	DIODE 1SS226
D10	8-719-800-76	s	DIODE 1SS226
D11	8-719-800-76	s	DIODE 1SS226
D12	8-719-800-76	s	DIODE 1SS226
D13	8-719-800-76	s	DIODE 1SS226
D14	8-719-800-76	s	DIODE 1SS226
D15	8-719-800-76	s	DIODE 1SS226
D16	8-719-800-76	s	DIODE 1SS226
D17	8-719-800-99	s	DIODE TLG223
D18	8-719-800-99	s	DIODE TLG223
D19	8-719-800-99	s	DIODE TLG223
D20	8-719-800-99	s	DIODE TLG223
D21	8-719-800-99	s	DIODE TLG223
D22	8-719-800-99	s	DIODE TLG223
D23	8-719-801-26	s	DIODE TLR223
D24	8-719-118-38	s	DIODE 1SZ46A
D25	8-719-800-76	s	DIODE 1SS226
D26	8-719-948-47	s	DIODE HSM88AS
D27	8-719-948-47	s	DIODE HSM88AS
D28	8-719-948-47	s	DIODE HSM88AS
D29	8-719-948-47	s	DIODE HSM88AS
D101	8-719-911-19	s	DIODE 1SS119
D102	8-719-911-19	s	DIODE 1SS119
D103	8-719-911-19	s	DIODE 1SS119
D104	8-719-911-19	s	DIODE 1SS119
D105	8-719-107-23	s	DIODE RD20M-B1
D106	8-719-107-23	s	DIODE RD20M-B1
D107	8-719-107-23	s	DIODE RD20M-B1
D108	8-719-107-23	s	DIODE RD20M-B1
D201	8-719-911-19	s	DIODE 1SS119
D202	8-719-911-19	s	DIODE 1SS119
D203	8-719-911-19	s	DIODE 1SS119
D204	8-719-911-19	s	DIODE 1SS119
D205	8-719-107-23	s	DIODE RD20M-B1
D206	8-719-107-23	s	DIODE RD20M-B1
D207	8-719-107-23	s	DIODE RD20M-B1
D208	8-719-107-23	s	DIODE RD20M-B1
DL1	1-415-539-11	s	DELAY LINE, ACTIVE
IC1	8-759-906-53	s	IC TL062CPS
IC2	8-759-906-53	s	IC TL062CPS
IC3	8-759-906-53	s	IC TL062CPS
IC4	8-759-001-98	s	IC MC10198L
IC5	8-759-001-25	s	IC MC10125L
IC6	8-759-907-81	s	IC SN74LS221NS
IC7	8-759-721-49	s	IC EPM5032DC-AU2
IC8	8-759-918-71	s	IC CX23065
IC9	8-759-906-53	s	IC TL062CPS
IC10	8-759-925-74	s	IC SN74HC04NS
IC11	8-759-947-23	s	IC TL721CP
IC12	8-759-925-90	s	IC SN74HC74NS
IC13	8-759-151-25	s	IC CXD8138Q
IC14	8-759-918-71	s	IC CX23065
IC15	8-759-906-53	s	IC TL062CPS

(AU-135 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
IC16	8-759-925-90	s	IC SN74HC74NS
IC17	8-759-926-17	s	IC SN74HC153NS
IC18	8-759-925-76	s	IC SN74HC08NS
IC19	8-759-925-76	s	IC SN74HC08NS
IC20	8-759-925-76	s	IC SN74HC08NS
IC21	8-759-645-17	s	IC M54517P
IC22	8-759-925-83	s	IC SN74HC27NS
IC23	8-759-926-24	s	IC SN74HC164NS
IC24	8-759-926-24	s	IC SN74HC164NS
IC25	8-759-925-81	s	IC SN74HC20NS
IC26	8-759-925-74	s	IC SN74HC04NS
IC27	8-759-927-46	s	IC SN74HC00NS
IC28	8-759-925-90	s	IC SN74HC74NS
IC29	8-759-947-57	s	IC CXD1136Q
IC30	8-759-923-65	s	IC AM26LS31CNS
IC31	8-759-011-65	s	IC MC74HC4053F
IC32	8-759-945-98	s	IC CXD1146Q
IC33	8-759-989-91	s	IC TL7705ACPS
IC40	8-759-928-09	s	IC TLC27M2CPS
IC101	8-759-938-46	s	IC PCM56P-JS
IC102	8-759-700-96	s	IC NJM5534M
IC103	8-759-981-57	s	IC RC2043DD
IC104	8-759-982-03	s	IC RC5532DD
IC105	8-759-982-03	s	IC RC5532DD
IC201	8-759-938-46	s	IC PCM56P-JS
IC202	8-759-700-96	s	IC NJM5534M
IC203	8-759-981-57	s	IC RC2043DD
IC204	8-759-982-03	s	IC RC5532DD
IC205	8-759-982-03	s	IC RC5532DD
L1	1-410-284-11	s	10uH (WITH CORE)
L2	1-410-284-11	s	10uH (WITH CORE)
L3	1-410-284-11	s	10uH (WITH CORE)
L4	1-410-284-11	s	10uH (WITH CORE)
L5	1-410-284-11	s	10uH (WITH CORE)
L6	1-410-284-11	s	10uH (WITH CORE)
L7	1-410-284-11	s	10uH (WITH CORE)
L8	1-410-284-11	s	10uH (WITH CORE)
L9	1-410-284-11	s	10uH (WITH CORE)
L10	1-410-284-11	s	10uH (WITH CORE)
L11	1-410-284-11	s	10uH (WITH CORE)
L12	1-410-284-11	s	10uH (WITH CORE)
PH101	8-759-420-80	s	IC AQV203A
PH102	8-759-420-80	s	IC AQV203A
PH103	8-759-420-80	s	IC AQV203A
PH104	8-759-420-80	s	IC AQV203A
PH201	8-759-420-80	s	IC AQV203A
PH202	8-759-420-80	s	IC AQV203A
PH203	8-759-420-80	s	IC AQV203A
PH204	8-759-420-80	s	IC AQV203A
Q1	8-729-105-29	s	TRANSISTOR 2SA1385
Q2	8-729-205-88	s	TRANSISTOR 2SC3074-Y
Q3	8-729-113-33	s	TRANSISTOR 2SB733-4
Q4	8-729-177-33	s	TRANSISTOR 2SD773-4
Q5	8-729-113-33	s	TRANSISTOR 2SB733-4
Q6	8-729-177-33	s	TRANSISTOR 2SD773-4
Q7	8-729-140-36	s	TRANSISTOR 2SC3734-B23
Q8	8-729-420-14	s	TRANSISTOR 2SK614
Q9	8-729-901-05	s	TRANSISTOR DTA124EK-T146

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(AU-135 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
Q10	8-729-102-51	s	TRANSISTOR 2SC2759-U22
Q11	8-729-102-51	s	TRANSISTOR 2SC2759-U22
Q101	8-729-230-31	s	TRANSISTOR 2SC3074LB
Q102	8-729-230-32	s	TRANSISTOR 2SA1244LB
Q103	8-729-230-31	s	TRANSISTOR 2SC3074LB
Q104	8-729-230-32	s	TRANSISTOR 2SA1244LB
Q201	8-729-230-31	s	TRANSISTOR 2SC3074LB
Q202	8-729-230-32	s	TRANSISTOR 2SA1244LB
Q203	8-729-230-31	s	TRANSISTOR 2SC3074LB
Q204	8-729-230-32	s	TRANSISTOR 2SA1244LB
R32	1-216-675-11	s	METAL CHIP 10K 0.5% 1/10W
R51	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R60	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R62	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R101	1-216-105-00	s	METAL CHIP 220K 5% 1/10W
R102	1-216-113-00	s	METAL CHIP 470K 5% 1/10W
R103	1-216-119-00	s	METAL CHIP 820K 5% 1/10W
R114	1-249-389-11	s	CARBON 4.7 5% 1/6W
R115	1-249-389-11	s	CARBON 4.7 5% 1/6W
R116	1-249-397-11	s	CARBON 22 5% 1/4W
R119	1-249-482-11	s	CARBON 4.7 5% 1/2W
R126	1-249-389-11	s	CARBON 4.7 5% 1/6W
R127	1-249-389-11	s	CARBON 4.7 5% 1/6W
R128	1-249-397-11	s	CARBON 22 5% 1/4W
R131	1-249-482-11	s	CARBON 4.7 5% 1/2W
R201	1-216-105-00	s	METAL CHIP 220K 5% 1/10W
R202	1-216-113-00	s	METAL CHIP 470K 5% 1/10W
R203	1-216-119-00	s	METAL CHIP 820K 5% 1/10W
R214	1-249-389-11	s	CARBON 4.7 5% 1/6W
R215	1-249-389-11	s	CARBON 4.7 5% 1/6W
R216	1-249-397-11	s	CARBON 22 5% 1/4W
R219	1-249-482-11	s	CARBON 4.7 5% 1/2W
R226	1-249-389-11	s	CARBON 4.7 5% 1/6W
R227	1-249-389-11	s	CARBON 4.7 5% 1/6W
R228	1-249-397-11	s	CARBON 22 5% 1/4W
R231	1-249-482-11	s	CARBON 4.7 5% 1/2W
RV1	1-228-458-00	s	RES, ADJ, METAL 5K
RV2	1-228-457-00	s	RES, ADJ, METAL 2K
RV3	1-228-457-00	s	RES, ADJ, METAL 2K
RV4	1-228-455-00	s	RES, ADJ, METAL 500
RV101	1-228-461-00	s	RES, ADJ, METAL 50K
RV102	1-228-460-00	s	RES, ADJ, METAL 20K
RV201	1-228-461-00	s	RES, ADJ, METAL 50K
RV202	1-228-460-00	s	RES, ADJ, METAL 20K
S1	1-570-611-11	s	SWITCH, TOGGLE
S2	1-570-610-11	s	SWITCH, TOGGLE

CT-129 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
	A-7584-071-A	o	POWER ASSY A WITH CT-129/130, PS-227 BOARD
C51	1-130-471-00	s	MYLAR 0.001uF 5% 50V
C52	1-130-471-00	s	MYLAR 0.001uF 5% 50V
C55	1-130-471-00	s	MYLAR 0.001uF 5% 50V
C56	1-130-483-00	s	MYLAR 0.01uF 5% 50V
C57	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C58	1-126-176-11	s	ELECT 220uF 20% 10V
CN51	1-565-244-11	o	CONNECTOR, 12P Serial No.10001 - 10199
	1-573-172-11	s	PIN, LINE ANGLE(SIL) 12P Serial No.10201 -
D51	8-719-210-21	s	DIODE 11EQS04
D52	8-719-210-21	s	DIODE 11EQS04
D53	8-719-210-21	s	DIODE 11EQS04
D54	8-719-210-21	s	DIODE 11EQS04
D55	8-719-210-21	s	DIODE 11EQS04
D56	8-719-210-21	s	DIODE 11EQS04
D57	8-719-911-19	s	DIODE 1SS119
D58	8-719-107-87	s	THYRISTOR 03P2M
D59	8-719-911-19	s	DIODE 1SS119
IC51	8-759-906-62	s	IC MB3759-SNY
L51	1-410-466-41	s	4.7uH
Q53	8-729-119-76	s	TRANSISTOR 2SA1175-E
R51	1-215-419-00	s	METAL 820 1% 1/6W
R52	1-215-425-00	s	METAL 1.5K 1% 1/6W
R53	1-249-417-11	s	CARBON 1K 5% 1/4W
R54	1-249-417-11	s	CARBON 1K 5% 1/4W
R55	1-215-445-00	s	METAL 10K 1% 1/6W
R56	1-249-433-11	s	CARBON 22K 5% 1/4W
R57	1-247-897-11	s	CARBON 560K 5% 1/4W
R58	1-249-437-11	s	CARBON 47K 5% 1/4W
R59	1-249-405-11	s	CARBON 100 5% 1/4W
R60	1-215-480-00	s	METAL 300K 1% 1/6W
R61	1-215-429-00	s	METAL 2.2K 1% 1/6W
R62	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R63	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R64	1-247-895-00	s	CARBON 470K 5% 1/4W
R65	1-249-425-11	s	CARBON 4.7K 5% 1/4W
R66	1-249-426-11	s	CARBON 5.6K 5% 1/4W
R67	1-249-426-11	s	CARBON 5.6K 5% 1/4W
R68	1-249-415-11	s	CARBON 680 5% 1/4W
R69	1-249-405-11	s	CARBON 100 5% 1/4W
R70	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R71	1-215-481-00	s	METAL 330K 1% 1/6W

CT-130 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
	A-7584-071-A	o	POWER ASSY A WITH CT-129/130, PS-227 BOARD
C301	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C302	1-124-907-11	s	ELECT 10uF 20% 50V
C303	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C304	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C306	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C307	1-124-907-11	s	ELECT 10uF 20% 50V
C308	1-124-906-11	s	ELECT 4.7uF 20% 50V
C309	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C310	1-126-233-11	s	ELECT 22uF 20% 35V
C311	1-124-907-11	s	ELECT 10uF 20% 50V
C312	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C313	1-124-903-11	s	ELECT 1uF 20% 50V
CN301	1-565-244-11	o	CONNECTOR, 12P Serial No.10001 - 10199
	1-573-171-11	s	PIN, LINE ANGLE(SIL) 11P Serial No.10201 -
D301	8-719-911-19	s	DIODE 1SS119
D302	8-719-911-19	s	DIODE 1SS119
D303	8-719-911-19	s	DIODE 1SS119
D304	8-719-911-19	s	DIODE 1SS119
D305	8-719-107-87	s	THYRISTOR 03P2M
D306	8-719-313-16	s	DIODE AU02A
D307	8-719-911-19	s	DIODE 1SS119
D308	8-719-911-19	s	DIODE 1SS119
D309	8-719-911-19	s	DIODE 1SS119
IC301	8-759-135-80	s	IC UPC358C
IC302	8-759-908-15	s	IC TL431CLP
IC303	8-759-135-80	s	IC UPC358C
IC304	8-759-103-93	s	IC UPC393C
IC305	8-759-135-80	s	IC UPC358C
Q301	8-729-119-76	s	TRANSISTOR 2SA1175-E
Q302	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q303	8-729-178-55	s	TRANSISTOR 2SC2785-E
R301	1-249-437-11	s	CARBON 47K 5% 1/4W
R302	1-215-423-00	s	METAL 1.2K 1% 1/6W
R303	1-249-433-11	s	CARBON 22K 5% 1/4W
R304	1-249-437-11	s	CARBON 47K 5% 1/4W
R305	1-249-433-11	s	CARBON 22K 5% 1/4W
R306	1-249-437-11	s	CARBON 47K 5% 1/4W
R307	1-249-437-11	s	CARBON 47K 5% 1/4W
R308	1-249-417-11	s	CARBON 1K 5% 1/4W
R309	1-249-427-11	s	CARBON 6.8K 5% 1/4W
R310	1-249-437-11	s	CARBON 47K 5% 1/4W
R311	1-249-405-11	s	CARBON 100 5% 1/4W
R312	1-249-437-11	s	CARBON 47K 5% 1/4W
R313	1-249-437-11	s	CARBON 47K 5% 1/4W
R314	1-249-435-11	s	CARBON 33K 5% 1/4W
R315	1-249-405-11	s	CARBON 100 5% 1/4W
R316	1-249-429-11	s	CARBON 10K 5% 1/4W
R317	1-249-423-11	s	CARBON 3.3K 5% 1/4W
R318	1-249-435-11	s	CARBON 33K 5% 1/4W
R319	1-249-432-11	s	CARBON 18K 5% 1/4W
R320	1-249-433-11	s	CARBON 22K 5% 1/4W
R321	1-249-437-11	s	CARBON 47K 5% 1/4W
R322	1-249-437-11	s	CARBON 47K 5% 1/4W

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(CT-130 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
R323	1-249-429-11	s	CARBON 10K 5% 1/4W
R324	1-249-429-11	s	CARBON 10K 5% 1/4W
R325	1-249-437-11	s	CARBON 47K 5% 1/4W
R326	1-249-437-11	s	CARBON 47K 5% 1/4W
R327	1-249-437-11	s	CARBON 47K 5% 1/4W
R328	1-249-437-11	s	CARBON 47K 5% 1/4W
R329	1-249-435-11	s	CARBON 33K 5% 1/4W
R330	1-249-437-11	s	CARBON 47K 5% 1/4W
R331	1-249-439-11	s	CARBON 68K 5% 1/4W
R332	1-249-405-11	s	CARBON 100 5% 1/4W
R333	1-249-437-11	s	CARBON 47K 5% 1/4W
R334	1-249-437-11	s	CARBON 47K 5% 1/4W
R335	1-249-437-11	s	CARBON 47K 5% 1/4W
R336	1-249-429-11	s	CARBON 10K 5% 1/4W

DP-118 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	1-635-701-11	o	PRINTED CIRCUIT BOARD, DP-118
2pcs	4-904-327-01	o	HOLDER, LED
CN1	1-506-631-11	o	CONNECTOR, 4P MALE
CN2	1-506-468-11	o	CONNECTOR, 3P, MALE
D1	8-719-820-95	s	DIODE TLGC135AP
D2	8-719-820-95	s	DIODE TLGC135AP
R1	1-249-405-11	s	CARBON 100 5% 1/4W
R2	1-249-405-11	s	CARBON 100 5% 1/4W

DP-152 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	1-636-217-11	o	PRINTED CIRCUIT BOARD, DP-152
CN1	1-506-482-11	o	CONNECTOR, 3P, MALE
CN2	1-506-619-11	o	CONNECTOR, 8P FEMALE
D1	8-719-812-41	s	DIODE TLR124
D2	8-719-812-41	s	DIODE TLR124
D3	8-719-812-41	s	DIODE TLR124
D4	8-719-812-41	s	DIODE TLR124
R1	1-249-417-11	s	CARBON 1K 5% 1/4W
R2	1-249-417-11	s	CARBON 1K 5% 1/4W
R3	1-249-417-11	s	CARBON 1K 5% 1/4W
R4	1-249-417-11	s	CARBON 1K 5% 1/4W

EX-252 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-188-A	o	MOUNTED CIRCUIT BOARD, EX-252
4pcs	7-685-870-04	s	SCREW +BVTT 3X5 (S)
CN1	1-580-098-11	o	CONNECTOR, 50P
CN2	1-580-097-11	o	CONNECTOR, 50P
CN3	1-580-096-11	o	CONNECTOR, 50P

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

LF-22 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-182-A	o	MOUNTED CIRCUIT BOARD, LF-22
C601	⚠1-136-951-11	s	FILM 0.1uF 20% 25V
C602	⚠1-136-951-11	s	FILM 0.1uF 20% 25V
C603	⚠1-136-951-11	s	FILM 0.1uF 20% 25V
C604	⚠1-136-951-11	s	FILM 0.1uF 20% 25V
C605	⚠1-136-951-11	s	FILM 0.1uF 20% 25V
C606	⚠1-162-599-12	s	CERAMIC 0.0047uF 20% 400V
C607	⚠1-162-599-12	s	CERAMIC 0.0047uF 20% 400V
C608	⚠1-162-599-12	s	CERAMIC 0.0047uF 20% 400V
C609	⚠1-162-599-12	s	CERAMIC 0.0047uF 20% 400V
CN601	1-535-419-00	o	TAB, FASTEN (PCB)
CN602	1-535-419-00	o	TAB, FASTEN (PCB)
CN603	1-535-419-00	o	TAB, FASTEN (PCB)
CN604	1-535-419-00	o	TAB, FASTEN (PCB)
CN605	1-506-467-11	o	CONNECTOR, 2P, MALE
D601	8-719-911-19	s	DIODE 1SS119
F601	⚠1-532-496-00	s	FUSE, THERMO
L601	1-424-402-11	s	FILTER, LINE
L602	⚠1-412-458-11	s	INDUCTOR (WITH CORE)
L603	⚠1-412-458-11	s	INDUCTOR (WITH CORE)
R601	1-205-967-11	s	WIREWOUND 4.7 20% 10W
R602	1-205-967-11	s	WIREWOUND 4.7 20% 10W
R603	1-202-847-00	s	COMP 560K 10% 1/2W
R604	1-202-847-00	s	COMP 560K 10% 1/2W
RY601	⚠1-515-450-00	s	RELAY, POWER

MB-294 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-185-A	o	MOUNTED CIRCUIT BOARD, MB-294
6pcs	7-685-870-04	s	SCREW +BVTT 3X5 (S)
CN1	1-580-097-11	o	CONNECTOR, 50P
CN2	1-580-097-11	o	CONNECTOR, 50P
CN3	1-564-862-11	o	CONNECTOR, 8P
CN4	1-564-862-11	o	CONNECTOR, 8P
CN5	1-506-641-11	o	CONNECTOR, 24P MALE
CN6	1-506-635-11	o	CONNECTOR, 12P MALE
CN7	1-506-633-11	o	CONNECTOR, 8P MALE
CN101	1-561-365-21	s	CONNECTOR, RF
CN201	1-561-365-21	s	CONNECTOR, RF
CN301	1-561-365-21	s	CONNECTOR, RF
CN401	1-561-365-21	s	CONNECTOR, RF
CN501	1-561-365-21	s	CONNECTOR, RF

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

ORX-11 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-187-A	o	MOUNTED CIRCUIT BOARD, ORX-11
1pc	1-508-944-00	s	PIN
1pc	2-832-003-00	s	BUSH, INSULATING
2pcs	7-621-255-22	s	SCREW +P 2X4
1pc	7-623-924-01	s	WASHER 3.0, NYLONE
C1	1-127-518-11	s	ELECT(SOLID) 100uF 20% 16V
C2	1-127-518-11	s	ELECT(SOLID) 100uF 20% 16V
C4	1-131-349-00	s	TANTALUM 2.2uF 10% 35V
C8	1-127-531-11	s	ELECT 20 16V
C9	1-127-531-11	s	ELECT 20 16V
C10	1-126-233-11	s	ELECT 22uF 20% 35V
C102	1-126-233-11	s	ELECT 22uF 20% 35V
C105	1-131-367-00	s	TANTALUM 22uF 10% 16V
C106	1-163-086-00	s	CERAMIC CHIP 3PF 0.25PF 50V
C108	1-131-374-00	s	TANTALUM 33uF 10% 10V
C110	1-131-374-00	s	TANTALUM 33uF 10% 10V
C202	1-126-233-11	s	ELECT 22uF 20% 35V
C205	1-131-367-00	s	TANTALUM 22uF 10% 16V
C206	1-163-086-00	s	CERAMIC CHIP 3PF 0.25PF 50V
C208	1-131-374-00	s	TANTALUM 33uF 10% 10V
C210	1-131-374-00	s	TANTALUM 33uF 10% 10V
C302	1-126-233-11	s	ELECT 22uF 20% 35V
C305	1-131-367-00	s	TANTALUM 22uF 10% 16V
C306	1-163-086-00	s	CERAMIC CHIP 3PF 0.25PF 50V
C308	1-131-374-00	s	TANTALUM 33uF 10% 10V
C310	1-131-374-00	s	TANTALUM 33uF 10% 10V
C402	1-126-233-11	s	ELECT 22uF 20% 35V
C405	1-131-367-00	s	TANTALUM 22uF 10% 16V
C406	1-163-086-00	s	CERAMIC CHIP 3PF 0.25PF 50V
C408	1-131-374-00	s	TANTALUM 33uF 10% 10V
C410	1-131-374-00	s	TANTALUM 33uF 10% 10V
CN1	1-562-784-11	o	CONNECTOR, 18P
D1	8-719-118-38	s	DIODE 1SZ46A
D2	8-719-121-14	s	DIODE RD8.2ESL2
D3	8-719-121-14	s	DIODE RD8.2ESL2
D101	A-7615-184-A	s	PD ASSY
D201	A-7615-184-A	s	PD ASSY
D301	A-7615-184-A	s	PD ASSY
D401	A-7615-184-A	s	PD ASSY
IC1	8-759-906-53	s	IC TL062CPS
L1	1-421-957-11	s	COIL, CHOKE 30UH
L2	1-421-957-11	s	COIL, CHOKE 30UH
Q1	8-729-113-33	s	TRANSISTOR 2SB733-4
Q2	8-729-177-33	s	TRANSISTOR 2SD773-4
Q102	8-729-122-63	s	TRANSISTOR 2SA1226
Q103	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q104	8-729-112-65	s	TRANSISTOR 2SA1462
Q105	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q202	8-729-122-63	s	TRANSISTOR 2SA1226
Q203	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q204	8-729-112-65	s	TRANSISTOR 2SA1462
Q205	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q302	8-729-122-63	s	TRANSISTOR 2SA1226
Q303	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q304	8-729-112-65	s	TRANSISTOR 2SA1462
Q305	8-729-119-28	s	TRANSISTOR 2SC2758-U18

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(ORX-11 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
Q402	8-729-122-63	s	TRANSISTOR 2SA1226
Q403	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q404	8-729-112-65	s	TRANSISTOR 2SA1462
Q405	8-729-119-28	s	TRANSISTOR 2SC2758-U18
RV1	1-228-457-00	s	RES, ADJ, METAL 2K
RV101	1-228-455-00	s	RES, ADJ, METAL 500
RV102	1-228-461-00	s	RES, ADJ, METAL 50K
RV103	1-228-455-00	s	RES, ADJ, METAL 500
RV201	1-228-455-00	s	RES, ADJ, METAL 500
RV202	1-228-461-00	s	RES, ADJ, METAL 50K
RV203	1-228-455-00	s	RES, ADJ, METAL 500
RV301	1-228-455-00	s	RES, ADJ, METAL 500
RV302	1-228-461-00	s	RES, ADJ, METAL 50K
RV303	1-228-455-00	s	RES, ADJ, METAL 500
RV401	1-228-455-00	s	RES, ADJ, METAL 500
RV402	1-228-461-00	s	RES, ADJ, METAL 50K
RV403	1-228-455-00	s	RES, ADJ, METAL 500

OTX-11 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-186-A	o	MOUNTED CIRCUIT BOARD, OTX-11
1pc	1-508-944-00	s	PIN
1pc	2-832-003-00	s	BUSH, INSULATING
2pcs	4-026-506-00	o	HEAT SINK (C)
2pcs	7-623-957-41	s	WASHER 6.0, FIBER
C3	1-127-531-11	s	ELECT 20 16V
C4	1-127-531-11	s	ELECT 20 16V
C8	1-131-349-00	s	TANTALUM 2.2uF 10% 35V
C9	1-127-518-11	s	ELECT(SOLID) 100uF 20% 16V
C11	1-127-518-11	s	ELECT(SOLID) 100uF 20% 16V
C104	1-131-367-00	s	TANTALUM 22uF 10% 16V
C108	1-131-367-00	s	TANTALUM 22uF 10% 16V
C204	1-131-367-00	s	TANTALUM 22uF 10% 16V
C208	1-131-367-00	s	TANTALUM 22uF 10% 16V
CN1	1-563-008-11	o	CONTACT, FEMALE, AWG24-30
D1	8-719-121-14	s	DIODE RD8.2ESL2
D2	8-719-121-14	s	DIODE RD8.2ESL2
D3	8-719-118-38	s	DIODE 1SZ46A
D101	A-7615-264-A	s	LED ASSY
D102	8-719-911-19	s	DIODE 1SS119
D103	8-719-800-76	s	DIODE 1SS226
D104	8-719-800-76	s	DIODE 1SS226
D105	8-719-911-19	s	DIODE 1SS119
D106	8-719-800-76	s	DIODE 1SS226
D201	A-7615-264-A	s	LED ASSY
D202	8-719-911-19	s	DIODE 1SS119
D203	8-719-800-76	s	DIODE 1SS226
D204	8-719-800-76	s	DIODE 1SS226
D205	8-719-911-19	s	DIODE 1SS119
D206	8-719-800-76	s	DIODE 1SS226
IC1	8-759-906-53	s	IC TL062CPS
IC101	8-759-983-69	s	IC LM358PS
IC201	8-759-983-69	s	IC LM358PS
Q1	8-729-113-33	s	TRANSISTOR 2SB733-4
Q2	8-729-140-96	s	TRANSISTOR 2SD774-34
Q101	8-729-122-63	s	TRANSISTOR 2SA1226
Q102	8-729-125-20	s	TRANSISTOR 2SC1252
Q201	8-729-122-63	s	TRANSISTOR 2SA1226
Q202	8-729-125-20	s	TRANSISTOR 2SC1252
R106	1-214-822-00	s	METAL 18 1% 1/2W
R107	1-214-828-00	s	METAL 33 1% 1/2W
R109	1-214-711-00	s	METAL 180 1% 1/4W
R110	1-214-681-00	s	METAL 10 1% 1/4W
R206	1-214-822-00	s	METAL 18 1% 1/2W
R207	1-214-828-00	s	METAL 33 1% 1/2W
R209	1-214-711-00	s	METAL 180 1% 1/4W
R210	1-214-681-00	s	METAL 10 1% 1/4W
RV1	1-228-457-00	s	RES, ADJ, METAL 2K
RV101	1-228-454-00	s	RES, ADJ, METAL 200
RV102	1-228-458-00	s	RES, ADJ, METAL 5K
RV201	1-228-454-00	s	RES, ADJ, METAL 200
RV202	1-228-458-00	s	RES, ADJ, METAL 5K
TH101	1-800-194-11	s	THERMISTOR S-68-01
TH201	1-800-194-11	s	THERMISTOR S-68-01

PS-227 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
	A-7584-071-A	o	POWER ASSY A WITH CT-129/130, PS-227 BOARD
1pc	3-168-882-01	o	JOINTO
2PCS	7-683-402-04	s	BOLT, HEXAGON STOK3x5
B1	4-873-829-02	o	HEAT SINK
B2	7-682-952-01	s	SCREW +PSW 3X16
B5	9-983-709-01	s	RUBBER (STB-CR07), RADIATION
B6	9-983-709-01	s	RUBBER (STB-CR07), RADIATION
B7	7-682-949-01	s	SCREW +PSW 3X10
B8	7-682-949-01	s	SCREW +PSW 3X10
B9	9-983-709-01	s	RUBBER (STB-CR07), RADIATION
B10	9-983-709-01	s	RUBBER (STB-CR07), RADIATION
B11	9-983-709-01	s	RUBBER (STB-CR07), RADIATION
B12	9-983-709-01	s	RUBBER (STB-CR07), RADIATION
B14	7-682-952-01	s	SCREW +PSW 3X16
B15	7-682-952-01	s	SCREW +PSW 3X16
B16	7-684-023-04	s	N 3, TYPE 2
B17	7-684-023-04	s	N 3, TYPE 2
B18	7-682-648-09	s	SCREW +PS 3X8
B21	7-685-646-79	s	SCREW +BVTP 3X8 TYPE2 IT-3
B23	7-685-646-79	s	SCREW +BVTP 3X8 TYPE2 IT-3
B24	7-682-650-09	s	SCREW +PS 3X12
B25	7-682-650-09	s	SCREW +PS 3X12
B26	1-543-060-00	s	CORE
B27	1-543-060-00	s	CORE
B28	1-543-060-00	s	CORE
B29	1-543-060-00	s	CORE
B30	1-543-060-00	s	CORE
B31	1-543-060-00	s	CORE
B32	1-543-060-00	s	CORE
B33	1-543-060-00	s	CORE
B35	7-682-648-09	s	SCREW +PS 3X8
2pcs	1-533-190-11	s	CLIP, FUSE
1pc	1-570-258-11	s	SWITCH, THERMAL REED
C101	1-125-643-11	s	ELECT 2200uF 20% 250V
C102	1-125-643-11	s	ELECT 2200uF 20% 250V
C103	1-136-201-11	s	FILM 0.22uF 5% 400V
C104	⚠1-161-740-00	s	CERAMIC 470PF 10% 400V
C105	⚠1-161-740-00	s	CERAMIC 470PF 10% 400V
C106	1-136-626-11	s	FILM 1uF 10% 250V
C107	1-136-626-11	s	FILM 1uF 10% 250V
C108	1-136-626-11	s	FILM 1uF 10% 250V
C109	1-136-626-11	s	FILM 1uF 10% 250V
C110	1-101-821-00	s	CERAMIC 0.0022uF 500V
C111	1-101-821-00	s	CERAMIC 0.0022uF 500V
C201	1-162-318-11	s	CERAMIC 0.001uF 10% 500V
C202	1-162-318-11	s	CERAMIC 0.001uF 10% 500V
C203	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C204	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C205	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C206	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C207	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C208	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C209	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C210	1-162-131-11	s	CERAMIC 220PF 10% 2KV
C212	1-126-912-11	s	ELECT 33uF 0 250V
C213	1-128-128-11	s	ELECT 100uF 0 250V
C214	1-101-821-00	s	CERAMIC 0.0022uF 500V
C215	1-123-875-11	s	ELECT 10uF 20% 50V

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(PS-227 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
C216	1-123-875-11	s	ELECT 10uF 20% 50V
C217	1-126-233-11	s	ELECT 22uF 20% 35V
C218	1-130-483-00	s	MYLAR 0.01uF 5% 50V
C219	1-130-483-00	s	MYLAR 0.01uF 5% 50V
C220	1-130-493-00	s	MYLAR 0.068uF 5% 50V
C221	1-130-485-00	s	MYLAR 0.015uF 5% 50V
C222	1-130-485-00	s	MYLAR 0.015uF 5% 50V
C226	1-126-162-22	s	ELECT 3.3uF 20% 50V
C228	1-162-318-11	s	CERAMIC 0.001uF 10% 500V
C229	1-162-318-11	s	CERAMIC 0.001uF 10% 500V
C230	1-162-318-11	s	CERAMIC 0.001uF 10% 500V
C231	1-162-318-11	s	CERAMIC 0.001uF 10% 500V
C232	1-126-913-11	s	ELECT 220uF 0 160V
C233	1-126-913-11	s	ELECT 220uF 0 160V
C234	1-101-821-00	s	CERAMIC 0.0022uF 500V
CN101	1-535-419-00	o	TAB, FASTEN (PCB)
CN102	1-535-419-00	o	TAB, FASTEN (PCB)
CN103	1-535-419-00	o	TAB, FASTEN (PCB)
CN201	1-564-104-00	o	CONNECTOR, 3P, MALE
CN202	1-506-632-11	o	CONNECTOR, 6P MALE
CN203	1-506-631-11	o	CONNECTOR, 4P MALE
CN204	1-506-633-11	o	CONNECTOR, 8P MALE
CN205	1-506-702-11	o	CONNECTOR, ILG 3P,
CN207	1-564-001-11	o	CONNECTOR, 2P, MALE
CT129	1-590-194-11	s	SOCKET, SIL 12P
CT130	1-590-894-11	s	SOCKET, SIL 11P
D101	8-719-500-27	s	DIODE S15VB60
D102	8-719-210-21	s	DIODE 11EQS04
D103	8-719-210-21	s	DIODE 11EQS04
D201	8-719-979-28	s	DIODE ESAD39-06C
D202	8-719-979-29	s	DIODE ESAD39-06N
D203	8-719-979-28	s	DIODE ESAD39-06C
D204	8-719-979-29	s	DIODE ESAD39-06N
D205	8-719-313-16	s	DIODE AU02A
D206	8-719-110-85	s	DIODE RD36ES-B4
D207	8-719-313-14	s	DIODE FML-22S
D208	8-719-123-89	s	DIODE RD91E-B
D209	8-719-110-76	s	DIODE RD33ESB1
D210	8-719-110-39	s	DIODE RD15ESB1
D214	8-719-912-20	s	DIODE 1SS120
D215	8-719-912-20	s	DIODE 1SS120
D216	8-719-027-88	s	DIODE GL5KG8T
D217	8-719-110-85	s	DIODE RD36ES-B4
D218	8-719-110-85	s	DIODE RD36ES-B4
D219	8-719-313-16	s	DIODE AU02A
D220	8-719-313-16	s	DIODE AU02A
D221	8-719-912-20	s	DIODE 1SS120
D222	8-719-912-20	s	DIODE 1SS120
D223	8-719-907-25	s	DIODE ERA84-009
D224	8-719-907-25	s	DIODE ERA84-009
D225	8-719-907-25	s	DIODE ERA84-009
D226	8-719-907-25	s	DIODE ERA84-009
D227	8-719-027-89	s	DIODE GL5PR8T
D228	8-719-912-20	s	DIODE 1SS120
D229	8-719-119-79	s	DIODE RD3.0ESL2
D230	8-719-120-65	s	DIODE RD5.6ESL2
D232	8-719-912-20	s	DIODE 1SS120
D233	8-719-912-20	s	DIODE 1SS120

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(PS-227 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
D234	8-719-912-20	s	DIODE 1SS120
F101	⚠1-576-081-11	s	FUSE, GLASS TUBE
F102	⚠1-576-172-11	s	FUSE, MICRO
IC201	8-759-143-02	s	IC UPC7812HF
IC202	8-759-143-02	s	IC UPC7812HF
L101	1-424-058-11	s	LFT
L201	1-421-329-00	s	COIL, CHOKE 10uH
L202	1-424-403-11	s	COIL, CHOKE 13.3MMH
L203	1-421-370-00	s	CHOKE
L204	1-459-140-00	s	COIL, WITH CORE
L205	1-424-135-11	s	FILTER, LINE
PS201	1-532-679-00	s	LINK, IC
Q101	8-729-926-54	s	TRANSISTOR IRFP460
Q102	8-729-926-54	s	TRANSISTOR IRFP460
Q103	8-729-119-76	s	TRANSISTOR 2SA1175-E
Q104	8-729-119-76	s	TRANSISTOR 2SA1175-E
Q201	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q202	8-729-104-66	s	TRANSISTOR 2SC3158
Q203	8-729-104-66	s	TRANSISTOR 2SC3158
Q204	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q205	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q206	8-729-208-04	s	TRANSISTOR 2SK422
Q207	8-729-208-04	s	TRANSISTOR 2SK422
Q208	8-729-119-76	s	TRANSISTOR 2SA1175-E
Q209	8-729-119-76	s	TRANSISTOR 2SA1175-E
Q210	8-729-133-33	s	TRANSISTOR 2SC2333-L
Q212	8-729-140-27	s	TRANSISTOR 2SA1458-K
Q213	8-729-140-41	s	TRANSISTOR 2SC3731-K
Q214	8-729-140-27	s	TRANSISTOR 2SA1458-K
Q215	8-729-140-41	s	TRANSISTOR 2SC3731-K
Q216	8-729-140-41	s	TRANSISTOR 2SC3731-K
Q217	8-729-140-27	s	TRANSISTOR 2SA1458-K
Q218	8-729-140-27	s	TRANSISTOR 2SA1458-K
Q219	8-729-140-41	s	TRANSISTOR 2SC3731-K
Q220	8-729-140-41	s	TRANSISTOR 2SC3731-K
Q221	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q222	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q223	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q224	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q225	8-729-178-55	s	TRANSISTOR 2SC2785-E
Q226	8-729-178-55	s	TRANSISTOR 2SC2785-E
R101	1-214-921-00	s	CARBON 220K 5% 1/2W
R102	1-214-921-00	s	CARBON 220K 5% 1/2W
R103	1-205-625-00	s	WIREWOUND 220 5% 5W
R104	1-205-625-00	s	WIREWOUND 220 5% 5W
R105	1-247-696-11	s	CARBON 47 5% 1/4W
R106	1-247-696-11	s	CARBON 47 5% 1/4W
R107	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R108	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R201	1-205-625-00	s	WIREWOUND 220 5% 5W
R202	1-205-625-00	s	WIREWOUND 220 5% 5W
R203	1-205-625-00	s	WIREWOUND 220 5% 5W
R204	1-205-625-00	s	WIREWOUND 220 5% 5W
R205	1-249-433-11	s	CARBON 22K 5% 1/4W
R206	1-249-423-11	s	CARBON 3.3K 5% 1/4W
R207	1-247-893-11	s	CARBON 390K 5% 1/4W

(PS-227 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
R208	1-247-893-11	s	CARBON 390K 5% 1/4W
R209	1-215-897-11	s	METAL 6.8K 5% 2W
R210	1-215-897-11	s	METAL 6.8K 5% 2W
R212	1-247-887-00	s	CARBON 220K 5% 1/4W
R213	1-247-887-00	s	CARBON 220K 5% 1/4W
R214	1-247-887-00	s	CARBON 220K 5% 1/4W
R215	1-249-434-11	s	CARBON 27K 5% 1/4W
R216	1-247-881-00	s	CARBON 120K 5% 1/4W
R217	1-249-440-11	s	CARBON 82K 5% 1/4W
R218	1-249-440-11	s	CARBON 82K 5% 1/4W
R219	1-249-436-11	s	CARBON 39K 5% 1/4W
R220	1-249-433-11	s	CARBON 22K 5% 1/4W
R221	1-215-903-11	s	METAL 68K 5% 2W
R222	1-205-677-00	s	WIREWOUND 1K 5% 5W
R223	1-205-677-00	s	WIREWOUND 1K 5% 5W
R226	1-249-419-11	s	CARBON 1.5K 5% 1/4W
R227	1-249-437-11	s	CARBON 47K 5% 1/4W
R228	1-249-429-11	s	CARBON 10K 5% 1/4W
R229	1-249-437-11	s	CARBON 47K 5% 1/4W
R230	1-216-377-11	s	METAL 4.7 5% 2W
R231	1-247-747-11	s	CARBON 470 5% 1/2W
R232	1-247-747-11	s	CARBON 470 5% 1/2W
R233	1-215-463-00	s	METAL 56K 1% 1/6W
R234	1-215-437-00	s	METAL 4.7K 1% 1/6W
R235	1-249-426-11	s	CARBON 5.6K 5% 1/4W
R236	1-215-469-00	s	METAL 100K 1% 1/6W
R237	1-215-469-00	s	METAL 100K 1% 1/6W
R238	1-215-438-00	s	METAL 5.1K 1% 1/6W
R239	1-249-425-11	s	CARBON 4.7K 5% 1/4W
R240	1-249-419-11	s	CARBON 1.5K 5% 1/4W
R241	1-249-437-11	s	CARBON 47K 5% 1/4W
R242	1-249-429-11	s	CARBON 10K 5% 1/4W
R243	1-249-419-11	s	CARBON 1.5K 5% 1/4W
R247	1-247-881-00	s	CARBON 120K 5% 1/4W
R248	1-249-437-11	s	CARBON 47K 5% 1/4W
R249	1-247-881-00	s	CARBON 120K 5% 1/4W
R250	1-249-437-11	s	CARBON 47K 5% 1/4W
R251	1-249-437-11	s	CARBON 47K 5% 1/4W
R252	1-247-742-11	s	CARBON 180 5% 1/2W
R253	1-249-437-11	s	CARBON 47K 5% 1/4W
R254	1-249-437-11	s	CARBON 47K 5% 1/4W
R255	1-249-429-11	s	CARBON 10K 5% 1/4W
R256	1-249-437-11	s	CARBON 47K 5% 1/4W
R257	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R258	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R259	1-249-437-11	s	CARBON 47K 5% 1/4W
R260	1-247-889-00	s	CARBON 270K 5% 1/4W
R261	1-247-881-00	s	CARBON 120K 5% 1/4W
R262	1-249-437-11	s	CARBON 47K 5% 1/4W
R263	1-249-437-11	s	CARBON 47K 5% 1/4W
R264	1-249-429-11	s	CARBON 10K 5% 1/4W
R265	1-249-429-11	s	CARBON 10K 5% 1/4W
R266	1-249-437-11	s	CARBON 47K 5% 1/4W
R267	1-249-437-11	s	CARBON 47K 5% 1/4W
R268	1-249-429-11	s	CARBON 10K 5% 1/4W
R269	1-249-437-11	s	CARBON 47K 5% 1/4W
R270	1-249-429-11	s	CARBON 10K 5% 1/4W
R271	1-249-437-11	s	CARBON 47K 5% 1/4W
R272	1-249-429-11	s	CARBON 10K 5% 1/4W

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(PS-227 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
R273	1-249-437-11	s	CARBON 47K 5% 1/4W
R274	1-249-429-11	s	CARBON 10K 5% 1/4W
R275	1-249-437-11	s	CARBON 47K 5% 1/4W
R276	1-249-429-11	s	CARBON 10K 5% 1/4W
R277	1-249-429-11	s	CARBON 10K 5% 1/4W
S201	1-570-857-11	s	SWITCH, SLIDE
S202	1-570-832-11	s	SWITCH, SLIDE
T101	⚠1-450-192-11	s	TRANSFORMER, CONVERTER
T102	1-421-819-11	s	TRANSFORMER, CURRENT
T103	⚠1-437-188-11	s	TRANSFORMER, DRIVE
T104	⚠1-437-188-11	s	TRANSFORMER, DRIVE
T201	1-421-624-00	s	TRANSFORMER, CURRENT
VZ101	1-576-046-11	s	ARRESTER, GUS TUBE

PS-228 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
	A-7584-072-A	o	POWER ASSY B WITH PS-228 BOARD
2pcs	1-533-189-11	o	HOLDER, FUSE
2pcs	3-621-124-00	o	SPACER
1pc	7-682-247-04	s	SCREW +K 3X6
1pc	7-682-250-04	s	SCREW +K 3X12
2pcs	7-682-947-01	s	SCREW +PSW 3X6
6pcs	7-682-948-01	s	SCREW +PSW 3X8
4pcs	7-682-949-01	s	SCREW +PSW 3X10
C101	⚠1-136-472-11	s	FILM 0.1uF 20% 250V
C102	⚠1-136-297-11	s	FILM 0.033uF 20% 250V
C103	⚠1-161-742-00	s	CERAMIC 0.0022uF 20% 400V
C104	⚠1-161-742-00	s	CERAMIC 0.0022uF 20% 400V
C105	1-125-495-11	s	ELECT 220uF 20% 400V
C106	1-136-207-11	s	FILM 0.047uF 5% 630V
C108	1-136-744-11	s	FILM 0.22uF 5% 50V
C109	1-102-228-00	s	CERAMIC 470PF 10% 500V
C110	1-102-228-00	s	CERAMIC 470PF 10% 500V
C111	⚠1-161-742-00	s	CERAMIC 0.0022uF 20% 400V
C112	⚠1-161-742-00	s	CERAMIC 0.0022uF 20% 400V
C113	⚠1-161-742-00	s	CERAMIC 0.0022uF 20% 400V
C114	⚠1-161-742-00	s	CERAMIC 0.0022uF 20% 400V
C202	1-124-520-11	s	ELECT 3300uF 20% 10V
C203	1-124-520-11	s	ELECT 3300uF 20% 10V
C204	1-124-962-11	s	ELECT 2200uF 20% 25V
C205	1-124-962-11	s	ELECT 2200uF 20% 25V
C206	1-124-580-11	s	ELECT 330uF 20% 25V
C207	1-124-580-11	s	ELECT 330uF 20% 25V
C208	1-106-351-00	s	MYLAR 0.0022uF 5% 100V
C209	1-106-371-00	s	MYLAR 0.015uF 10% 200V
C210	1-130-483-00	s	MYLAR 0.01uF 5% 50V
C211	1-130-477-00	s	MYLAR 0.0033uF 5% 50V
C212	1-126-142-11	s	ELECT 100uF 20% 35V
C213	1-126-142-11	s	ELECT 100uF 20% 35V
C214	1-130-477-00	s	MYLAR 0.0033uF 5% 50V
C215	1-124-510-11	s	ELECT 220uF 20% 25V
C216	1-124-510-11	s	ELECT 220uF 20% 25V
C219	1-124-927-11	s	ELECT 4.7uF 20% 100V
C221	1-130-495-00	s	MYLAR 0.1uF 5% 50V
C222	1-130-491-00	s	MYLAR 0.047uF 5% 50V
C224	1-130-491-00	s	MYLAR 0.047uF 5% 50V
C225	1-130-471-00	s	MYLAR 0.001uF 5% 50V
C226	1-130-475-00	s	MYLAR 0.0022uF 5% 50V
C229	1-130-467-00	s	MYLAR 470pF 5% 50V
C230	1-130-471-00	s	MYLAR 0.001uF 5% 50V
C231	1-130-471-00	s	MYLAR 0.001uF 5% 50V
CN101	⚠1-564-104-00	o	CONNECTOR, 3P, MALE
CN201	1-506-640-11	o	CONNECTOR, 22P, MALE
CN202	1-506-633-11	o	CONNECTOR, 8P MALE
D101	8-719-300-63	s	DIODE LB-156
D102	8-719-970-87	s	DIODE ERA38-06
D103	8-719-911-19	s	DIODE 1SS119
D104	8-719-970-87	s	DIODE ERA38-06
D105	8-719-109-85	s	DIODE RD5.1ES-B2
D106	8-719-970-87	s	DIODE ERA38-06
D107	8-719-108-30	s	THYRISTOR 3P4MH
D201	8-719-970-87	s	DIODE ERA38-06
D202	8-719-920-67	s	DIODE ERC91-02
D203	8-719-970-87	s	DIODE ERA38-06

(PS-228 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
D204	8-719-970-39	s	DIODE ESAC92M-02
D205	8-719-903-16	s	DIODE ESAC85-009
D206	8-719-903-06	s	DIODE ERC84-009
D207	8-719-970-39	s	DIODE ESAC92M-02
D208	8-719-920-67	s	DIODE ERC91-02
D209	8-719-970-87	s	DIODE ERA38-06
D210	8-719-970-87	s	DIODE ERA38-06
D211	8-719-110-84	s	DIODE RD36ESB3
D212	8-719-913-44	s	DIODE ERA82-004
D213	8-719-911-19	s	DIODE 1SS119
D214	8-719-911-19	s	DIODE 1SS119
D215	8-719-110-84	s	DIODE RD36ESB3
D216	8-719-110-78	s	DIODE RD33ESB2
D217	8-719-913-44	s	DIODE ERA82-004
F101	⚠1-532-825-11	s	FUSE, GLASS TUBE
IC101	1-807-814-11	s	IC B-5272
IC201	8-759-602-66	s	IC M5230L-A
IC202	8-759-602-66	s	IC M5230L-A
IC203	8-759-937-59	s	IC MB3759
IC204	8-759-908-15	s	IC TL431CLP
L101	⚠1-424-385-11	s	LFT (SV16VF-10080)
L201	1-459-155-00	s	COIL, WITH CORE 45UH
L202	1-459-155-00	s	COIL, WITH CORE 45UH
PS201	1-532-605-00	s	LINK, IC
Q101	8-729-819-83	s	TRANSISTOR 2SC3460-M
Q102	8-729-140-96	s	TRANSISTOR 2SD774-34
Q201	8-729-905-88	s	TRANSISTOR 2SA1599
Q202	8-729-905-89	s	TRANSISTOR 2SC4149
Q203	8-729-905-88	s	TRANSISTOR 2SA1599
Q204	8-729-905-89	s	TRANSISTOR 2SC4149
Q205	8-729-119-76	s	TRANSISTOR 2SA1175-E
Q206	8-729-119-78	s	TRANSISTOR 2SC2785-HF
Q207	8-729-119-78	s	TRANSISTOR 2SC2785-HF
R101	⚠1-217-784-11	s	FUSIBLE 10 5% 5W
R102	1-215-902-11	s	METAL OXIDE 47K 5% 2W
R103	1-249-417-11	s	CARBON 1K 5% 1/4W
R104	1-247-694-11	s	CARBON 33 5% 1/4W
R105	1-247-704-11	s	CARBON 220 5% 1/4W
R106	1-216-427-00	s	METAL 120 5% 1W
R107	1-247-694-11	s	CARBON 33 5% 1/4W
R108	1-215-861-00	s	METAL 47 5% 1W
R109	1-249-417-11	s	CARBON 1K 5% 1/4W
R201	1-247-756-11	s	CARBON 2.2K 5% 1/2W
R202	1-247-756-11	s	CARBON 2.2K 5% 1/2W
R203	1-249-409-11	s	CARBON 220 5% 1/4W
R204	1-249-409-11	s	CARBON 220 5% 1/4W
R205	1-249-409-11	s	CARBON 220 5% 1/4W
R206	1-249-409-11	s	CARBON 220 5% 1/4W
R207	1-247-696-11	s	CARBON 47 5% 1/4W
R208	1-216-450-00	s	METAL 82 5% 2W
R209	1-247-764-11	s	CARBON 10K 5% 1/2W
R210	1-215-499-00	s	METAL 15K 1% 1/4W
R211	1-215-499-00	s	METAL 15K 1% 1/4W
R212	1-247-752-11	s	CARBON 1K 5% 1/2W
R213	1-247-752-11	s	CARBON 1K 5% 1/2W
R214	1-249-435-11	s	CARBON 33K 5% 1/4W
R215	1-249-423-11	s	CARBON 3.3K 5% 1/4W

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(PS-228 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
R217	1-215-499-00	s	METAL 15K 1% 1/4W
R218	1-215-499-00	s	METAL 15K 1% 1/4W
R219	1-247-739-11	s	CARBON 100 5% 1/2W
R220	1-247-739-11	s	CARBON 100 5% 1/2W
R221	1-249-430-11	s	CARBON 12K 5% 1/4W
R222	1-249-423-11	s	CARBON 3.3K 5% 1/4W
R224	1-249-439-11	s	CARBON 68K 5% 1/4W
R225	1-249-439-11	s	CARBON 68K 5% 1/4W
R226	1-249-441-11	s	CARBON 100K 5% 1/4W
R227	1-249-439-11	s	CARBON 68K 5% 1/4W
R228	1-249-409-11	s	CARBON 220 5% 1/4W
R229	1-249-418-11	s	CARBON 1.2K 5% 1/4W
R230	1-249-432-11	s	CARBON 18K 5% 1/4W
R231	1-247-903-00	s	CARBON 1M 5% 1/4W
R232	1-249-437-11	s	CARBON 47K 5% 1/4W
R233	1-247-887-00	s	CARBON 220K 5% 1/4W
R234	1-249-433-11	s	CARBON 22K 5% 1/4W
R235	1-249-423-11	s	CARBON 3.3K 5% 1/4W
R236	1-249-419-11	s	CARBON 1.5K 5% 1/4W
R237	1-249-423-11	s	CARBON 3.3K 5% 1/4W
R238	1-249-413-11	s	CARBON 470 5% 1/4W
R239	1-249-427-11	s	CARBON 6.8K 5% 1/4W
R240	1-249-419-11	s	CARBON 1.5K 5% 1/4W
R241	1-249-428-11	s	CARBON 8.2K 5% 1/4W
R242	1-249-421-11	s	CARBON 2.2K 5% 1/4W
R243	1-249-413-11	s	CARBON 470 5% 1/4W
R244	1-249-417-11	s	CARBON 1K 5% 1/4W
R245	1-249-426-11	s	CARBON 5.6K 5% 1/4W
R246	1-249-423-11	s	CARBON 3.3K 5% 1/4W
R247	1-249-436-11	s	CARBON 39K 5% 1/4W
RV201	1-228-456-00	s	RES, ADJ, METAL 1K
RV202	1-228-458-00	s	RES, ADJ, METAL 5K
RV203	1-228-458-00	s	RES, ADJ, METAL 5K
T101	⚠1-450-193-11	s	TRANSFORMER, CONVERTER
T102	⚠1-437-169-11	s	TRANSFORMER, DRIVE
T103	⚠1-421-715-21	s	TRANSFORMER, CURRENT
T104	⚠1-448-393-11	s	TRANSFORMER, CONVERTER

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

VA-99 BOARD

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-184-A	o	MOUNTED CIRCUIT BOARD, VA-99
1pc	X-3166-228-1	o	CASE ASSY, SHIELD, VA
10pcs	3-621-124-00	o	SPACER
4pcs	7-626-320-11	s	PIN, SPRING 3X8
2pcs	7-685-870-04	s	SCREW +BVTT 3X5 (S)
C3	1-161-485-00	s	CERAMIC 0.1uF 50V
C4	1-161-485-00	s	CERAMIC 0.1uF 50V
C5	1-161-485-00	s	CERAMIC 0.1uF 50V
C6	1-131-349-00	s	TANTALUM 2.2uF 10% 35V
C7	1-161-485-00	s	CERAMIC 0.1uF 50V
C8	1-127-499-00	s	ELECT(SOLID) 22uF 20% 16V
C9	1-127-499-00	s	ELECT(SOLID) 22uF 20% 16V
C13	1-161-485-00	s	CERAMIC 0.1uF 50V
C14	1-161-485-00	s	CERAMIC 0.1uF 50V
C15	1-161-485-00	s	CERAMIC 0.1uF 50V
C16	1-131-349-00	s	TANTALUM 2.2uF 10% 35V
C17	1-161-485-00	s	CERAMIC 0.1uF 50V
C18	1-127-499-00	s	ELECT(SOLID) 22uF 20% 16V
C19	1-127-499-00	s	ELECT(SOLID) 22uF 20% 16V
C101	1-124-589-11	s	ELECT 47uF 20% 10V
C102	1-124-589-11	s	ELECT 47uF 20% 10V
C104	1-131-365-00	s	TANTALUM 10uF 10% 16V
C105	1-131-365-00	s	TANTALUM 10uF 10% 16V
C108	1-131-377-00	s	TANTALUM 10uF 20% 10V
C113	1-131-347-00	s	TANTALUM 1uF 10% 35V
C114	1-131-347-00	s	TANTALUM 1uF 10% 35V
C115	1-131-365-00	s	TANTALUM 10uF 10% 16V
C116	1-131-365-00	s	TANTALUM 10uF 10% 16V
C117	1-131-367-00	s	TANTALUM 22uF 10% 16V
C119	1-131-365-00	s	TANTALUM 10uF 10% 16V
C120	1-131-365-00	s	TANTALUM 10uF 10% 16V
C123	1-124-242-00	s	ELECT 33uF 20% 25V
C125	1-124-589-11	s	ELECT 47uF 20% 10V
C128	1-124-242-00	s	ELECT 33uF 20% 25V
C129	1-124-242-00	s	ELECT 33uF 20% 25V
C130	1-131-365-00	s	TANTALUM 10uF 10% 16V
C131	1-131-365-00	s	TANTALUM 10uF 10% 16V
C133	1-124-589-11	s	ELECT 47uF 20% 10V
C134	1-124-589-11	s	ELECT 47uF 20% 10V
C140	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C142	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C148	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C150	1-102-963-00	s	CERAMIC 33PF 5% 50V
C201	1-124-589-11	s	ELECT 47uF 20% 10V
C202	1-124-589-11	s	ELECT 47uF 20% 10V
C204	1-131-365-00	s	TANTALUM 10uF 10% 16V
C205	1-131-365-00	s	TANTALUM 10uF 10% 16V
C208	1-131-377-00	s	TANTALUM 10uF 20% 10V
C213	1-131-347-00	s	TANTALUM 1uF 10% 35V
C214	1-131-347-00	s	TANTALUM 1uF 10% 35V
C215	1-131-365-00	s	TANTALUM 10uF 10% 16V
C216	1-131-365-00	s	TANTALUM 10uF 10% 16V
C217	1-131-367-00	s	TANTALUM 22uF 10% 16V
C219	1-131-365-00	s	TANTALUM 10uF 10% 16V
C220	1-131-365-00	s	TANTALUM 10uF 10% 16V
C223	1-124-242-00	s	ELECT 33uF 20% 25V
C225	1-124-589-11	s	ELECT 47uF 20% 10V
C228	1-124-242-00	s	ELECT 33uF 20% 25V
C229	1-124-242-00	s	ELECT 33uF 20% 25V

(VA-99 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
C230	1-131-365-00	s	TANTALUM 10uF 10% 16V
C231	1-131-365-00	s	TANTALUM 10uF 10% 16V
C233	1-124-589-11	s	ELECT 47uF 20% 10V
C234	1-124-589-11	s	ELECT 47uF 20% 10V
C240	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C242	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C248	1-163-088-00	s	CERAMIC CHIP 5PF +/-0.25PF 50V
C250	1-102-963-00	s	CERAMIC 33PF 5% 50V
C301	1-124-589-11	s	ELECT 47uF 20% 10V
C302	1-124-589-11	s	ELECT 47uF 20% 10V
C304	1-131-365-00	s	TANTALUM 10uF 10% 16V
C305	1-131-365-00	s	TANTALUM 10uF 10% 16V
C308	1-131-377-00	s	TANTALUM 10uF 20% 10V
C313	1-131-347-00	s	TANTALUM 1uF 10% 35V
C314	1-131-347-00	s	TANTALUM 1uF 10% 35V
C315	1-131-365-00	s	TANTALUM 10uF 10% 16V
C316	1-131-365-00	s	TANTALUM 10uF 10% 16V
C317	1-131-367-00	s	TANTALUM 22uF 10% 16V
C319	1-131-365-00	s	TANTALUM 10uF 10% 16V
C320	1-131-365-00	s	TANTALUM 10uF 10% 16V
C323	1-124-242-00	s	ELECT 33uF 20% 25V
C325	1-124-589-11	s	ELECT 47uF 20% 10V
C328	1-124-242-00	s	ELECT 33uF 20% 25V
C329	1-124-242-00	s	ELECT 33uF 20% 25V
C330	1-131-365-00	s	TANTALUM 10uF 10% 16V
C331	1-131-365-00	s	TANTALUM 10uF 10% 16V
C333	1-124-589-11	s	ELECT 47uF 20% 10V
C334	1-124-589-11	s	ELECT 47uF 20% 10V
C340	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C342	1-163-088-00	s	CERAMIC CHIP 5PF 0.25PF 50V
C348	1-163-088-00	s	CERAMIC CHIP 5PF +/-0.25PF 50V
C350	1-102-963-00	s	CERAMIC 33PF 5% 50V
C406	1-131-360-00	s	TANTALUM 15uF 10% 20V
C408	1-131-365-00	s	TANTALUM 10uF 10% 16V
C409	1-131-365-00	s	TANTALUM 10uF 10% 16V
C410	1-131-365-00	s	TANTALUM 10uF 10% 16V
C411	1-131-365-00	s	TANTALUM 10uF 10% 16V
C414	1-163-084-00	s	CERAMIC CHIP 1.5PF 0.25PF 50V
C415	1-131-381-00	s	TANTALUM 47uF 10% 6.3V
C416	1-131-381-00	s	TANTALUM 47uF 10% 6.3V
C506	1-131-360-00	s	TANTALUM 15uF 10% 20V
C508	1-131-365-00	s	TANTALUM 10uF 10% 16V
C509	1-131-365-00	s	TANTALUM 10uF 10% 16V
C510	1-131-365-00	s	TANTALUM 10uF 10% 16V
C511	1-131-365-00	s	TANTALUM 10uF 10% 16V
C514	1-163-084-00	s	CERAMIC CHIP 1.5PF 0.25PF 50V
C515	1-131-381-00	s	TANTALUM 47uF 10% 6.3V
C516	1-131-381-00	s	TANTALUM 47uF 10% 6.3V
C520	1-131-365-00	s	TANTALUM 10uF 10% 6.3V
CN1	1-580-098-11	o	CONNECTOR, 50P
D1	8-719-121-14	s	DIODE RD8.2ESL2
D2	8-719-121-14	s	DIODE RD8.2ESL2
D3	8-719-118-38	s	DIODE 1SZ46A
D4	8-719-121-14	s	DIODE RD8.2ESL2
D5	8-719-121-14	s	DIODE RD8.2ESL2
D6	8-719-118-38	s	DIODE 1SZ46A
D101	8-719-800-76	s	DIODE 1SS226
D102	8-719-800-76	s	DIODE 1SS226

(VA-99 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
D103	8-719-800-76	s	DIODE 1SS226
D104	8-719-119-70	s	DIODE RD2.7ESL2
D105	8-719-119-98	s	DIODE RD3.6ESL2
D106	8-719-801-26	s	DIODE TLR223
D201	8-719-800-76	s	DIODE 1SS226
D202	8-719-800-76	s	DIODE 1SS226
D203	8-719-800-76	s	DIODE 1SS226
D204	8-719-119-70	s	DIODE RD2.7ESL2
D205	8-719-119-98	s	DIODE RD3.6ESL2
D206	8-719-801-26	s	DIODE TLR223
D301	8-719-800-76	s	DIODE 1SS226
D302	8-719-800-76	s	DIODE 1SS226
D303	8-719-800-76	s	DIODE 1SS226
D304	8-719-119-70	s	DIODE RD2.7ESL2
D305	8-719-119-98	s	DIODE RD3.6ESL2
D306	8-719-801-26	s	DIODE TLR223
D401	8-719-800-76	s	DIODE 1SS226
D402	8-719-801-26	s	DIODE TLR223
D501	8-719-800-76	s	DIODE 1SS226
D502	8-719-801-26	s	DIODE TLR223
IC1	8-759-906-53	s	IC TL062CPS
IC2	8-759-906-53	s	IC TL062CPS
IC101	8-759-105-49	s	IC UPC319G2
IC102	8-759-906-53	s	IC TL062CPS
IC103	8-759-906-53	s	IC TL062CPS
IC104	8-759-079-05	s	IC MC79L05ACP
IC105	1-808-668-11	s	IC HDVA-1
IC106	8-759-906-53	s	IC TL062CPS
IC107	8-759-009-46	s	IC MC14528BF
IC201	8-759-105-49	s	IC UPC319G2
IC202	8-759-906-53	s	IC TL062CPS
IC203	8-759-906-53	s	IC TL062CPS
IC204	8-759-079-05	s	IC MC79L05ACP
IC205	1-808-668-11	s	IC HDVA-1
IC206	8-759-906-53	s	IC TL062CPS
IC207	8-759-009-46	s	IC MC14528BF
IC301	8-759-105-49	s	IC UPC319G2
IC302	8-759-906-53	s	IC TL062CPS
IC303	8-759-906-53	s	IC TL062CPS
IC304	8-759-079-05	s	IC MC79L05ACP
IC305	1-808-668-11	s	IC HDVA-1
IC306	8-759-906-53	s	IC TL062CPS
IC307	8-759-009-46	s	IC MC14528BF
IC401	8-759-980-04	s	IC LM311PS
IC402	8-759-906-53	s	IC TL062CPS
IC403	8-741-122-90	s	IC BX1229
IC501	8-759-980-04	s	IC LM311PS
IC502	8-759-906-53	s	IC TL062CPS
IC503	8-741-122-90	s	IC BX1229
L1	1-421-957-11	s	COIL, CHOKE 30UH
L2	1-421-957-11	s	COIL, CHOKE 30UH
L3	1-421-957-11	s	COIL, CHOKE 30UH
L4	1-421-957-11	s	COIL, CHOKE 30UH
PH101	1-807-154-11	s	ELEMENT, VAR, RES MCD-7417
PH102	1-807-154-11	s	ELEMENT, VAR, RES MCD-7417
PH201	1-807-154-11	s	ELEMENT, VAR, RES MCD-7417
PH202	1-807-154-11	s	ELEMENT, VAR, RES MCD-7417
PH301	1-807-154-11	s	ELEMENT, VAR, RES MCD-7417

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(VA-99 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
PH302	1-807-154-11	s	ELEMENT, VAR, RES MCD-7417
Q1	8-729-113-33	s	TRANSISTOR 2SB733-4
Q2	8-729-177-33	s	TRANSISTOR 2SD773-4
Q3	8-729-113-33	s	TRANSISTOR 2SB733-4
Q4	8-729-177-33	s	TRANSISTOR 2SD773-4
Q101	8-729-112-65	s	TRANSISTOR 2SA1462
Q102	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q103	8-729-301-12	s	TRANSISTOR 2SC2733
Q104	8-729-216-22	s	TRANSISTOR 2SA1162
Q105	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q106	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q107	8-729-112-65	s	TRANSISTOR 2SA1462
Q108	8-729-112-65	s	TRANSISTOR 2SA1462
Q109	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q110	8-729-112-65	s	TRANSISTOR 2SA1462
Q111	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q112	8-729-112-65	s	TRANSISTOR 2SA1462
Q113	8-769-401-67	s	TRANSISTOR 3SK163-1
Q114	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q115	8-769-401-67	s	TRANSISTOR 3SK163-1
Q116	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q117	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q118	8-729-100-66	s	TRANSISTOR 2SC1623
Q119	8-729-100-66	s	TRANSISTOR 2SC1623
Q201	8-729-112-65	s	TRANSISTOR 2SA1462
Q202	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q203	8-729-301-12	s	TRANSISTOR 2SC2733
Q204	8-729-216-22	s	TRANSISTOR 2SA1162
Q205	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q206	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q207	8-729-112-65	s	TRANSISTOR 2SA1462
Q208	8-729-112-65	s	TRANSISTOR 2SA1462
Q209	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q210	8-729-112-65	s	TRANSISTOR 2SA1462
Q211	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q212	8-729-112-65	s	TRANSISTOR 2SA1462
Q213	8-769-401-67	s	TRANSISTOR 3SK163-1
Q214	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q215	8-769-401-67	s	TRANSISTOR 3SK163-1
Q216	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q217	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q218	8-729-100-66	s	TRANSISTOR 2SC1623
Q219	8-729-100-66	s	TRANSISTOR 2SC1623
Q301	8-729-112-65	s	TRANSISTOR 2SA1462
Q302	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q303	8-729-301-12	s	TRANSISTOR 2SC2733
Q304	8-729-216-22	s	TRANSISTOR 2SA1162
Q305	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q306	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q307	8-729-112-65	s	TRANSISTOR 2SA1462
Q308	8-729-112-65	s	TRANSISTOR 2SA1462
Q309	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q310	8-729-112-65	s	TRANSISTOR 2SA1462
Q311	8-729-140-47	s	TRANSISTOR 2SC3735-L-B35
Q312	8-729-112-65	s	TRANSISTOR 2SA1462
Q313	8-769-401-67	s	TRANSISTOR 3SK163-1
Q314	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q315	8-769-401-67	s	TRANSISTOR 3SK163-1

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(VA-99 BOARD)

Ref. No. or Q'ty	Part No.	SP	Description
Q316	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q317	8-729-200-86	s	TRANSISTOR 2SC2714-0
Q318	8-729-100-66	s	TRANSISTOR 2SC1623
Q319	8-729-100-66	s	TRANSISTOR 2SC1623
Q401	8-729-112-65	s	TRANSISTOR 2SA1462
Q402	8-729-122-63	s	TRANSISTOR 2SA1226
Q403	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q404	8-729-100-66	s	TRANSISTOR 2SC1623
Q501	8-729-112-65	s	TRANSISTOR 2SA1462
Q502	8-729-122-63	s	TRANSISTOR 2SA1226
Q503	8-729-119-28	s	TRANSISTOR 2SC2758-U18
Q504	8-729-100-66	s	TRANSISTOR 2SC1623
R126	1-216-309-00	s	METAL CHIP 5.6 5% 1/10W
R127	1-216-309-00	s	METAL CHIP 5.6 5% 1/10W
R135	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R139	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R140	1-216-109-00	s	METAL CHIP 330K 5% 1/10W
R156	1-214-530-00	s	METAL 75 1% 1/8W
R177	1-215-425-00	s	METAL 1.5K 1% 1/6W
R226	1-216-309-00	s	METAL CHIP 5.6 5% 1/10W
R227	1-216-309-00	s	METAL CHIP 5.6 5% 1/10W
R235	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R239	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R240	1-216-109-00	s	METAL CHIP 330K 5% 1/10W
R256	1-214-530-00	s	METAL 75 1% 1/8W
R277	1-215-425-00	s	METAL 1.5K 1% 1/6W
R326	1-216-309-00	s	METAL CHIP 5.6 5% 1/10W
R327	1-216-309-00	s	METAL CHIP 5.6 5% 1/10W
R335	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R339	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R340	1-216-109-00	s	METAL CHIP 330K 5% 1/10W
R356	1-214-530-00	s	METAL 75 1% 1/8W
R377	1-215-425-00	s	METAL 1.5K 1% 1/6W
R412	1-216-675-11	s	METAL CHIP 10K 0.50% 1/10W
R419	1-216-121-00	s	METAL CHIP 1M 5% 1/10W
R426	1-249-400-11	s	CARBON 39 5% 1/4W
R427	1-249-400-11	s	CARBON 39 5% 1/4W
R428	1-249-397-11	s	CARBON 22 5% 1/4W
R526	1-249-400-11	s	CARBON 39 5% 1/4W
R527	1-249-400-11	s	CARBON 39 5% 1/4W
R528	1-249-397-11	s	CARBON 22 5% 1/4W
RV1	1-228-457-00	s	RES, ADJ, METAL 2K
RV2	1-228-457-00	s	RES, ADJ, METAL 2K
RV101	1-228-458-00	s	RES, ADJ, METAL 5K
RV102	1-228-456-00	s	RES, ADJ, METAL 1K
RV103	1-228-459-00	s	RES, ADJ, METAL 10K
RV104	1-228-460-00	s	RES, ADJ, METAL 20K
RV201	1-228-458-00	s	RES, ADJ, METAL 5K
RV202	1-228-456-00	s	RES, ADJ, METAL 1K
RV203	1-228-459-00	s	RES, ADJ, METAL 10K
RV204	1-228-460-00	s	RES, ADJ, METAL 20K
RV301	1-228-458-00	s	RES, ADJ, METAL 5K
RV302	1-228-456-00	s	RES, ADJ, METAL 1K
RV303	1-228-459-00	s	RES, ADJ, METAL 10K
RV304	1-228-460-00	s	RES, ADJ, METAL 20K

FRAME

Ref. No. or Q'ty	Part No.	SP	Description
	1-555-724-00	o	WIRE, GROUND
	1-563-223-11	s	CAP, DUST (6C+2P RECEPTACLE)
	1-946-217-11	o	HARNESS (CCU)
CN11	1-562-855-11	o	HOUSING, IL-M 6P
	1-564-092-11	o	CONTACT, FEMALE, IL-M, AWG24-28
CN101	1-560-163-00	s	PLUG, RF "R"
CN201	1-560-163-00	s	PLUG, RF "B"
CN301	1-560-163-00	s	PLUG, RF "G"
CN401	1-560-163-00	s	PLUG, RF "SYNC"
CN501	1-560-163-00	s	PLUG, RF "VF"
	1-946-219-11	o	HARNESS (FR POWER)
	1-535-072-00	o	CONTACT, FEMALE AWG18-24
CN5 (to MB-294 BOARD)			
	1-563-126-11	o	HOUSING, 24P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN9	1-566-358-11	s	PIN, D-SUB CONNECTOR 50P
	1-564-774-11	o	CONTACT, AWG22-24
CN11	1-561-518-00	o	HOUSING, ILG 6P
	1-946-222-11	o	HARNESS (FAN)
FA1	1-541-611-21	s	FAN, DC
	1-946-227-11	o	HARNESS (D-SUB)
CN201 (to PS-227 BOARD)			
	1-562-211-11	o	HOUSING, VH, 3P
	1-562-210-11	s	CONTACT, FEMALE, AWG22-18
CN201 (to PS-228 BOARD)			
	1-563-126-11	o	HOUSING, 24P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN203 (to PS-227 BOARD)			
	1-563-116-11	o	HOUSING, 4P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
BK1	1-576-037-11	s	BREAKER, CIRCUIT
C1	1-161-043-00	s	CERAMIC 2200P 10% 50V
C2	1-161-043-00	s	CERAMIC 2200P 10% 50V
C3	1-161-043-00	s	CERAMIC 2200P 10% 50V
C4	1-161-043-00	s	CERAMIC 2200P 10% 50V
CN1 (to DP-118 BOARD)			
	1-563-116-11	o	HOUSING, 4P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN1 (to DP-152 BOARD)			
	1-569-196-11	o	HOUSING, 3P
	1-569-194-11	o	CONTACT
CN2 (to DP-118 BOARD)			
	1-569-196-11	o	HOUSING, 3P
	1-569-194-11	o	CONTACT
CN2 (to DP-152 BOARD)			
	1-563-118-11	o	HOUSING, 8P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN3	1-509-176-41	s	CONNECTOR, 3P, FEMALE "D-AUD 1/2 OUT"
CN4	1-509-176-41	s	CONNECTOR, 3P, FEMALE "D-AUD 3/4 OUT"
CN5	1-509-176-41	s	CONNECTOR, 3P, FEMALE "D-AUD 5/6 OUT"
CN6	1-509-176-51	s	CONNECTOR, 3P, FEMALE "A-AUD 1 OUT"
CN6 (to MB-294 BOARD)			
	1-563-120-11	o	HOUSING, 12P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

(FRAME)

Ref. No. or Q'ty	Part No.	SP	Description
CN7	1-509-176-51	s	CONNECTOR, 3P, FEMALE "A-AUD 2 OUT"
CN7	1-563-118-11	o	HOUSING, 8P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN8	⚠1-580-375-11	s	INLET 3P "AC IN"
CN71	1-561-518-00	o	HOUSING, ILG 6P
	1-562-855-11	o	HOUSING, IL-M 6P
	1-564-092-11	o	CONTACT, FEMALE, IL-M, AWG24-28
CN101 (to PS-228 BOARD)			
	⚠1-562-211-11	o	HOUSING, VH, 3P
	⚠1-562-210-11	s	CONTACT, FEMALE, AWG22-18
CN202 (to PS-227 BOARD)			
	1-563-117-11	o	HOUSING, 6P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN202 (to PS-228 BOARD)			
	1-563-118-11	o	HOUSING, 8P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN204 (to PS-227 BOARD)			
	1-563-118-11	o	HOUSING, 8P
	1-563-115-11	o	CONTACT, FEMALE, AWG24-28
CN605 (to LF-22 BOARD)			
	1-569-195-11	s	HOUSING, 2P
SW1	⚠1-552-060-21	s	SWITCH, ROCKER(AC POWER)
SW2	⚠1-552-060-21	s	SWITCH, ROCKER(AC POWER)

PACKING MATERIALS & SUPPLIED ACCESSORIES

Ref. No. or Q'ty	Part No.	SP	Description
1pc	A-7515-188-A	o	MOUNTED CIRCUIT BOARD, EX-252
1pc	X-2146-504-1	o	ANGLE ASSY(2U, HD BLACK), RACK
2pcs	7-682-275-09	s	SCREW +K 5X10
1pc	⚠1-506-411-21	s	ADAPTOR, AC PLUG 3P-2P
1pc	⚠1-557-377-11	s	CORD, POWER
1pc	⚠1-556-760-11	s	CORD, POWER (3 CORE)
1pc	1-561-518-00	o	HOUSING, ILG 6P, FEMALE
2pcs	1-563-029-21	s	CONNECTOR, 3P
4pcs	7-627-556-37	s	SCREW,PRECISION +P2.6X4 TYPE 1
4pcs	2-297-913-00	s	WASHER (DIA.5), ORNAMENTAL
1pc	2-990-242-01	o	HOLDER (B), PLUG
4pcs	7-682-377-04	s	SCREW +RK 5X14
8pcs	7-682-662-09	s	SCREW +PS 4X10
4pcs	1-161-043-00	s	CERAMIC 2200P 10% 50V

Please see pages D-13 to D-15 for the part numbers of capacitors and resistors that are not listed in the parts list.

SECTION E
CHANGED PARTS

Ref. No. or Q'ty	Parts No.	SP	Description
AU-135 BOARD			
Serial No. Up to 10399			
D8	8-719-800-76	s	DIODE 1SS226
PS-227 BOARD			
Serial No. Up to 10199			
R205	1-249-425-11	s	CARBON 4.7k 5% 1/4W
R206	1-215-418-00	s	METAL 750 1% 1/6W
Serial No. Up to 10399			
D216	8-719-900-58	s	DIODE GL-5PG95
D227	8-719-921-01	s	DIODE EBR5534S
PS-228 BOARD			
Serial No. Up to 10299			
Q101	8-729-819-82	s	TRANSISTOR 2SC3460-L
Serial No. Up to 10399			
R210	1-249-431-11	s	CARBON 15k 5% 1/4W
R211	1-249-431-11	s	CARBON 15k 5% 1/4W
R217	1-249-431-11	s	CARBON 15k 5% 1/4W
R218	1-249-431-11	s	CARBON 15k 5% 1/4W
VA-99 BOARD			
Serial No. Up to 10199			
C103	1-131-377-00	s	TANTALUM 10µF 10% 10V
C203	1-131-377-00	s	TANTALUM 10µF 10% 10V
C303	1-131-377-00	s	TANTALUM 10µF 10% 10V
R412	1-215-445-00	s	METAL 10k 1% 1/6W

HDFR-300 (J, E)
3-166-523-04

Sony Corporation
Camera Products Group

Printed in Japan
1992. 4 11
© 1990
Published by B&P Marketing Group