

# PARTS LIST

for



## 30" ELECTRIC SLIDE-IN RANGE W/MODULAR COOKTOP

MODEL  
RS575PXR-5




FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



**Whirlpool** CORPORATION  
Benton Harbor, Michigan.

# OVEN PARTS

For Model: RS575PXR-5




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816791	Oven, Self Clean
2	877898	Vent Tube
	241428	Screw, 10-24 x 3/8 (2)
3		Bracket, Anti-Tip
4	816728	Retainer, Insulation (Bottom)
	681151	Screw, 10-24 x 1/2 (5)
5	877708	Retainer, Insulation (Top)
	681151	Screw, 10-24 x 1/2 (2)
6	816102	Bracket, Conduit
7	877721	Retainer, Insulation Side (2)
	681151	Screw, 10-24 x 1/2 (6)
9	877899	Support, Front (2)
	681151	Screw, 10-24 x 1/2 (10)
10	877723	Trim, Oven (Front) (2)
11		Side Panel (Lower)
	877724	Right Side
	877725	Left Side
	681151	Screw, 10-24 x 1/2 (6)
14	877709	Shield, Toe (2)
	681151	Screw, 10-24 x 1/2 (2)
15	877726	Channel, Oven Support (Lower)
	681151	Screw, 10-24 x 1/2 (2)
	834649	Screw, 10-24 x 7/8
17	877522	Bracket, Cooktop
	681151	Screw, 10-24 x 1/2 (5)
18	816103	Back, Range (Lower)
	681151	Screw, 10-24 x 1/2 (14)
	680363	Screw, 10-24 x 1/2
	487836	Nut, Hex 10-32 (3)
20	868880	Screw, Leveling (4)
21	251379	Plug Button (Light Switch Hole)
22	877711	Panel Side, Upper (2)
	681151	Screw, 10-24 x 1/2 (8)
23	241212	Block, Terminal Main
	834649	Screw, 10-24 x 7/8 (2)
	487836	Nut, Hex 10-32 (6)
24	877728	Back, Range (Upper)
	681151	Screw, 10-24 x 1/2 (4)
27	868829	Tube, Oven Vent
	681151	Screw, 10-24 x 1/2
31	816109	Cover, Wiring
	681151	Screw, 10-24 x 1/2 (6)
	486608	Washer, Flat (3)
32	816104	Deflector, Air

# CONTROL PANEL PARTS

For Model: RS575PXR-5




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	877712	Panel, Control
2		Rail, Control Panel
	868819	Top
	868820	Bottom
	681151	Screw, 10-24 x 1/2 (2)
4	816034	End Cap R.H.
	816035	End Cap L.H.
	877752	Screw, 8-18 x 1/2 (4)
	487521	Screw, 8-15 x 3/8 (2)
5		Bracket, Control Panel
	868823	Upper
	868824	Lower
	595135	Screw, 8-32 x 3/8 (2)
7	877698	Deflector, Heat
	877699	Washer, Flat (4)
	877752	Screw, 8-18 x 1/2 (4)
8	877865	Light, Indicator (125V) (Right Module, Left Module, Oven Clean)
	877900	Light, Indicator (Lock, Oven)
10	868934	Lens, Indicator Light (5)
14		Switch, Infinite (4)
	877713	Alternate
	877528	Alternate
	877919	Screw, 8-32 x 3/16 (8)
15	877527	Thermostat
17	816078	Bracket, Thermostat Mounting
	877919	Screw, 8-32 x 3/16 (4)
18	877901	Switch, Oven Selector
	877919	Screw, 8-32 x 3/16 (2)
19	834764	Bezel, Clock
20	816077	Timer, Range (Includes Illus. 21 & 22)
21	866403	Motor, Timer
22	255853	Knob, Timer (3)
23	868843	Glass, Clock
24	866148	Switch, Oven Light
	98754	Nut, Hex Flat 3/8-27
	816036	Nut, Knurled 3/8-27
25	877924	Control Knob (4) (Surface Unit)
27	868997	Knob, Thermostat
28	868998	Knob, Oven Selector

# COOKTOP PARTS

For Model: RS575PXR-5




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

2	816793	Bracket, Door Latch Switch
	681151	Screw, 10-24 x 1/2
4	865677	Switch, Door Latch
5	877523	Push Rod, Switch
7	877562	Rod End, Switch
8	816114	Support Latch Motor
	681151	Screw, 10-24 x 1/2
9	816113	Motor, Door Latch
10	816112	Cam, Door Latch
	816107	Pin, Spring
11	834905	Insulator, Limit Switch (2)
14		Switch Limit (Lower)
	834906	Alternate
	877877	Alternate
15		Switch Limit (Upper)
	868280	Alternate
	877878	Alternate
	834903	Screw, 4-40 x 1-1/4 (2)
17	877614	Housing Latch
	816058	Washer (2)
	868430	Screw, 10-24 x 1/2 (2)
18	877884	Axle, Latch
19	816105	Latch, Door
20	816106	Bar Tie
21	816079	Panel, Subtop
	681151	Screw, 10-24 x 1/2 (9)
	680363	Screw, 10-24 x 1/2 (2)
23	868833	Shield, Wire
	866466	Screw, 8-32 x 3/16 (10)
	681151	Screw, 10-24 x 1/2 (3)
24	868420	Receptacle, Porcelain (2)
26	868421	Clip, Receptacle (4)
	868959	Screw, 10-24 x 1/4 (4)
27	816083	Terminal Female
30	877714	Frame, Cooktop
33	877534	Cooktop, Modular
	868430	Screw, 10-24 x 1/2 (8)
	868959	Screw, 10-24 x 1/4 (6)
34	816081	Gasket, Vent Tube
36	816082	Cover, Vent
	877733	Clip, Retainer (2)
38	816080	Shield, Wire
	681151	Screw, 10-24 x 1/2 (2)

# DOOR AND DRAWER PARTS

For Model: RS575PXR-5




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1		Rail, Drawer
	816031	Right Side
	816032	Left Side
	681151	Screw, 10-24 x 1/2 (2)
2	877727	Spacer, Drawer Rail (2)
4	868127	Guide, Drawer Front (2)
	834649	Screw, 10-24 x 7/8 (2)
5	816111	Frame, Oven Door
	868430	Screw, 10-24 x 1/2 (6)
7	877906	Handle, Door
	877889	Screw, 6-32 x 1/2 (4)
10	877907	Glass, Outer (Black)
14	816797	Panel, Airwash
	877702	Screw, 10-16 x 1-1/2
15	816794	Glass, Inner
17	868503	Retainer Glass (2)
	681151	Screw, 10-24 x 1/2 (4)
19	816795	Liner, Oven Door
	681151	Screw, 10-24 x 1/2 (9)
20	816796	Baffle
21	142001	Button, Plug 3/16 (2)
24	877590	Seal, Oven Door
26	877505	Window
28	877506	Seal, Window
	681151	Screw, 10-24 x 1/2 (2)
29	877507	Strike
	816058	Washer (2)
	868430	Screw, 10-24 x 1/2 (2)
31	865972	Channel, Hinge (2)
	868430	Screw, 10-24 x 1/2 (4)
32	834471	Roller, Door Stop (2)
	816058	Washer (2)
34	241423	Rivet, Square Head (2)
35	865640	Arm Assembly (2)
36	877884	Pin, Hinge (2)
37	241312	Spring, Door (2)
40	877716	Drawer
	441256	Nut, Hex 10-24 (2)
41	877717	Guide, Drawer (Rear) (2)
42	877903	Screw, 10-24 x 3/8 (2)
43	877734	Panel, Drawer Black
44	877718	Handle, Drawer
	877903	Screw, 10-32 x 3/8 (4)

# INTERIOR OVEN PARTS

For Model: RS575PXR-5




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	877802	Cup, Light
	486146	Screw, 10-24 x 1/2 (2)
2	877803	Receptacle, Light
3	527949	Bulb, Light
5	877804	Lens, Light
7	877805	Retainer, Lens
9		Unit, Broiler
	865934	(240V)
	261968	(208V)
	486146	Screw, 10-24 x 1/2 (2)
10	866429	Hanger, Broil Unit
	486146	Screw, 10-24 x 1/2 (2)
12		Unit Bake
	868964	Alternate (240V)
	868963	Alternate (240V)
	261967	Alternate (208V)
	486146	Screw, 10-24 x 1/2 (2)
15	865959	Bracket, Thermobulb
	486146	Screw, 10-24 x 1/2
17	142017	Button, Plug 1/2 (2)
19	865983	Rack, Oven Regular
20	877951	Rack, Oven Offset
22	866219	Grill, Broiler Pan
23	816792	Pan, Broiler

# GRILLE MODULE KIT RCK891-2 (816531)

For Model: RS575PXR-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816531	Grill Kit, Complete
2	816534	Pan, Grill
3	877549	Rack Grill (2)
4	877541	Unit, Dual (2200W)
6	868437	Receptacle, Male
	868878	Pushnut, 1/4"
8	816532	Frame, Basket (2)
9	877543	Handle, Basket (2)
	868430	Screw, 10-24 x 1/2 (2)
10	868460	Rocks, Lava (4 Lbs.)
11	816533	Screen, Basket (2)

LITERATURE AND OPTIONAL PARTS

SPLICING WIRES--25FT. LENGTH

242828	Wire, Black 12 Ga. 150~c
242820	Wire, Black 14 Ga. 150~c
242821	Wire, Blue 14 Ga. 150~c
242822	Wire, Brown 14 Ga. 150~c
242830	Wire, Brown 14 Ga. 200~c
242823	Wire, Green 14 Ga. 150~c
242824	Wire, Orange 14 Ga. 150~c
242829	Wire, Red 12 Ga. 150~c
242825	Wire, Red 14 Ga. 150~c
242831	Wire, Red 14 Ga. 200~c
242826	Wire, White 14 Ga. 150~c
242827	Wire, Yellow 14 Ga. 150~c
242832	Wire, Yellow 14 Ga. 200~c

ACCESSORY PARTS

877691	Backguard Kit (RCK950)
877692	Side Panel Kit, White (RCK952W)
877703	Side Panel Kit, Almond (RCK952N)
877704	Side Panel Kit, Gold (RCK952G)
877705	Side Panel Kit, Coffee (RCK952C)
261950	Griddle Kit (RCK884)
242886	Rotisserie Kit (RCK892)
242903	Surface unit Module, 1-6" 1-8"
877860	Surface Unit Module, 2-6"
877959	Solid Element Module

PAINT, TOUCH UP (1/2 oz.)

72017	White
72107	Almond
72109	New Avocado
72108	Coffee
72110	Harvest Gold
511873	White Porcelain (2 Oz.)

PAINT PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
261888	New Avocado
261886	Coffee
261890	Harvest Gold
285006	Superior Black
206922	Primer (White)

206925 Leveler (Thinner) (2 Oz.)

PAINT, BULK (1 qt.)

799344 White (Uncut)  
978883 Almond (Uncut)  
261889 New Avocado (Uncut)  
261887 Coffee (Uncut)  
261891 Harvest Gold (Uncut)

REFINISHING MATERIAL

799832 Kit, Porcelain Repair (White)  
261748 Touch-Up, Oven (1 Oz.)  
261582 Grease

INSULATION

261514 Insulation, Fiberglass (1-1/2" x 24" x 120")  
240132 Insulation, Fiberglass (2-1/2" x 22" x 120")  
866187 Insulation, Moisture Barrier  
241531 Insulation, Door  
834470 Insulation, Oven Back  
834469 Insulation, Oven Wrapper  
241430 Foil, Aluminum Oven (18" x 25")

LITERATURE PARTS

LIT816052 Tech Sheet  
LIT877750 Installation Instructions  
LIT816021 Guide, Use & Care  
LIT877952 Guide, Cooking  
LIT816782 List, Repair Parts