

KIRKLAND
Signature


FRAME AND CONSOLE PARTS

For Model: SUD600HQ0

(White)

UNDERCOUNTER
DISHWASHER

By Whirlpool
CORPORATION




1		Console (Includes Insert)
	8051720	White
2	3379357	Catch, Door
3	3379358	Spring, Door Catch
4	3376359	Fuse, Thermal
5	9744031	Control, Electronic
7	304231	Screw
8		Door Frame
	9743028	Black
9	3380854	Bolt, Latch
10		Lever, Latch
	3372231	White
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	8271433	Harness and Protector
14	3376405	Elbow, Harness
15	3400803	Screw
16	8051304	Cover, Control
17	3374501	Motor, Dual Wax
19		Panel, Front
	3379376	White
21	98997	Clip, Harness
22	8054189	Barrier, Lower Vent
25	3373234	Bearing, Spring (2)

INNER DOOR PARTS

For Model: SUD600HQ0

(White)




1	3371435	Door, Inner (Includes Items 2 & 3)
2	3376066	Latch, Detergent Dispenser (Includes Item 3)
3	3369061	Snap, Detergent Dispenser (Includes Item 2)
4	3369055	Actuator Assembly
5	8052027	Wet Agent, Dispenser
6	3379673	Seal, Door Vent
7		Draw Bar,
	3369000	Upper Dispenser
	3369602	Lower Dispenser
8	3368999	Spring (Draw Bar)
9	3378138	Lid Assembly
10	300106	Spring, Lid
11	3372028	Pin (Lid Hinge) (Also Order Item 10)
12	3371710	Screen, Vent
13	3378134	Cap, Wet-Agent
15	3400815	Screw
16	3371569	Cover, Drip
17	3374772	Damper, Door (2)
19	3379674	Vent Asm. (Includes Item 6)
20	8271325	Absorber, Sound

TUB ASSEMBLY PARTS

For Model: SUD600HQ0

(White)




1	3378160	Tub Assembly
2	3380371	Tub, Wheel Assembly (8)
3	3368933	Runner (2)
4	3376439	Leveler (2)
5	3370389	Screw, Shoulder
6	302819	Wheel (2)
7	343641	Screw,
8	3378149	Plate, Latch
9	3374720	Screw
10	3376927	Gasket
12	3378140	Deflector (2)
13	3379487	Heater (Includes Item 14)
14	717273	Washer, Rubber (2)
15	3378706	Nut (2) (Heater Terminal)
16	3378779	Water Valve
17	304392	Screw
18	661566	Thermostat, Hi-Limit
20	301958	Clamp
22	3378595	Bracket, Thermostat
25	304231	Screw
26	3374767	Insulation, Toe & Access. Panel
28	3374343	Spring, Door (2)
29	3369048	Housing, Float Switch
30	3369067	Switch, Float
31	3369049	Cover, Switch Housing
32	3376397	Float & Washer Assembly
33	717488	Nut
34		Panel, Toe (Includes #26)
	9742869	White
35		Panel, Access
	3379918	White
36	302868	Screw
37	3369414	Hose, Inlet
39	3379740	Support, Heater
40	8055334	Shield, Sound
41	3378131	Terminal Box
42	300068	Cover Assembly, Terminal Box
45	3380885	Seal, Top
46	3380884	Seal, Side (2)
48	304666	Retainer, Push (2)
49	3370307	Strain Relief
50	3378128	Washer
51	3400014	Screw
52	3369138	Screw
53	3378123	Clip, Grounding
54	8052018	Friction Pad (Velcro)
55	3374773	Damper, Tub side (6)

PUMP AND MOTOR PARTS

For Model: SUD600HQ0

(White)

Note: The Pump Gasket Must Be Replaced Anytime The Pump Assembly Is Removed And Reinstalled In The Dishwasher.




1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.
3	9741232	Screw
4	302710	Seal, Inlet Base
5	302709	Ball, Check
6	95080	"O" Ring
7	719929	Ball, Check
9	9742968	Filter
10	3400001	Screw
11	3378176	Impeller, Wash (Includes Items 12 & 13)
12	3371152	Screw & Seal
13	302711	Seal, Pump Outlet
14	3376844	Outlet, Pump (Includes Item 13)
15	3369482	Check Valve (Includes Item 6)
16	717000	Gasket, Pump
17	8051313	Pump & Motor Assembly (Includes Item 16)
19	3378175	Chopper Kit (Also Order Item 30) See Note A.
22	302704	Seal, Drain Cover
23	3376845	Cover, Drain (Also Order Item 30) See Note A.
24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.
25	3376157	Base, Pump (Includes Item 24) (Also Order Item 30) See Note A.
26	3367197	Support, Pump Mounting (4)
27	3368270	Slinger (See Note A.)
28	3377333	Motor (Includes Item 27) (Also Order Item 30) See Note A.
29	3369331	Screw
30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
31	303918	Tool, Pump Centering
32	356138	Clamp, Hose
33	3374077	Hose, Drain
34	3371748	Cap, Drain
35	3374757	Shaft, Absorber
36	3378202	Weight, Absorber
37	3378083	Thermostat
38	3376723	Seal, O-Ring
39	3376358	Retainer, Thermostat
40	9740674	Gasket, Drain Cover

NOTE A: Pump Centering Tool Required For Pump Re-Assembling - Order Item 31.

DISHRACK PARTS

For Model: SUD600HQ0


(White)



1	3368290	Support, Arm (Also Order Items 2 & 8)
2	303722	Clip
3	3377274	Spray Arm, Upper (Also Order Item 8)
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3376961	Wheel & Transport Assembly (4)
7	8051113	Dishrack, Lower (Includes Items 4 & 6)
8	3374702	Support Lock, Spray Arm
9	8051119	Basket, Silverware
11	3376846	Seal, Lower Sprayarm
12	9742998	Track
13	3379941	Stop, Track (4)
14	3377464	Clip, No-Flip
17	3380860	Wheel Assembly (3 Pos.)
18	3369908	Dishrack, Upper
20	3368629	Retainer, Tinerow
21	8051250	Tinerow, Folding
22	3379363	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle
25	3379955	Pivot, Folddown
26	3371264	Cupshelf
27	3369913	Clip, Cupshelf (2)
28	3370993	Basket Assembly Small items

MISCELLANEOUS PARTS

For Model: SUD600HQ0
(White)



1 3369816 Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

ACCESSORY PARTS

Side Panel Kits:
4317925 White
4317929 Almond
Door Spring Kit:
4318050 Heavy Duty

LITERATURE PARTS

LIT8051229 Instructions, Installation
LIT3367007 Instructions, Installation (Supplement) (Locating Your Water Supply)
LIT8051546 Guide, Energy
LIT8051560 Guide, Use & Care
Tech Sheet
LIT9744033 English
LIT9744034 French
LIT0677967 Do-It Yourself, Manual

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017 White
72107 Almond
72032 Black

PAINT, PRESSURIZED SPRAY (13 oz.)

350956 Almond
285006 Superior Black
350942 Primer (White)

PAINT, TOUCH-UP (1 qt.)

978883 Almond (Uncut)
799340 Black (Uncut)

DISHRACK REPAIR

675576 Vinyl Touch-Up (Blue)
675677 Tine Tip Repair Kit (Blue-- Enough For Two Complete Dishracks)
676453 Vinyl Touch-Up (White)
675679 Tine Tip Repair Kit (White-- Enough For Two Complete Dishracks)
676455 Vinyl Touch-Up (Grey)
676458 Tine Tip Repair Kit (Grey-- Enough For Two Complete Dishracks)
675652 Adhesive, Tine Tips