


**SAMSUNG**

## Television Video Cassette Recorder

**Chassis :** C17A (TS-10 )  
**Model :** TW14N34X/BWT  
TX14N34X/XEC  
TX14N3F4X/XEC  
TX14N54X/XEC  
TX14N5F4X/XEC  
TX14N74X/XEC

# **SERVICE** *Manual*

### Television Video Cassette Recorder



### CONTENTS

1. Precautions
2. Specifications
3. Disassembly and Reassembly
4. Alignment and Adjustment
5. Troubleshooting
6. Exploded View and Parts List
7. Electrical Parts List
8. Block Diagram
9. Wiring Diagram
10. Schematic Diagrams



**ELECTRONICS**