



VIDEO CASSETTE RECORDER

Chassis : Khan

SV-665B/660B/460B/265B/260B

SV-665X/660X/460X/260X

SV-660GS/465GS/264GS/160GS/160G

SV-L620K/L80K/L30K/L10K

SV-L625K/L85K/L35K/L23KS/L12K/5L

SV-667I/466I/266I/262I

SV-3000/910/900/810/800/715/710/700


SERVICE Manual

If you want to know additional information which is not included on this Service Manual, please refer to the SV-665B Training manual (AC82-00078A).


VIDEO CASSETTE RECORDER



SV-665B/665X/264GS/160GS/160G/L35K/L30K/L23KS/L12K/L10K/466I/266I/900/800/700



SV-660B/460B/265B/660X/460X/465GS/261I/L85K/L80K/910/810/715/710



SV-660GS/L625K/L620K/667I/3000



SV-260B/260X



SV-5L

CONTENTS

1. Precautions
2. Alignment and Adjustment
3. Exploded View and Parts List
4. Electrical Parts List
5. Block Diagram
6. Schematic Diagrams

