

This Service Manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.

© Samsung Electronics Co., Ltd. MAR. 2004
Printed in Korea
AK82-00514A

SAMSUNG

SERVICE MANUAL

DVD-V340/V440/V540/V27000/V28000, SV-DVD340/DVD440/DVD541/DVD546/DVD641/DVD645



DVD-VCR COMBINATION

Chassis : Kaiser

DVD-V340/V440/V540

DVD-V27000/V28000


SV-DVD340/DVD440/DVD541

SV-DVD546/DVD641/DVD645


SERVICE Manual

If you want to know additional information which is not included on this Service Manual, please refer to the SV-DVD440 Training Manual (AK82-00513A).


DVD-VCR COMBINATION




DVD-V540/V28000 , SV-DVD440/DVD541/DVD641



DVD-V440/V27000 , SV-DVD340



DVD-V340



SV-DVD546/DVD645

CONTENTS

1. Precautions
2. Alignment and Adjustment
3. Exploded Views and Parts List
4. Electrical Parts List
5. Block Diagram
6. Schematic Diagrams